

Condensate Pump Check Valve

To install:

1. Remove tubing from old check valve
2. Unscrew check valve and dispose
3. Install new check valve in place of old
4. Tighten the check valve to factory torque spec 16cm-kg or 14inch-lb to ensure proper seating and sealing of the new valve.
5. Reconnect tubing to valve and test for leaks

