





JACK THE FROSTY SNOWMAN WITH LANTERN STATUE

XCA-831

Read this manual carefully before use and save it for future reference.



**REQUIRES (3) 'AAA' BATTERIES
(BATTERIES NOT INCLUDED)**



INSTALLING BATTERIES

1. Make sure the power switch is turned to the 'OFF' position.
2. Gently remove the battery housing cover.
3. Paying attention to the positive and negative terminals, gently insert three 1.5-Volt 'AAA' batteries (not included).
4. Replace the battery cover and slide the power switch to the 'ON' position.

CLEANING

Do not use harmful additives or abrasive materials to clean any part of this unit. Do not submerge the unit in water.

- Ensure the power button is turned to the 'OFF' position.
- Gently dust with a soft, dry cloth or a clean feather duster.

TROUBLESHOOTING

- Ensure the power button is turned to the 'ON' position.
- Make sure the batteries are installed correctly, observe polarity and ensure contact is good.
- Install new batteries (not included). Do not mix old and new batteries.

! SAFETY STATEMENTS & WARNINGS !

- For indoor use only.
- For decorative purposes only — this item is not a toy!
- Do not use harsh chemicals or abrasive materials to clean the statue.
- Remove batteries if unit is being stored or if it will not be used for long periods of time.
- Promptly remove expelled batteries. Do not mix old and new batteries. Mixing batteries could cause leakage of the acid inside batteries, damaging the unit.
- LED light is not replaceable.
- Manufacturer is not liable for damage or personal injury caused by improper use, inadequate maintenance or neglect of this product.

Any modification to the product or failure to follow recommended care will void the product warranty.