



# Network Video Recorder v4.x

User Manual

COPYRIGHT ©2017 Hangzhou Hikvision Digital Technology Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou Hikvision Digital Technology Co., Ltd. or its subsidiaries (hereinafter referred to be "Hikvision"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of Hikvision. Unless otherwise stipulated, Hikvision does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

## About this Manual

This Manual is applicable to Network Video Recorder (device).

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website (<http://overseas.hikvision.com/en/>).

Please use this user manual under the guidance of professionals.

## Trademarks Acknowledgement

**HIKVISION**® and other Hikvision trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

## Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL HIKVISION, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

## Regulatory Information

### FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**FCC Compliance:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

## EU Conformity Statement



This product and, if applicable, the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE Directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: [www.recyclethis.info](http://www.recyclethis.info)



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: [www.recyclethis.info](http://www.recyclethis.info)

## Industry Canada ICES-003 Compliance

This device meets the CAN ICES-3 (A)/NMB-3(A) standards requirements.

## Applicable Models

This manual applies to the models listed in the following table:

Series	Model
DS-9600NI-I8	DS-9608NI-I8
	DS-9616NI-I8
	DS-9632NI-I8
	DS-9664NI-I8
DS-9600NI-I16	DS-9616NI-I16
	DS-9632NI-I16
	DS-9664NI-I16
DS-7600NI-I2	DS-7608NI-I2
	DS-7616NI-I2
DS-7600NI-I2/P	DS-7608NI-I2/8P
	DS-7616NI-I2/16P
DS-7700NI-I4	DS-7708NI-I4
	DS-7716NI-I4
	DS-7732NI-I4
DS-7700NI-I4/P	DS-7708NI-I4/8P
	DS-7716NI-I4/16P
	DS-7732NI-I4/16P

## Symbol Conventions

The symbols that may be found in this document are defined as follows:

Symbol	Description
 <b>NOTE</b>	Provides additional information to emphasize or supplement important points of the main text.
 <b>WARNING</b>	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 <b>DANGER</b>	Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.

## Safety Instructions

- Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Refer to technical specifications for detailed information.
- Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100 to 240 VAC or 12 VDC according to the IEC60950-1 Standard. Refer to technical specifications for detailed information.
- Do not connect several devices to one power adapter as adapter overload may cause overheating or a fire hazard.
- Make sure that the plug is firmly connected to the power socket.
- If smoke, odor, or noise rise from the device, turn off the power at once, unplug the power cable, and then contact the service center.

## Preventive and Cautionary Tips

Before connecting and operating your device, be advised of the following tips:

- Ensure unit is installed in a well-ventilated, dust-free environment.
- Unit is designed for indoor use only.
- Keep all liquids away from the device.
- Ensure environmental conditions meet factory specifications.
- Ensure unit is properly secured to a rack or shelf. Major shocks or jolts to the unit as a result of dropping it may cause damage to the sensitive electronics within the unit.
- Use the device in conjunction with a UPS if possible.
- Power down the unit before connecting and disconnecting accessories and peripherals.
- A factory recommended HDD should be used for this device.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

## Product Key Features

### General

- Connectable to network cameras, network domes, and encoders
- Connectable to third-party network cameras, including ACTI, Arecont, AXIS, Bosch, Brickcom, Canon, Panasonic, Pelco, Samsung, Sanyo, Sony, Vivotek, Zavio, and cameras that adopt the ONVIF or PSIA protocol
- Connectable to smart IP cameras
- H.265+/H.265/H.264+/H.264/MPEG4 video formats
- PAL/NTSC adaptive video inputs
- Each channel supports dual streams
- Up to 8/16/32/64 network cameras can be added according to model
- Independent configuration for each channel, including resolution, frame rate, bit rate, image quality, etc.
- The quality of the input and output record is configurable

## Local Monitoring

- HDMI/VGA1 and HDMI2/VGA2 outputs provided
- HDMI video output at up to 4K resolution
- Multiple screen display in Live View is supported, and the display sequence of channels is adjustable
- Live view screen can be switched in groups. Manual switch and auto-switch are provided and the auto-switch interval is configurable.
- 3D positioning supported by I Series devices in Live View
- Configurable main stream and sub-stream for Live View
- Quick setting menu is provided for Live View
- POS information overlay on Live View
- Motion detection, video tampering, video exception alert, and video loss alert functions
- Privacy mask
- Multiple PTZ protocols supported; PTZ preset, patrol, and pattern
- Zooming in by clicking the mouse and PTZ tracing by dragging the mouse

## HDD Management

- Up to 16 SATA hard disks and 1 eSATA disk can be connected for DS-9600NI-M8 and DS-96128NI-I16/C, and up to 8 SATA hard disks and 1 eSATA disk can be connected for DS-9600NI-M8
- Up to 8 TB storage capacity for each disk supported
- Supports 8 network disks (NAS/IP SAN disk)
- Supports S.M.A.R.T. and bad sector detection
- HDD group management
- Supports HDD standby function
- HDD property: redundancy, read-only, read/write (R/W)
- HDD quota management; different capacities can be assigned to different channels
- RAID 0, RAID 1, RAID 5, RAID 6, and RAID 10 are supported
- Hot-swappable RAID storage scheme, can be enabled and disabled upon demand. 16 arrays can be configured.
- Disk clone to the eSATA disk
- HDD health monitoring

## Recording, Capture, and Playback

- Holiday recording schedule configuration
- Continuous and event video recording parameters
- Multiple recording types: manual, continuous, alarm, motion, motion | alarm, motion & alarm VCA, and POS
- Eight recording time periods with separated recording types
- POS information overlay on image by I Series devices
- Pre-record and post-record for alarm, motion detection for recording, and pre-record time for schedule and manual recording

- Searching record files and captured pictures by events (alarm input/motion detection)
- Tag adding for record files, searching and playing back by tags
- Locking and unlocking record files
- Local redundant recording and capture
- Normal/important/custom video playback mode
- Searching and playing back record files by channel number, recording type, start time, end time, etc.
- Supports playback by main stream or sub stream.
- Smart search for the selected area in the video
- Zooming in when playback
- Reverse playback of multi-channels
- Supports pause, play reverse, speed up, speed down, skip forward, and skip backward when playback, and locating by dragging the mouse
- Supports thumbnails view and fast view during playback
- Up to 16-ch synchronous playback at 1080p real time
- Supports playback by transcoded stream
- Manual capture, continuous capture of video images, and playback of captured pictures.
- Supports enabling H.264+ to ensure high video quality with lowered bitrate.

### **Files Management**

- Search and export important files
- Search and export vehicle detection files and human appearance files
- Export video data by USB, SATA, or eSATA device
- Export video clips when playback
- Either Normal or Hot Spare working mode is configurable to constitute an N+1 hot spare system

### **Alarm and Exception**

- Configurable arming time of alarm input/output
- Alarm for video loss, motion detection, tampering, abnormal signal, video input/output standard mismatch, illegal login, network disconnected, IP confliction, abnormal record/capture, HDD error, and HDD full, etc.
- POS triggered alarms supported by I Series devices
- VCA detection alarm is supported
- Smart analysis for people counting and heat map
- Connectable to the thermal network camera
- Supports advanced search for fire/ship/temperature/temperature difference detection triggered alarm and the recorded video files and pictures
- Alarm triggers full screen monitoring, audio alarm, notifying surveillance center, sending e-mail, and alarm output.
- Automatic restore when system is abnormal

## Other Local Functions

- Operable by front panel, mouse, remote control, or control keyboard
- Three-level user management; admin user is allowed to create many operating accounts and define their operating permission, which includes the limit to access any channel
- Admin password resetting by exporting/importing a GUID file
- Operation, alarm, exceptions, and log recording and searching
- Manually triggering and clearing alarms
- Import and export device configuration information

## Network Functions

- Two self-adaptive 10M/100M/1000 Mbps network interfaces
- IPv6 is supported
- TCP/IP protocol, DHCP, DNS, DDNS, NTP, SADP, SMTP, NFS, and iSCSI are supported
- TCP, UDP, and RTP for unicast
- Auto/Manual port mapping by UPnP™
- Supports access by Hik-Connect
- Remote Web browser access by HTTPS ensures high security
- ANR (Automatic Network Replenishment) function is supported, which enables the IP camera to save the recording files in the local storage when the network is disconnected, then synchronizes the files to the device when the network is resumed
- Remote reverse playback via RTSP
- Supports accessing the platform via ONVIF
- Remote search, playback, download, locking and unlocking of the record files, and supports downloading files upon broken transfer resume
- Remote parameters setup; remote import/export of device parameters
- Remote viewing of the device status, system logs, and alarm status
- Remote keyboard operation
- Remote HDD formatting and program upgrading
- Remote system restart and shutdown
- RS-232, RS-485 transparent channel transmission
- Alarm and exception information can be sent to the remote host
- Remotely start/stop recording
- Remotely start/stop alarm output
- Remote PTZ control
- Remote JPEG capture
- Virtual host function to access and manage the IP camera directly
- Two-way audio and voice broadcasting
- Embedded Web server

## **Development Scalability**

- SDK for Windows system
- Source code of application software for demo
- Development support and training for application system

**TABLE OF CONTENTS**

Chapter 1 Introduction	15
1.1 Front Panel	15
1.1.1 DS-9600NI Series	15
1.1.2 DS-7700NI Series	17
1.1.3 DS-7600NI Series	17
1.2 IR Remote Control Operations	18
1.3 USB Mouse Operation	22
1.4 Rear Panel	23
1.4.1 DS-9600NI Series	23
1.4.2 DS-7600NI Series	24
1.4.3 DS-7700NI Series	24
Chapter 2 Menu Tree	26
Chapter 3 Getting Started	27
3.1 Starting the Device	27
3.2 Activating the Device	28
3.3 Configuring the Login Unlock Pattern	29
3.4 Log In to the Device	30
3.4.1 Log In via the Unlock Pattern	30
3.4.2 Log In via a Password	31
3.5 Starting the Setup Wizard	32
3.6 Entering the Main Menu	35
3.7 System Operation	36
3.7.1 Logging Out	36
3.7.2 Shutting Down the Device	37
3.7.3 Rebooting the Device	37
Chapter 4 Camera Management	38
4.1 Adding IP Cameras	38
4.1.1 Adding IP Cameras Manually	38
4.1.2 Adding Automatically Searched Online IP Cameras	39
4.2 Managing PoE Cameras	39
4.2.1 Adding PoE Cameras	39
4.2.2 Adding Non-PoE IP Cameras	39
4.2.3 Configuring PoE Interfaces	40
4.3 Configuring Customized Protocols	41
Chapter 5 Camera Settings	43
5.1 Configuring OSD Settings	43
5.2 Configuring Privacy Mask	44

5.3 Configuring Video Parameters	45
5.4 Configuring the Day/Night Switch	45
5.5 Configuring Other Camera Parameters	45
Chapter 6 Live View	47
6.1 Starting Live View	47
6.1.1 Digital Zoom	48
6.1.2 Fisheye View	48
6.1.3 3D Positioning	49
6.1.4 Live View Strategy	49
6.2 Target Detection	50
6.3 Configuring Live View Settings	51
6.4 Configuring Live View Layout	52
6.5 Configuring Camera Auto-Switch	52
6.6 Configuring Channel-Zero Encoding	53
Chapter 7 PTZ Control	54
7.1 PTZ Control Wizard	54
7.2 Configuring PTZ Parameters	55
7.3 Setting PTZ Presets, Patrols, and Patterns	56
7.3.1 Setting Presets	56
7.3.2 Calling Presets	57
7.3.3 Setting Patrols	57
7.3.4 Calling a Patrol	59
7.3.5 Setting a Pattern	60
7.3.6 Calling a Pattern	60
7.3.7 Setting Linear Scan Limits	61
7.3.8 Calling Linear Scan	61
7.3.9 One-Touch Park	62
7.4 Auxiliary Functions	63
Chapter 8 Storage	64
8.1 Storage Device Management	64
8.1.1 Installing the HDD	64
8.1.2 Adding Network Disks	64
8.1.3 Configuring eSATA for Data Storage	66
8.2 Storage Mode	67
8.2.1 Configuring HDD Groups	67
8.2.2 Configuring HDD Quota	69
8.3 Recording Parameters	70
8.3.1 Main Stream	70
8.3.2 Sub-Stream	70

8.3.3 Picture	71
8.3.4 ANR	71
8.3.5 Configuring Advanced Recording Settings	71
8.4 Configuring Recording Schedules	72
8.5 Configuring Continuous Recording	75
8.6 Configuring Motion Detection Triggered Recordings	75
8.7 Configuring Event Triggered Recordings	77
8.8 Configuring Alarm Triggered Recordings	78
8.9 Configuring POS Event Triggered Recordings	80
8.10 Configuring Picture Capture	80
8.11 Configuring Holiday Recording and Capture	81
8.12 Configuring Redundant Recording and Capture	82
Chapter 9 Disk Array (RAID)	84
9.1 Creating a Disk Array	84
9.1.1 Enabling a RAID	84
9.1.2 One-Touch Creation	85
9.1.3 Manual Creation	85
9.2 Rebuilding an Array	86
9.2.1 Configuring a Hot Spare Disk	87
9.2.2 Automatically Rebuilding an Array	87
9.2.3 Manually Rebuilding an Array	87
9.3 Deleting an Array	88
9.4 Checking and Editing Firmware	89
Chapter 10 File Management	90
10.1 Searching and Exporting All Files	90
10.1.1 Searching Files	90
10.1.2 Exporting Files	91
10.2 Searching and Exporting Human Pictures	91
10.2.1 Searching Human Pictures	91
10.2.2 Exporting Human Pictures	92
10.3 Searching and Exporting Vehicle Files	93
10.3.1 Searching Vehicle Pictures	93
10.3.2 Exporting Vehicle Pictures	94
10.4 Searching History Operation	95
10.4.1 Saving Search Conditions	95
10.4.2 Calling Search History	95
Chapter 11 Playback	96
11.1 Playing Video Files	96
11.1.1 Instant Playback	96

11.1.2	Playing Video	96
11.1.3	Playing Tag Files	97
11.1.4	Playing by Smart Search	99
11.1.5	Playing Event Files	101
11.1.6	Playing by Sub-Periods	104
11.1.7	Playing Log Files	104
11.1.8	Playing External Files	107
11.2	Playback Operations	107
11.2.1	Normal/Important/Custom Video	107
11.2.2	Setting Play Strategy in Important/Custom Mode	108
11.2.3	Editing Video Clips	108
11.2.4	Switching Between Main Stream and Sub-Stream	109
11.2.5	Thumbnails View	109
11.2.6	Fisheye View	109
11.2.7	Fast View	110
11.2.8	Digital Zoom	110
11.2.9	POS Information Overlay	111
Chapter 12	Event and Alarm Settings	112
12.1	Configuring Arming Schedule	112
12.2	Configuring Alarm Linkage Actions	112
12.3	Configuring Motion Detection Alarms	114
12.4	Configuring Video Loss Alarms	116
12.5	Configuring Video Tampering Alarms	116
12.6	Configuring Sensor Alarms	117
12.6.1	Configuring Alarm Inputs	117
12.6.2	Configuring One-Key Disarming	118
12.6.3	Configuring Alarm Outputs	119
12.7	Configuring Exceptions Alarms	120
12.8	Setting Alarm Linkage Actions	122
12.8.1	Configuring Auto-Switch Full Screen Monitoring	122
12.8.2	Configuring Audio Warning	122
12.8.3	Notifying Surveillance Center	123
12.8.4	Configuring E-Mail Linkage	123
12.8.5	Triggering Alarm Outputs	123
12.8.6	Configuring PTZ Linkage	124
12.9	Triggering or Clearing Alarm Output Manually	124
Chapter 13	VCA Event Alarm	126
13.1	Face Detection	126
13.2	Vehicle Detection	127

13.3 Line Crossing Detection	128
13.4 Intrusion Detection	129
13.5 Region Entrance Detection	130
13.6 Region Exiting Detection	131
13.7 Unattended Baggage Detection	133
13.8 Object Removal Detection	134
13.9 Audio Exception Detection	135
13.10 Sudden Scene Change Detection	136
13.11 Defocus Detection	137
13.12 PIR Alarm	138
Chapter 14 Smart Analysis	140
14.1 People Counting	140
14.2 Heat Map	140
Chapter 15 POS Configuration	142
15.1 Configuring POS Settings	142
15.1.1 Configuring POS Connection	142
15.1.2 Configuring POS Text Overlay	147
15.2 Configuring POS Alarm	148
Chapter 16 Network Settings	150
16.1 Configuring TCP/IP Settings	150
16.1.1 Device with Dual Network Interface	150
16.1.2 Device with a Single Network Interface	151
16.2 Configuring Hik-Connect	152
16.3 Configuring DDNS	153
16.4 Configuring PPPoE	154
16.5 Configuring NTP	154
16.6 Configuring SNMP	155
16.7 Configuring E-Mail	156
16.8 Configure Ports	158
Chapter 17 Hot Spare Device Backup	160
17.1 Set Hot Spare Device	160
17.2 Set Working Device	161
17.3 Manage Hot Spare System	161
Chapter 18 System Maintenance	163
18.1 Storage Device Maintenance	163
18.1.1 Configuring Disk Clone	163
18.1.2 S.M.A.R.T. Detection	164
18.1.3 Bad Sector Detection	165
18.1.4 HDD Health Detection	166

18.2 Search and Export Log Files	167
18.2.1 Searching the Log Files	167
18.2.2 Exporting Log Files	168
18.3 Importing/Exporting IP Camera Configuration Files	169
18.4 Importing/Exporting Device Configuration Files	170
18.5 Upgrading the System	171
18.5.1 Upgrading with a Local Backup Device	171
18.5.2 Upgrading by FTP	171
18.6 Restore Default Settings	172
Chapter 19 General System Settings	173
19.1 Configuring General Settings	173
19.2 Configuring the Date and Time	174
19.3 Configuring the DST Settings	175
19.4 Managing User Accounts	175
19.4.1 Adding a User	175
19.4.2 Setting User Permissions	177
19.4.3 Setting Local Live View Permission for Non-Admin Users	180
19.4.4 Editing the Admin User	181
19.4.5 Editing an Operator/Guest User	182
19.4.6 Deleting a User	183
Chapter 20 Appendix	184
20.1 Glossary	184
20.2 Troubleshooting	185

# Chapter 1 Introduction

## 1.1 Front Panel

### 1.1.1 DS-9600NI Series




Figure 1-1 DS-9600NI-I8 Series




Figure 1-2 DS-9600NI-I16 Series

Table 1-1 Panel Description

No.	Name	Function Description	
1	Status Indicators	ALARM	Red when a sensor alarm is detected
		READY	Blue when the device is functioning properly
		STATUS	Blue when device is controlled by an IR remote
			Red when controlled by a keyboard, purple when IR remote and keyboard used at same time
		HDD	Flickers red when data is being read from or written to HDD
		MODEM	Reserved for future usage
		Tx/Rx	Flickers blue when network connection is functioning properly
GUARD	Blue when the device is in armed status; at this time, an alarm is enabled when an event is detected.		
	Off when the device is unarmed. The arm/disarm status can be changed by pressing and holding the ESC button for more than 3 seconds in Live View mode.		
2	IR Receiver	Receiver for IR remote control	
3	Front Panel Lock	Locks or unlocks the panel by the key	
4	DVD-R/W	Slot for DVD-R/W disk	
5	Alphanumeric Buttons	Switches to the corresponding channel in Live View or PTZ control mode	
		Inputs numbers and characters in edit mode	
		Switches between channels in playback mode	
		Blue when the corresponding channel is recording; red when the channel is in network transmission status; pink when the channel is recording and transmitting	
6	USB Interfaces	Universal Serial Bus (USB) ports for devices such as USB mouse and USB Hard Disk Drive (HDD)	
7	Composite Keys	ESC	Returns to the previous menu
			Press to arm/disarm the device in Live View mode
		REC/SHOT	Enters the Manual Record settings menu
			Press followed by a numeric button to call a PTZ preset in PTZ control settings
		PLAY/AUTO	Turns audio on/off in playback mode
			Enters playback mode
		ZOOM+	Automatically scans in the PTZ control menu
			Zooms in the PTZ camera in the PTZ control setting
		A/FOCUS+	Adjusts focus in the PTZ Control menu
			Switches input method (upper and lower case alphabet, symbols, numeric)
		EDIT/IRIS+	Edits text fields. When editing text fields, also deletes character in front of cursor.
			Checks the checkbox in checkbox fields.
			Adjusts the camera iris in PTZ control mode
			Generates video clips for backup in playback mode
		MAIN/SPOT/ZOOM-	Enters/exits the USB device and eSATA HDD folder
			Switches between main and spot output
F1/LIGHT	Zooms out the image in PTZ control mode		
	Selects all items used in a list field		
F2/AUX	Turns on/off PTZ light (if applicable) in PTZ control mode		
	Switches between play and reverse play in playback mode		
MENU/WIPER	Cycles through tab pages		
	Switches between channels in synchronous playback mode		
	Returns to the Main menu (after successful login)		
PREV/FOCUS-	Press and hold button for five seconds to turn off audible key beep		
	Starts wiper (if applicable) in PTZ control mode		
PTZ/IRIS-	Shows/hides the control interface in playback mode		
	Switches between single screen and multi-screen mode		
8	Control Buttons	DIRECTION	Adjusts the focus in conjunction with the A/FOCUS+ button in PTZ control mode
			Enters the PTZ Control mode
			Adjusts the PTZ camera iris in PTZ control mode
		ENTER	Navigates between menu fields and items
In playback mode, use the Up and Down buttons to speed up and slow down recorded video. Use the Left and Right buttons to select the next and previous video files.			
Cycles through channels in Live View mode			
9	JOG SHUTTLE Control	Controls PTZ camera movement in PTZ control mode	
		Confirms selection in any menu mode	
		Checks the checkbox fields	
		Plays or pauses the video playing in playback mode	
		Advances the video by a single frame in single-frame playback mode	
10	POWER ON/OFF	Stops/starts auto switch in auto-switch mode	
		Moves the active selection up and down in a menu	
		Cycles through channels in Live View mode	
		Jumps 30s forward/backward in video files in playback mode	
		Controls PTZ camera movement in PTZ control mode	
		Long press for more than 3 seconds to turn on/off the device	

### 1.1.2 DS-7700NI Series




Figure 1-3 DS-7700NI Series

Table 1-2 Panel Description

No.	Name	Function Description	
1	Status Indicators	POWER	Green when device is powered up
		HDD	Blinks red when HDD is reading/writing
		Tx/Rx	Blinks green when network connection is functioning normally
2	ENTER	Confirms selection in menu mode; or used to check checkbox fields and ON/OFF switch	
		Play/pause video in playback mode	
		Play video by a single frame in single-frame play mode	
3	DIRECTION	Pause/resume auto sequence in auto sequence view mode	
		Navigate between fields and items and select setting parameters in menu mode	
		Up/Down buttons speed up and slow down record playing, and Left/Right buttons move the recording 30s forwards or backwards, in playback mode	
4	Back	Up/Down buttons adjust the image parameters level bar in the image setting interface. Buttons switch channels in Live View mode.	
5	POWER ON/OFF	Back to previous menu	
6	MENU	Power on/off switch	
7	USB Interface	Access the main menu interface	
		Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD)	

### 1.1.3 DS-7600NI Series




Figure 1-4 DS-7600NI Series

Table 1-3 Panel Description

No.	Name	Connections
1	POWER	Green when device is powered up
2	HDD	Flickers red when data is being read from or written to HDD
3	Tx/Rx	Flickers blue when network connection is functioning properly
4	USB Interface	Universal Serial Bus (USB) port for additional devices such as USB mouse and USB Hard Disk Drive (HDD)

## 1.2 IR Remote Control Operations

The device may be controlled with the included IR remote control, shown in Figure 1-5.



Batteries (2 × AAA) must be installed before operation.

The IR remote control is set at the factory to control the device (using default Device ID# 255) without any additional steps. Device ID# 255 is the default universal device identification number shared by the devices. You may also pair an IR remote control to a specific device by changing the Device ID#, as follows:

### Pairing (Enabling) the IR Remote Control to a Specific Device (optional)

You can pair an IR remote control to a specific device by creating a user-defined Device ID#. This feature is useful when using multiple IR remote controls and devices.

#### On the NVR:

**Step 1** Go to System > General.

**Step 2** Type a number (255 digits maximum) into the Device No. field.

#### On the IR Remote Control:

**Step 1** Press the **DEV** button.

**Step 2** Use the number buttons to enter the Device ID# that was entered into the device.

**Step 3** Press the **Enter** button to accept the new Device ID#.




Figure 1-5 Remote Controller

## Unpairing (Disabling) an IR Remote Control from a Device

To unpair an IR remote control from a device so that the unit cannot control any device functions, proceed as follows:

Press the DEV key on the IR remote control. Any existing Device ID# will be erased from the unit’s memory and it will no longer function with the device.

 **NOTE**

(Re)-enabling the IR remote control requires pairing to a device. See “Pairing the IR Remote Control to a Specific Device (optional),” above.

The remote control keys closely resemble the ones on the device front panel. See table 1.4.

Table 1-4 IR Remote Functions

No.	Name	Function Description
1	POWER ON/OFF	<ul style="list-style-type: none"> <li>• To Turn Power On                             <ul style="list-style-type: none"> <li>- If user has not changed the default device Device ID# (255)                                     <ol style="list-style-type: none"> <li>1. Press Power On/Off button (1).</li> </ol> </li> <li>- If user has changed the device Device ID#                                     <ol style="list-style-type: none"> <li>1. Press DEV button.</li> <li>2. Press number buttons to enter user-defined Device ID#.</li> <li>3. Press Enter button.</li> <li>4. Press Power button to start device.</li> </ol> </li> </ul> </li> <li>• To Turn Device Off                             <ul style="list-style-type: none"> <li>- If User Is Logged On                                     <ol style="list-style-type: none"> <li>1. Hold Power On/Off button (1) down for five seconds to display "Yes/No" verification prompt.</li> <li>2. Use Up/Down arrow buttons (12) to highlight desired selection.</li> <li>3. Press Enter button (12) to accept selection.</li> </ol> </li> <li>- If User Is Not Logged On                                     <ol style="list-style-type: none"> <li>1. Hold Power On/Off button (1) down five seconds to display user name/password prompt.</li> <li>2. Press the Enter button (12) to display the on-screen keyboard.</li> <li>3. Input the user name.</li> <li>4. Press the Enter button (12) to accept input and dismiss the on-screen keyboard.</li> <li>5. Use the Down Arrow button (12) to move to the "Password" field.</li> <li>6. Input password (use on-screen keyboard or numeric buttons (3) for numbers).</li> <li>7. Press the Enter button (12) to accept input and dismiss the on-screen keyboard.</li> <li>8. Press the OK button on the screen to accept input and display the Yes/No" verification prompt (use Up/Down Arrow buttons (12) to move between fields).</li> <li>9. Press the Enter button (12) to accept selection.</li> </ol> </li> </ul> </li> </ul> <p>User name/password prompts depend on device configuration. See "System Configuration."</p>
2	DEV	Enable IR Remote: Press DEV button, enter device Device ID# with number keys, press Enter to pair unit with the device Disable IR Remote: Press DEV button to clear Device ID#; unit will no longer be paired with device
3	Numerals	Switch to the corresponding channel in Live View or PTZ Control mode Input numbers in Edit mode
4	EDIT	Delete characters before cursor Check the checkbox and select the ON/OFF switch
5	A	Adjust focus in the PTZ Control menu Switch on-screen keyboards (upper and lower case alphabet, symbols, and numerals)
6	REC	Enter Manual Record setting menu Call a PTZ preset by using the numeric buttons in PTZ control settings Turn audio on/off in Playback mode
7	PLAY	Go to Playback mode Auto scan in the PTZ Control menu
8	INFO	Reserved
9	VOIP	Switches between main and spot output Zooms out the image in PTZ control mode
10	MENU	Return to Main menu (after successful login) N/A Show/hide full screen in Playback mode
12	DIRECTION	Navigate between fields and menu items Up/Down speeds up/slows down recorded video, Left/Right advances/rewinds 30 secs in Playback mode Cycle through channels in Live View mode Control PTZ camera movement in PTZ control mode
	ENTER	Confirm selection in any menu mode Checks checkbox Play or pause video in Playback mode Advance video a single frame in single-frame Playback mode Stop/start auto switch in auto-switch mode
13	PTZ	Enter PTZ Control mode
14	ESC	Go back to previous screen N/A
15	RESERVED	Reserved
16	F1	Select all items on a list N/A Switch between play and reverse play in Playback mode
17	PTZ Control	Adjust PTZ camera iris, focus, and zoom
18	F2	Cycle through tab pages Switch between channels in Synchronous Playback mode

## Troubleshooting the Remote Control



Make sure you have installed batteries properly in the remote control. Also, you have to aim the remote control at the IR receiver on the front panel.

If there is no response after you press any button on the remote, follow the procedure below to troubleshoot.

**Step 1** Go to **System > General** by operating the front control panel or the mouse.

**Step 2** Check and remember device ID#. The default ID# is 255. This ID# is valid for all the IR remote controls.

**Step 3** Press the **DEV** button on the remote control.

**Step 4** Enter the device ID# you set in step 2.

**Step 5** Press the **ENTER** button on the remote.

If the Status indicator on the front panel turns blue, the remote control is operating properly. If the Status indicator does not turn blue and there is still no response from the remote, check the following:

- Batteries are installed correctly and the polarities of the batteries are not reversed
- Batteries are fresh and not out of charge
- IR receiver is not obstructed
- No fluorescent lamp is used nearby

If the remote still doesn't function properly, change to a different remote and try again, or contact the device provider.

## 1.3 USB Mouse Operation

A regular 3-button (Left/Right/Scroll-wheel) USB mouse can also be used with this device. To use a USB mouse:

**Step 1** Plug the USB mouse into one of the USB interfaces on the front panel of the device.

**Step 2** The mouse should automatically be detected. If in a rare case that the mouse is not detected, the possible reason may be that the two devices are not compatible, refer to the recommended device list from your provider.

The operation of the mouse:

Table 1-5 Description of the Mouse Control

Name	Action	Description
Left-Click	Single-Click	Live view: Select channel and show the quick set menu Menu: Select and enter
	Double-Click	Live view: Switch between single-screen and multi-screen
	Click and Drag	PTZ control: pan, tilt and zoom Video tampering, privacy mask, and motion detection: Select target area Digital zoom-in: Drag and select target area Live view: Drag channel/time bar
Right-Click	Single-Click	Live View: Show menu Menu: Exit current menu to upper level menu
Scroll-Wheel	Scrolling Up	Live view: Previous screen Menu: Previous item
	Scrolling Down	Live view: Next screen Menu: Next item

# 1.4 Rear Panel

## 1.4.1 DS-9600NI Series




Figure 1-6 DS-9600NI-I8 Series




Figure 1-7 DS-9600NI-I16 Series

Table 1-6 Panel Description

No.	Name	Description
1	LAN1/LAN2 Interface	2 RJ-45 10/100/1000 Mbps self-adaptive Ethernet interfaces provided
2	LINE IN	RCA connector for audio input
3	AUDIO OUT	2 RCA connectors for audio output
4	HDMI1/HDMI2	HDMI video output connector
5	VGA1/VGA2	DB-9 connector for VGA output. Display local video output and menu.
6	USB 3.0 interface	Universal Serial Bus ports for devices such as USB mouse, USB Hard Disk Drive (HDD)
7	RS-232 Interface	Connector for RS-232 devices
8	eSATA	Connects external SATA HDD, CD/DVD-RM
9	Controller Port	D+, D- pins connect to Ta, Tb pins of controller. For cascading devices, the first device's D+, D- pin should be connected to the D+, D- pin of the next device
	ALARM IN	Connector for alarm input
	ALARM OUT	Connector for alarm output
10	100 to 240 VAC	100 to 240 VAC power supply
11	Power Switch	Switch for turning on/off the device
12	GROUND	Ground (needs to be connected when device starts)

### 1.4.2 DS-7600NI Series




Figure 1-8 DS-7600NI-I2 Series




Figure 1-9 DS-7600NI-I2/8P Series



DS-7616NI-I2/16P provides 16 network Interfaces with PoE.

Table 1-7 Panel Description

No.	Name	Description
1	Audio In	RCA connector for audio input
2	Audio Out	RCA connector for audio output
3	VGA Interface	DB-9 connector for VGA output. Display local video output and menu.
4	HDMI Interface	HDMI video output connector
5	ALARM IN	Connector for alarm input
	ALARM OUT	Connector for alarm output
6	LAN Network Interface	1 10/100/1000 Mbps self-adaptive Ethernet interface
7	USB Interface	Universal Serial Bus (USB 3.0) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD)
8	Ground	Ground (needs to be connected when device starts)
9	Power Supply	12 VDC power supply for DS-7600NI-I4, and 100 to 240 VAC for DS-7600NI-I4/P
10	Power Switch	Switch for turning on/off the device
11	Network Interfaces with PoE function (supported by DS-7600NI-I2/P)	Network interfaces for the cameras and to provide power over Ethernet

### 1.4.3 DS-7700NI Series




Figure 1-10 DS-7700NI-I4 Series




Figure 1-11 DS-7700NI-I4/16P Series


**NOTE**

DS-7708NI-I4/8P provides eight network Interfaces with PoE.

Table 1-8 Panel Description

No.	Name	Description
1	LAN Interface	1 network interface provided for DS-7700NI-I4/P, and 2 network interfaces for DS-7700NI-I4
2	AUDIO OUT	RCA connector for audio output
3	LINE IN	RCA connector for audio input
4	HDMI	HDMI video output connector
5	USB 3.0 interface	Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD)
6	RS-232 Interface	Connector for RS-232 devices
7	VGA	DB-9 connector for VGA output. Display local video output and menu.
8	RS-485 Interface	Half-duplex connector for RS-485 devices
9	ALARM IN	Connector for alarm input
	ALARM OUT	Connector for alarm output
10	GROUND	Ground (needs to be connected when device starts)
11	AC 100V to 240V	100 to 240 VAC power supply
12	Power Switch	Switch for turning on/off the device
13	Network Interfaces with PoE function (supported by DS-7700NI-I4/P)	Network interfaces for the cameras and to provide power over Ethernet

# Chapter 2 Menu Tree



# Chapter 3 Getting Started



## 3.1 Starting the Device

### Purpose

Proper startup and shutdown procedures are crucial to expanding the life of the device.

### Before You Start

Check that the voltage of the extra power supply matches the device's requirement and the ground connection is working properly.

### Powering Up the Device

- Step 1** Check that the power supply is plugged into an electrical outlet. It is **HIGHLY** recommended that an Uninterruptible Power Supply (UPS) be used in conjunction with the device. The Power indicator LED on the front panel should be red, indicating the device is receiving power.
- Step 2** Press **POWER** on the front panel. The Power indicator LED should turn blue indicating that the unit is starting.
- Step 3** After startup, the Power indicator LED remains blue. A splash screen with the status of the HDD appears on the monitor. The row of icons at the bottom of the screen shows the HDD status. 'X' means that the HDD is not installed or cannot be detected.

## 3.2 Activating the Device

### Purpose

For the first-time access, you need to activate the device by setting an admin password. No operation is allowed before activation. You can also activate the device via Web Browser, SADP, or Client Software.

**Step 1** Input the same password in the **Create New Password** and **Confirm New Password** text fields.

### NOTE

Click  to show the characters input.




Figure 3-1 Setting Admin Password

### WARNING

We highly recommend you create a strong password of your own choosing (using a minimum of eight characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. We also recommend that you reset your password regularly. Especially in high security systems, resetting the password monthly or weekly can better protect your product.

**Step 2** Click **OK** to save the password and activate the device.

**Step 3** When the device is activated, the system pops up a message box to remind you to properly keep the password. Click **OK** to export the GUID file for future password resetting.



Figure 3-2 Properly Keep Your Password Reminder

### NOTE

If Admin's password is modified, a dialog box pops up. Optionally, click **Yes** to duplicate the password to connected IP cameras.

## 3.3 Configuring the Login Unlock Pattern

You can configure a device login unlock pattern for the admin user.

**Step 1** After the device is activated, enter the following interface to configure the device unlock pattern.

**Step 2** Use the mouse to draw a pattern among the nine dots on the screen. Release the mouse when the pattern is done.




Figure 3-3 Draw the Pattern

### NOTE

Connect at least four dots to draw the pattern.

Each dot can be connected only once.

**Step 3** Draw the same pattern again to confirm it. When the two patterns match, the pattern is configured successfully.



If the two patterns are different, you must set the pattern again.

## 3.4 Log In to the Device

### 3.4.1 Log In via the Unlock Pattern



Only the *admin* user has permission to unlock the device.

Configure the pattern before unlocking. Refer to Chapter 3.3 Configuring the Login Unlock Pattern.

**Step 1** Right-click the mouse and select the menu to enter the interface.




Figure 3-4 Draw the Unlock Pattern

**Step 2** Draw the pre-defined pattern to unlock and enter the menu operation.



If you have forgotten your pattern, select **Forgot My Pattern** or **Switch User** to enter the normal login dialog box.

If the pattern you draw is different from the pattern you configured, try again.

If you draw the wrong pattern more than five times, the system will switch to the normal login mode automatically.

## 3.4.2 Log In via a Password

### Purpose

If the device has logged out, you must log in to the device before operating the menu and other functions.

**Step 1** Select your **User Name** in the drop-down list.




Figure 3-5 Login Interface

**Step 2** Input password.

**Step 3** Click **Login** to log in.



If you forget the admin password, click **Forgot Password** to reset the password.



In the Login dialog box, if you enter the wrong password seven times, the current user account will be locked for 60 seconds.

## 3.5 Starting the Setup Wizard




Figure 3-6 Setup Wizard

By default, the Setup Wizard starts once the device has loaded.

The Setup Wizard walks you through some important basic device settings. If you don't want to use the Setup Wizard at that moment, click **Exit**.

**Step 2** Configure the date and time on the Date and Time Setup interface.




Figure 3-7 Date and Time Settings

**Step 3** After the time settings, click **Next** to enter the Network Setup Wizard window, as shown in the following figure.

Figure 3-8 Network Settings

**Step 4** Click **Next** after configuring the network parameters, which takes you to the **HDD Management** window.

Label	Capacity	Status	Property	Type	Free Space
5	931.52GB	Normal	R/W	Local	876.00GB
7	931.52GB	Normal	R/W	Local	831.00GB

Figure 3-9 HDD Management

**Step 5** To initialize the HDD, click **Init**. Initialization deletes all data saved in the HDD.

**Step 6** Click **Next** to enter the **Camera Setup** interface to add IP cameras.

- 1) Click **Search** to search online IP cameras. Before adding a camera, make sure the IP camera to be added is in active status.
- 2) Click **Add** to add the camera.

 **NOTE**

If the camera is in inactive status, select the camera from the list and click **Activate**.




Figure 3-10 Search for IP Cameras

**Step 7** Enter Platform Access and configure the Hik-Connect settings.




Figure 3-11 Hik-Connect Access

**Step 8** Click **Next** to enter the **Change Password** interface to create a new admin password if required.



Figure 3-12 Change Password

**NOTE**

Click  to show the characters input.

- 1) Check the **New Admin Password** checkbox.
- 2) Enter the original password in the **Admin Password** text field.
- 3) Input the same password in the **New Password** and **Confirm** text fields.
- 4) Check the **Unlock Pattern** checkbox to enable login via the unlock pattern.

**WARNING**

We highly recommend you create a strong password of your own choosing (using a minimum of eight characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. We also recommend that you reset your password regularly. Especially in high security systems, resetting the password monthly or weekly can better protect your product.

**Step 9** Click **OK** to complete the startup Setup Wizard.

### 3.6 Entering the Main Menu

**Step 1** After you have completed the Setup Wizard, right-click on the screen to enter the main menu bar. Refer to the following figure and table for descriptions of the main menu and sub-menus.



Figure 3-13 Main Menu Bar

Table 3-1 Description of Icons

Icon	Description
	Live View
	Playback
	File Management
	Smart Analysis
	Camera Management
	Storage Management
	System Management
	System Maintenance:

## 3.7 System Operation

### 3.7.1 Logging Out

#### Purpose

After logging out, the monitor turns to Live View mode. To perform any operations, you need to log in again.

**Step 1** Click  on the menu bar.



Figure 3-14 Logout

**Step 2** Click **Logout**.

 **NOTE**

After you log out of the system, menu operations on the screen are invalid. You must input a user name and password to unlock the system.

### 3.7.2 Shutting Down the Device

**Step 1** Click  on the menu bar.



Figure 3-15 Shutdown Menu

**Step 2** Click Shutdown.

**Step 3** Click **Yes**.

 **NOTE**

Do not press **POWER** again when the system is shutting down.

### 3.7.3 Rebooting the Device

From the Shutdown menu, you can also reboot the device.

**Step 1** Click  on the menu bar.

**Step 2** Click **Reboot** to reboot the device.

# Chapter 4 Camera Management

## 4.1 Adding IP Cameras

### 4.1.1 Adding IP Cameras Manually

#### Purpose


Before you can view live video or record video files, you must add the network cameras to the device's connection list.

#### Before You Start

Ensure the network connection is valid and the IP camera has been activated.

**Step 1** Click  on the main menu bar to enter the Camera Management interface.

**Step 2** Click the **Custom Add** tab on the title bar to enter the Add IP Camera interface.



Add IP Camera (Custom)	
IP Camera Address	110.110.1.11
Protocol	ONVIF
Management Port	80
Transfer Protocol	Auto
User Name	admin
Password	*****
<input type="button" value="Continue to Add"/> <input type="button" value="Add"/>	

Figure 4-1 Add IP Camera

**Step 3** Input the IP address, protocol, management port, and other information.

**Step 4** Enter the IP camera's login user name and password.

**Step 5** Click **Add** to finish adding the IP camera.

**Step 6** (Optional) Click **Continue to Add** to add additional IP cameras.

## 4.1.2 Adding Automatically Searched Online IP Cameras

**Step 1** On the Camera Management interface, click the **Online Device** panel to expand the Online Device interface.

**Step 2** Select the automatically searched online devices.

**Step 3** Click **Add**.



If the IP camera you wish to add has not been activated, activate it from the IP camera list on the camera management interface.

## 4.2 Managing PoE Cameras



This chapter is applicable only to the following models: DS-7600NI-I2/P, DS-7700NI-I4/P Series.

### Purpose

The PoE interfaces enable the device system to pass electrical power safely, along with data, on Ethernet cabling to the connected PoE cameras. The number of PoE cameras supported varies by device model.

If you disable the PoE interface, you can connect to online network cameras. Also, the PoE interface supports the Plug-and-Play function.

For example, for DS-7608NI-I2/8P, to connect six network cameras via PoE interfaces and two online cameras, disable two PoE interfaces in the Edit IP Camera menu.

Follow the steps to add network cameras for devices that support the PoE function.

### 4.2.1 Adding PoE Cameras

**Step 1** Connect PoE cameras to the device's PoE ports with network cables.

**Step 2** Go to **Camera > Camera > IP Camera** to view camera images and information.

### 4.2.2 Adding Non-PoE IP Cameras

You can disable the PoE interface by selecting manual while the current channel can be used as a normal channel and the parameters can also be edited.

**Step 1** Go to **Camera > Camera > IP Camera**.

**Step 2** Position the cursor on a window with no linked IP camera and click .

Figure 4-2 Edit IP Camera

**Step 3** Set Adding Method to **Manual**.

- **Plug-and-Play:** The camera is physically connected to the PoE interface. Its parameters cannot be edited. You can go to **System > Network > TCP/IP** to change the IP address of the PoE port.
- **Manual:** Add IP camera without a physical connection, via the network.

**Step 4** Enter the IP address, the user name, and password of administrator manually.

**Step 5** Click **OK**.

## 4.2.3 Configuring PoE Interfaces

### Purpose

When long-distance PoE transmission (100 to 300 m) is required, enable long distance mode for the PoE channel.

**Step 1** Go to **Camera > Camera > PoE Settings**.

**Step 2** Enable or disable long network cable mode by selecting **Long Distance** or **Short Distance** radio.

- **Long Distance:** Long-distance (100 to 300 meters) network transmissions via PoE interface.
- **Short Distance:** Short-distance (<100 meters) network transmission via PoE interface.




Figure 4-3 PoE Settings



The PoE ports are enabled with the short distance mode by default.

The bandwidth of an IP camera connected to the PoE via long network cable (100 to 300 meters) cannot exceed 6 MP.

The allowed maximum long network cable may be less than 300 meters, depending on IP camera model and cable materials.

When the transmission distance reaches 100 to 250 meters, you must use CAT-5E or CAT-6 network cable to connect with the PoE interface.

When the transmission distance reaches 250 to 300 meters, you must use CAT-6 network cable to connect with the PoE interface.

Refer to Appendix **Error! Reference source not found.** for the list of IP cameras.

**Step 3** Click **Apply**.

### 4.3 Configuring Customized Protocols

#### Purpose

To connect the network cameras that are not configured with the standard protocols, you can configure customized protocols for them. The system provides 16 customized protocols.

**Step 1** Click **Protocol** at the top taskbar to enter the protocol management interface.

Figure 4-4 Protocol Management

**Step 2** Select the protocol type of transmission and choose the transfer protocols.

- **Type:** The network camera adopting custom protocols must support getting streams through standard RTSP.
- **Path:** Contact the network camera manufacturer to consult the URL (uniform resource locator) for getting main stream and sub-stream.

The format of the URL is: [Type]://[IP Address of the network camera]:[Port]/[Path].

**Example:** rtsp://192.168.1.55:554/ch1/main/av\_stream.

 **NOTE**

The protocol type and the transfer protocols must be supported by the connected IP camera.

After adding the customized protocols, the protocol name will be listed in the drop-down list.

# Chapter 5 Camera Settings

## 5.1 Configuring OSD Settings

### Purpose

You can configure the OSD (On-screen Display) settings for the camera, including date/time, camera name, etc.

**Step 1** Go to **Camera > Display**.

**Step 2** Select the camera from the drop-down list.

**Step 3** Edit the name in the **Camera Name** text field.

**Step 4** Check the **Display Name**, **Display Date**, and **Display Week** checkbox(es) to show the information on the image.

**Step 5** Set the date format, time format, and display mode.




Figure 5-1 OSD Configuration Interface

**Step 6** Use the mouse to click and drag the text frame on the preview window to adjust the OSD position.

**Step 7** Click **Apply** to apply the settings.

## 5.2 Configuring Privacy Mask

### Purpose

The privacy mask protects personal privacy by concealing parts of the image from view or recording with a masked area.

**Step 1** Go to **Camera > Privacy Mask**.

**Step 2** Select the camera on which to set the privacy mask.

**Step 3** Click the **Enable** checkbox to enable this feature.

**Step 4** Use the mouse to draw a zone on the window. The zones will be marked by different frame colors.




Figure 5-2 Privacy Mask Settings Interface

### NOTE

Up to four privacy masks zones can be configured and the size of each area can be adjusted.

Clear the configured privacy mask zones on the window by clicking the corresponding Clear Zone 1-4 icons on the right of the window, or click **Clear All** to clear all zones.

**Step 5** Click **Apply** to save the settings.

## 5.3 Configuring Video Parameters

### Purpose

You can customize the image parameters including the brightness, contrast, and saturation for the Live View and recording effect.

**Step 1** Go to **Camera > Display**.

**Step 2** Select a camera from the drop-down list.

**Step 3** Adjust the slider or click on the up/down arrow to set the value of the brightness, contrast, or saturation.

**Step 4** Click **Apply** to save the settings.

## 5.4 Configuring the Day/Night Switch

**Step 1** The camera can be set to day, night, or auto switch mode according to the surrounding illumination conditions.

**Step 2** Go to **Camera > Display**.

**Step 3** Select the camera from the drop-down list.

**Step 4** Set the day/night switch mode to **Day**, **Night**, **Auto**, or **Auto-Switch**.

- **Auto:** The camera automatically switches between day mode and night mode according to the illumination.

The sensitivity ranges from 0 to 7, and higher sensitivity more easily triggers the mode switch.

The switch time refers to the interval between the day/night switch. You can set it from five sec to 120 sec.

- **Auto-Switch:** The camera switches the day mode and the night mode according to the start time and end time you set.

**Step 5** Click **Apply** to save the settings.

## 5.5 Configuring Other Camera Parameters

For a connected camera, you can configure the camera parameters including the exposure mode, backlight, and image enhancement.

**Step 1** Go to **Camera > Display**.

**Step 2** Select a camera from the drop-down list.

**Step 3** Configure the camera parameters.

- **Exposure:** Set the camera exposure time (1/10000 to 1 sec). A larger exposure value results in a brighter image.
- **Backlight:** Set the camera's wide dynamic range (0 to 100). When the surrounding illumination and the object have large differences in brightness, you should set the WDR value.
- **Image Enhancement:** For optimized image contrast enhancement.

**Step 4** Click **Apply** to save the settings.

# Chapter 6 Live View

Live View displays the video image from each camera in real time. The device automatically enters Live View mode when powered on. It is also at the very top of the menu hierarchy, thus pressing **ESC** many times brings you back to Live View mode.

## 6.1 Starting Live View

**Step 1** The system automatically enters the Live View interface when starting, or you can click



on the main menu bar to enter the Live View interface.

**Step 2** Click to select a window for Live View.

**Step 3** Double-click the IP camera on the left list to start playing the live video.



Figure 6-1 Live View

**Step 4** Use the toolbar at the window bottom for capture, instant playback, audio on/off, digital zoom, Live View strategy, show information and start/stop recording, etc.

## 6.1.1 Digital Zoom

Digital Zoom zooms into the live image in different magnifications (1x to 16x).

**Step 1** In Live View mode, click  from the toolbar to enter the digital zoom interface.

**Step 2** Move the sliding bar or scroll the mouse wheel to zoom in/out the image to different magnifications (1x to 16x).



Figure 6-2 Digital Zoom

## 6.1.2 Fisheye View

The device supports the fisheye camera expansion in Live View or playback mode.

### NOTE

The fisheye expansion view feature is supported only by the DS-7600/7700/9600-I (/P) Series.

The connected camera must support the fisheye view.

**Step 1** In the Live View mode, click  to enter the fisheye expansion mode.

**Step 2** Select the expansion view mode.

- **180° Panorama** (): Switch the Live View image to 180° panorama view.
- **360° Panorama** (): Switch the Live View image to 360° panorama view.

- **PTZ Expansion** (): The PTZ Expansion is the close-up view of a defined area in the fisheye view or panorama expansion. It supports the electronic PTZ function, also called e-PTZ.
- **Radial Expansion** (): In radial expansion mode, the whole wide-angle view of the fisheye camera is displayed. This mode is called Fisheye View because it approximates the vision of a fish's convex eye. The lens produces curvilinear images of a large area, while distorting the perspective and angles of objects in the image.

### 6.1.3 3D Positioning

3D Positioning (for I Series devices) zooms in/out of a specific live image area.

**Step 1** In Live View mode, click  to enter the 3D positioning mode.

**Step 2** Zoom in/out of the image.

- **Zoom In**

Use the left mouse key to click on the desired position in the video image and drag a rectangle area in the lower right direction to zoom in.

- **Zoom Out**

Use the left mouse key to drag a rectangle area in the upper left direction to move the position to the center and enable the rectangle area to zoom out.

### 6.1.4 Live View Strategy

**Step 1** In Live View mode, click  to enter the digital zoom interface in full screen mode.

**Step 2** Set the Live View strategy to **Real-time**, **Balanced**, or **Fluency**.

## 6.2 Target Detection

In Live View mode, the target detection function can detect a human motion/face/vehicle/human body during the last five seconds and the following 10 seconds.

**Step 1** In Live View mode, click  to enter the target detection interface.

**Step 2** Check the checkboxes to select different detection types: motion detection (  ), vehicle detection (  ), face detection (  ), and human body detection (  ).

**Step 3** Select historical analysis (  ) or real-time analysis (  ) to obtain the results.




Figure 6-3 Target Detection

**Step 4** The smart analysis results of the detection are displayed in the list.

## 6.3 Configuring Live View Settings

Live View settings can be customized. You can configure the output interface, dwell time for screen to be shown, mute or turning on the audio, the screen number for each channel, etc.

**Step 1** Go to **System > Live View > General**.

The screenshot shows the 'Live View - General' settings page. It features two columns of settings. The left column includes: 'Video Output Interface' set to 'VGA/HDMI', 'Live View Mode' set to '2 \* 2', 'Dwell Time' set to '5s', 'Enable Audio Output' with a checked checkbox, and a 'Volume' slider ranging from 1 to 5. The right column includes: 'Event Output' set to 'VGA/HDMI' and 'Full Screen Monitoring Dwell Time' set to '10s'. A blue 'Apply' button is positioned at the bottom left of the settings area.

Figure 6-4 Live View-General

**Step 2** Configure the Live View parameters.

- **Video Output Interface:** Select the video output to configure.
- **Live View Mode:** Select the display mode for Live View, e.g., 2\*2, 1\*5, etc.
- **Dwell Time:** The time in seconds to wait between switching cameras when using auto-switch in Live View.
- **Enable Audio Output:** Enable/disable audio output for the selected video output.
- **Volume:** Adjust the Live View volume, playback, and two-way audio for the selected output.
- **Event Output:** Select the output to show event video.
- **Full Screen Monitoring Dwell Time:** Set the time in seconds to show alarm event screen.

**Step 3** Click **OK** to save the settings.

## 6.4 Configuring Live View Layout

**Step 1** Go to **System > Live View > View Settings**.




Figure 6-5 Live View

**Step 2** Select the video output interface, e.g., HDMI/VGA or channel-zero.

**Step 3** Select a window division mode from the toolbar.

**Step 4** Select a division window, and double-click on a camera in the list to set the camera to the window.

**Step 5** You can enter the number in the text field to quickly search the camera from the list.



You can also click-and-drag the camera to the desired window on the Live View interface to set the camera order.

Click  to start Live View for all channels.

Click  to stop all Live View channels.

**Step 6** Click **Apply** to save the settings.

## 6.5 Configuring Camera Auto-Switch

You can set the cameras' auto-switch to play in different display modes.

**Step 1** Go to **System > Live View > General**.

**Step 2** Set the video output interface, Live View mode, and dwell time.

- **Video Output Interface:** Select the video output interface.
- **Live View Mode:** Select the display mode for Live View, e.g., 2\*2, 1\*5, etc.
- **Dwell Time:** The time in seconds to wait between switching of cameras when in auto-switch. The range is from 5s to 300s.

**Step 3** Go to **View Settings** to set the view layout.

**Step 4** Click **OK** to save the settings.

## 6.6 Configuring Channel-Zero Encoding

### Purpose


Enable channel-zero encoding when you need a remote view of many channels in real time from a Web browser or CMS (Client Management System) software, in order to decrease the bandwidth requirement without affecting the image quality.

**Step 1** Go to **System > Live View > General**.

**Step 2** Set the video output interface to **Channel-Zero**.

**Step 3** Go to **System > Live View > Channel-Zero**.

**Step 4** Check the Enable Channel-Zero Encoding checkbox.



The screenshot displays the configuration options for Channel-Zero Encoding. At the top, the checkbox 'Enable Channel-Zero Encoding' is checked. Below it are three dropdown menus: 'Frame Rate' is set to 'Full Frame', 'Max. Bitrate Mode' is set to 'General', and 'Max. Bitrate(Kbps)' is set to '1792'. A blue 'Apply' button is located at the bottom of the configuration area.

Figure 6-6 Live View, Channel-Zero Encoding

**Step 5** Configure the **Frame Rate**, **Max. Bitrate Mode**, and **Max. Bitrate**. The higher frame rate and bitrate settings result in higher bandwidth requirement.

**Step 6** Click **Apply**.

**Result:** You can view all of the channels on one screen using the CMS or a Web browser.

# Chapter 7 PTZ Control

## 7.1 PTZ Control Wizard

### Before You Start

Make sure the connected IP camera supports the PTZ function and is properly connected.

### Purpose

Follow the PTZ Control Wizard to guide you through the basic PTZ operations.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View. The PTZ Control Wizard pops up as below.



Figure 7-1 PTZ Control Wizard

**Step 2** Follow the PTZ Control Wizard to adjust the PTZ view, focus, and zoom in/out.

**Step 3** (Optional) Check Do not show this prompt again checkbox.

**Step 4** Click **OK** to exit.


## 7.2 Configuring PTZ Parameters

### Purpose

Follow these procedures to set the PTZ parameters. The PTZ parameters configuration must be done before you can control the PTZ camera.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View. The PTZ control panel displays on the right of the interface.

**Step 2** Click **PTZ Parameters Settings** to set the PTZ parameters.



Parameter	Value
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None
Flow Ctrl	None
PTZ Protocol	PELCO-C
Address	0

Address range: 0~255

OK Cancel

Figure 7-2 PTZ Parameters Settings

**Step 3** Edit the PTZ camera parameters.

### NOTE

All the parameters should match the PTZ camera parameters.

**Step 4** Click **OK** to save the settings.

## 7.3 Setting PTZ Presets, Patrols, and Patterns

### Before You Start

Make sure that the presets, patrols, and patterns are supported by PTZ protocols.

### 7.3.1 Setting Presets

#### Purpose

Follow these steps to set the preset location that you want the PTZ camera to point to when an event takes place.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Use the directional buttons on the PTZ control panel to wheel the camera to the location where you want to set a preset, and the zoom and focus operations can be recorded in the preset as well.

**Step 4** Click  in the lower right corner of Live View to set the preset.




Figure 7-3 Set Preset

**Step 5** Select the preset No. (1 to 255) from the drop-down list.

**Step 6** Enter the preset name in the text field.

**Step 7** Click **Apply** to save the preset.

**Step 8** Repeat steps 2-6 to save more presets.

**Step 9** (Optional) Click **Cancel** to cancel the location information of the preset.

**Step 10** (Optional) Click  in the lower right corner of Live View to view the configured presets.




Figure 7-4 View the Configured Presets

## 7.3.2 Calling Presets

### Purpose

A preset enables the camera to point to a specified position such as a window when an event takes place.

**Step 1** Click  on the quick settings toolbar of the PTZ camera Live View.

**Step 2** Click  in the lower right corner of Live View.

**Step 3** Select the preset No. from the drop-down list.

**Step 4** Click **Call** to call it, or click  in the lower right corner of Live View, and click the configured preset to call it.



Figure 7-5 Call Preset (1)



Figure 7-6 Call Preset (2)

## 7.3.3 Setting Patrols

### Purpose

Patrols can be set to move the PTZ to key points and have it stay there for a set duration before moving on to the next key point. The key points correspond to the presets.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click **Patrol** to configure patrol.



Figure 7-7 Patrol Configuration

**Step 4** Select the patrol No. in the text field.

**Step 5** Click **Set** to enter the Patrol Settings interface.




Figure 7-8 Patrol Settings

**Step 6** Click to add a key point to the patrol.




Figure 7-9 Key Point Configuration

- 1) Configure key point parameters.
  - **Preset:** Determines the order the PTZ will follow while cycling through the patrol.
  - **Speed:** Defines the speed the PTZ will move from one key point to the next.
  - **Duration:** Refers to the duration to stay at the corresponding key point.
- 2) Click **Apply** to save the key points to the patrol.

**Step 7** (Optional) Click to edit the added key point.

KeyPoint	
Preset	Preset 1
Speed	1
Duration	15
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

Figure 7-10 Edit Key Point

**Step 8** (Optional) Select a key point and click  to delete it.

**Step 9** (Optional) Click  or  to adjust the key point order.

**Step 10** Click **Apply** to save the patrol settings.

**Step 11** Repeat steps 3-9 to set more patrols.

### 7.3.4 Calling a Patrol

#### Purpose

Calling a patrol makes the PTZ move according to the predefined patrol path.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click **Patrol** on the PTZ control panel.

Aux Function	Patrol	Pattern
Patrol1		
 Set	 Call	 Stop

Figure 7-11 Patrol Configuration

**Step 4** Select a patrol in the text field.

**Step 5** Click **Call** to start the patrol.

**Step 6** (Optional) Click **Stop** to stop the patrol.

## 7.3.5 Setting a Pattern

### Purpose

Patterns can be set by recording the movement of the PTZ. You can call the pattern to make the PTZ move according to the predefined path.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click **Pattern** to configure a pattern.




Figure 7-12 Pattern Configuration

**Step 4** Select the pattern No. in the text field.

**Step 5** Set the pattern.

- 1) Click **Record** to start recording.
- 2) Click corresponding buttons on the control panel to move the PTZ camera.
- 3) Click **Stop** to stop recording. The PTZ movement is recorded as the pattern.

**Step 6** Repeat steps 3-4 to set more patterns.

## 7.3.6 Calling a Pattern

### Purpose

Follow the procedure to move the PTZ camera according to the predefined patterns.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click **Pattern**.



Figure 7-13 Pattern Configuration

**Step 4** Select a pattern in the text field.

**Step 5** Click **Call** to start the pattern.

**Step 6** (Optional) Click **Stop** to stop the pattern.

### 7.3.7 Setting Linear Scan Limits

#### Before You Start

Make sure the connected IP camera supports the PTZ function and is properly connected.

#### Purpose

Linear Scan trigger a scan in the horizontal direction in the predefined range.

#### NOTE

This function is supported only by certain models.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click the **directional buttons** to wheel the camera to the location of where you want to set the limit, and click **Left Limit** or **Right Limit** to link the location to the corresponding limit.

#### NOTE

The speed dome linear scans from the left limit to the right limit, and you must set the left limit on the left side of the right limit. Also, the angle from the left limit to the right limit must be no more greater than 180°.

### 7.3.8 Calling Linear Scan

#### NOTE

Before operating this function, make sure the connected camera supports linear scan and is in HIKVISION protocol.

## Purpose

Follow the procedure to call the linear scan in the predefined scan range.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click **Linear Scan** to start the linear scan and click it again to stop it.

**Step 4** (Optional) Click **Restore** to clear the defined left limit and right limit data.



Reboot the camera to have the settings take effect.

## 7.3.9 One-Touch Park



Before operating this function, make sure the connected camera supports linear scan and is in HIKVISION protocol.

### Purpose

Certain speed dome models can be configured to start a predefined park action (scan, preset, patrol, etc.) automatically after a period of inactivity (park time).

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click Park (Quick Patrol), Park (Patrol 1), or Park (Preset 1) to activate the park action.

- **Park (Quick Patrol):** The dome starts patrolling from the predefined preset 1 to preset 32 in order after the park time. Undefined presets will be skipped.
- **Park (Patrol 1):** The dome starts moving according to the predefined patrol 1 path after the park time.
- **Park (Preset 1):** The dome moves to the predefined preset 1 location after the park time.



The park time can be set only via the speed dome configuration interface. The default value is 5s.

**Step 4** Click Stop Park (Quick Patrol), Stop Park (Patrol 1), or Stop Park (Preset 1) to inactivate it.

## 7.4 Auxiliary Functions

### Before You Start

Make sure the connected IP camera supports the PTZ function and is properly connected.

### Purpose

You can operate the auxiliary functions including light, wiper, 3D positioning, and center on the PTZ control panel.

**Step 1** Click  on the quick settings toolbar of the PTZ camera's Live View.

**Step 2** The PTZ control panel displays on the right of the interface.

**Step 3** Click Aux Function.




Figure 7-14 Aux Function Configuration

**Step 4** Click the icons to operate the aux functions. See the table for the icon descriptions.

Table 7-1 Description of Aux Functions Icons

Icon	Description
	Light on/off
	Wiper on/off
	3D positioning
	Center

# Chapter 8 Storage

## 8.1 Storage Device Management

### 8.1.1 Installing the HDD

Before starting the device, install and connect an HDD to the device. Refer to the Quick Start Guide for installation instructions.

### 8.1.2 Adding Network Disks

You can add the allocated NAS or IP SAN disk to the device, and use it as a network HDD. Up to eight network disks can be added.

#### Adding a NAS

**Step 1** Go to **Storage > Storage Device**.

**Step 2** Click **Add** to enter the Custom Add interface.

**Step 3** Select NetHDD from the drop-down list.

**Step 4** Set the type to NAS.

**Step 5** Enter the NetHDD IP address in the text field.

**Step 6** Click **Search** to search the available NAS disks.

The screenshot shows a 'Custom Add' dialog box with the following fields and values:

- NetHDD:** NetHDD 1 (dropdown menu)
- Type:** NAS (dropdown menu)
- NetHDD IP:** 120 . 36 . 2 . 39 (text field)
- NetHDD Directory:** /nas/device1/11 (text field with a search button to its right)

At the bottom of the dialog are two buttons: **OK** and **Cancel**.

Figure 8-1 Add NAS Disk

**Step 7** Select the NAS disk from the list, or manually enter the directory in the NetHDD Directory text field.

**Step 8** Click **OK** to complete adding the NAS disk.

**Step 9** After successfully adding the NAS disk, return to the HDD Information menu. The added NetHDD will be displayed in the list.

### Adding an IP SAN

**Step 1** Go to **Storage > Storage Device**.

**Step 2** Click **Add** to enter the Custom Add interface.

**Step 3** Select NetHDD from the drop-down list.

**Step 4** Set the type to IP SAN.

**Step 5** Enter the NetHDD IP address in the text field.

**Step 6** Click **Search** to search the available IP SAN disks.

**Step 7** Select the IP SAN disk from the list.

**Step 8** Click **OK** to complete adding the IP SAN disk.

### NOTE

A single IP SAN disk can be added.

Figure 8-2 Add IP SAN Disk

**Step 9** After having successfully added the IP SAN disk, return to the HDD Information menu. The added NetHDD will be displayed in the list.

 **NOTE**

If the installed HDD or NetHDD is uninitialized, select it and click **Init** for initialization.

### 8.1.3 Configuring eSATA for Data Storage

When there is an external eSATA device connected to the device, you can configure eSATA for data storage, and you can manage the eSATA in the device.

**Step 1** Click Storage > Advanced.

**Step 2** Set the eSATA type to Export or Record/Capture from the drop-down **eSATA** list.

- **Export:** Use the eSATA for backup.
- **Record/Capture:** Use the eSATA for record/capture. Refer to the following steps for operating instructions.

Figure 8-3 Set eSATA Mode

**Step 3** When the eSATA type is set to Record/Capture, enter the storage device interface.

**Step 4** Edit the property of the selected eSATA, or initialize it as required.

## 8.2 Storage Mode

### 8.2.1 Configuring HDD Groups

#### Purpose

Multiple HDDs can be managed in groups. Video from specified channels can be recorded onto a particular HDD group through HDD settings.

**Step 1** Go to **Storage > Storage Device**.

**Step 2** Check the checkbox to select the HDD to set the group.

+ Add		Init		Total Capacity 1863.03GB				Free Space 1702.00GB	
<input type="checkbox"/>	Label	Capacity	Status	Property	Type	Free Space	Group	Edit	Delete
<input checked="" type="checkbox"/>	5	931.52GB	Normal	R/W	Local	871.00GB	2		
<input checked="" type="checkbox"/>	7	931.52GB	Normal	R/W	Local	831.00GB	1		

Figure 8-4 Storage Device

**Step 3** Click  to enter the Local HDD Settings interface.

**Local HDD Settings**

HDD No.

HDD Property  R/W  Read-only  Redundan...

Group

1  2  3  4  5  6  7  8  
 9  10  11  12  13  14  15  16

HDD Capacity

Figure 8-5 Local HDD Settings

**Step 4** Select the Group number for the current HDD.

**Step 5** Click **OK**.

 **NOTE**

Regroup the cameras for HDD if the HDD group number is changed.

**Step 6** Go to **Storage > Storage Mode**.

**Step 7** Check the **Group** tab checkbox.

**Step 8** Select the group No. from the list.

**Step 9** Check the checkbox to select the IP camera(s) to record/capture on the HDD group.




Figure 8-6 Storage Mode-HDD Group

**Step 10** Click **Apply**.

 **NOTE**

Reboot the device to activate the new storage mode settings.

## 8.2.2 Configuring HDD Quota

### Purpose


Each camera can be configured with an allocated quota for storing recorded files or captured pictures.

**Step 1** Go to **Storage > Storage Mode**.

**Step 2** Check the **Quota** tab checkbox.

**Step 3** Select a camera for which to set the quota.

**Step 4** Enter the storage capacity in the **Max. Record Capacity (GB)** and **Max. Picture Capacity (GB)** text fields.



The screenshot shows the 'Storage Mode-HDD Quota' configuration window. At the top, there are two radio buttons for 'Mode': 'Quota' (selected) and 'Group'. Below this is a 'Camera' dropdown menu showing '[D1] IPCamera 01'. The 'Used Record Capacity' is 18.00GB, 'Used Picture Capacity' is 2048.00MB, and 'HDD Capacity (GB)' is 1863. The 'Max. Record Capacity (GB)' is set to 1500, and the 'Max. Picture Capacity (GB)' is set to 50. A yellow warning triangle icon is next to the text 'Free Quota Space 313 GB'. At the bottom, there are two buttons: 'Copy to' (grey) and 'Apply' (blue).

Figure 8-7 Storage Mode-HDD Quota

**Step 5** (Optional) Click **Copy to** to copy the quota settings of the current camera to other cameras.

**Step 6** Click **Apply** to apply the settings.

**NOTE**

When the quota capacity is set to 0, all cameras will use the total capacity of the HDD for record and picture capture.

**NOTE**

Reboot the device to activate the new storage mode settings.

## 8.3 Recording Parameters

### 8.3.1 Main Stream

Main Stream refers to the primary stream that affects data recorded to the hard disk drive and will directly determine your recording quality and image size.

Compared to the sub-stream, the main stream can provide higher quality video with higher resolution and frame rate.

**Step 1 Frame Rate** (FPS – Frames Per Second): Refers to how many frames are captured each second. A higher frame rate is advantageous when there is movement in the video stream, as it maintains image quality throughout.

**Step 2 Resolution:** Image resolution is a measure of how much detail a digital image can hold: the greater the resolution, the greater the level of detail. Resolution can be specified as the number of pixel-columns (width) by the number of pixel-rows (height), e.g., 1024 × 768.

**Step 3 Bitrate:** The bit rate (in kbit/s or Mbit/s) is often referred to as speed, but actually defines the number of bits/time unit and not distance/time unit.

**Step 4 Enable H.264+ Mode:** The H.264+ mode helps to ensure high video quality with a lowered bitrate. It effectively reduces the need of bandwidth and HDD storage space.

**NOTE**

A higher resolution, frame rate, and bitrate setting will provide better video quality, but will also require more Internet bandwidth and use more hard disk drive storage space.

### 8.3.2 Sub-Stream

The sub-stream is a second codec that runs alongside the main stream. It reduces the outgoing Internet bandwidth without sacrificing the direct recording quality.

The sub-stream is often exclusively used by smartphone applications to view live video. Users with limited Internet speeds benefit most from this setting.

### 8.3.3 Picture

**Step 1** Picture refers to live picture capture in continuous or event recording type.

**Step 2 Picture Quality:** Set the picture quality to low, medium, or high. Higher picture quality requires more storage space.

**Step 3 Interval:** The interval of capturing live pictures.

### 8.3.4 ANR

ANR (Automatic Network Replenishment) function enables IP cameras to save the recording files in local storage when the network is disconnected. When the network is re-connected, it uploads the files to the device.

**Step 1** Enable the ANR (Automatic Network Replenishment) function via a Web browser (**Configuration > Storage > Schedule Settings > Advanced**).

### 8.3.5 Configuring Advanced Recording Settings

**Step 1** Go to **Storage > Schedule Settings > Record Schedule/Capture Schedule**.

**Step 2** Check the **Enable** checkbox to enable scheduled recording.

**Step 3** Click **Advanced** to set the recording parameters.

The screenshot shows a dialog box titled "Advanced Parameters" with the following settings:

- Record Audio:** A checkbox that is currently unchecked.
- Pre-Record:** A dropdown menu set to "5s".
- Post-Record:** A dropdown menu set to "5s".
- Stream Type:** A dropdown menu set to "Main Stream".
- Expired Time (day):** A text input field containing the number "5".
- Redundant Record/Capture:** A checkbox that is currently unchecked.

At the bottom of the dialog box are two buttons: "OK" (highlighted in blue) and "Cancel".

Figure 8-8 Advanced Record Settings

- **Record Audio:** Check the checkbox to enable or disable audio recording.
- **Pre-record:** The time set to record before the scheduled time or event. For example, if an alarm triggers the recording at 10:00, and the pre-record time is 5 seconds, the device will start to record at 9:59:55.

- **Post-record:** The time set to record after the event or scheduled time. For example, if an alarm triggered recording ends at 11:00, and the post-record time is 5 seconds, the device will record until 11:00:05.
- **Expired Time:** The period of time for a recorded file to be kept in the HDD. When the deadline is reached, the file will be deleted. If the expired time is set to 0, the file will not be deleted. The actual keeping time for the file should be determined by the HDD capacity.
- **Redundant Record/Capture:** Enable redundant record or capture to save the record and captured picture in the redundant HDD. See *Chapter Configuring Redundant Recording and Capture*.
- **Stream Type:** Main stream and sub-stream are selectable for recording. Select sub-stream to record for a longer time with the same storage space.

**Step 4** Click **OK** to save the settings.

## 8.4 Configuring Recording Schedules

The camera automatically starts/stops recording according to the configured schedule.

### Before You Start

Make sure you have installed the HDDs in the device or added the network disks before you attempt to store video files, pictures, and log files.

Refer to the *Quick Start Guide* for HDD installation instructions. Refer to Chapter 8.1.2 Adding Network Disk for network HDD connections.

**Step 1** Go to **Storage > Recording Schedule**.

**Step 2** Select a camera.

**Step 3** Check Enable Schedule.

**Step 4** Select a **Record Type**. The record type can be Continuous, Motion Detection, Alarm, Motion | Alarm, Motion & Alarm, or Event. Different recording types are configurable.

- **Continuous:** Scheduled recording
- **Event:** Recording triggered by an event triggered alarm
- **Motion:** Recording triggered by motion detection
- **Alarm:** Recording triggered by an alarm
- **M/A:** Recording triggered by either motion detection or an alarm
- **M&A:** Recording triggered by motion detection and an alarm
- **POS:** Recording triggered by POS and an alarm

**Step 5** Select a day and click-and-drag the mouse on the time bar to set the record schedule.




Figure 8-9 Record Schedule

**Step 6** Repeat the above steps to schedule recording or capture for other days of the week.

 **NOTE**

All-day continuous recording is the factory default.

**Step 7** (Optional) Copy the schedule settings of the day to the other days of the week or holiday.

- 1) Click the  tab.
- 2) Select the day(s) to duplicate with the same schedule settings.
- 3) Click **OK**.




Figure 8-10 Copy Schedule to Other Days

**Step 8** Click **Apply** to save the settings.

 **NOTE**

To enable Motion, Alarm, M | A (motion or alarm), M & A (motion and alarm), or Event triggered recording and capture, you must configure the motion detection settings, alarm input settings and other events as well. Refer to Chapter 12

Event and Alarm Settings and Chapter 13 VCA Event Alarm for details.

## 8.5 Configuring Continuous Recording

**Step 1** Go to **Camera > Encoding Parameters > Recording Parameters**.

**Step 2** Set the continuous main stream/sub-stream recording parameters for the camera.

**Step 3** Go to **Storage > Recording Schedule**.

**Step 4** Set the record type to **Continuous**.

**Step 5** Set the schedule for the continuous recording. Refer to Chapter 8.4 Configuring Recording Schedule for details.




Figure 8-11 Record Schedule

## 8.6 Configuring Motion Detection Triggered Recordings

You can configure recordings triggered by motion detection events.

**Step 1** Go to **System > Event > Normal Event > Motion Detection**.

**Step 2** Configure motion detection and select the channel(s) to trigger the recording when a motion event occurs. Refer to Chapter 12.3 Configuring Motion Detection Alarm for details.

**Step 3** Go to **Camera > Encoding Parameters > Recording Parameters**.

**Step 4** Set the event main stream/sub-stream recording parameters for the camera.

**Step 5** Go to **Storage > Recording Schedule**.

**Step 6** Set the record type to **Motion**.

**Step 7** Set the schedule for the motion detection triggered recording. Refer to Chapter 8.4 Configuring Recording Schedule for details.

## 8.7 Configuring Event Triggered Recordings

You can configure recordings triggered by motion detection, motion detection and alarm, face detection, vehicle detection, line crossing detection, etc.

**Step 1** Go to **System > Event**.

**Step 2** Configure event detection and select the channel(s) to trigger the recording when an event occurs. Refer to Chapter 12

Event and Alarm Settings and Chapter 13 VCA Event Alarm for details.

**Step 3** Go to **Camera > Encoding Parameters > Recording Parameters**.

**Step 4** Set the event main stream/sub-stream recording parameters for the camera.

**Step 5** Go to **Storage > Recording Schedule**.

**Step 6** Set the record type to **Event**.

**Step 7** Set the event triggered recording schedule. Refer to Chapter 8.4 Configuring Recording Schedule for details.

## 8.8 Configuring Alarm Triggered Recordings

You can configure the recording triggered by the motion detection, face detection, vehicle detection, line crossing detection, etc.

**Step 1** Go to **System > Event > Normal Event > Alarm Input**.

**Step 2** Configure the alarm input and select the channel(s) to trigger the recording when an alarm occurs. Refer to Chapter 12

Event and Alarm Settings and Chapter 13 VCA Event Alarm for details.

**Step 3** Go to **Camera > Encoding Parameters > Recording Parameters**.

**Step 4** Set the event main stream/sub-stream recording parameters for the camera.

**Step 5** Go to **Storage > Recording Schedule**.

**Step 6** Set the record type to **Alarm**.

**Step 7** Set the schedule for the alarm triggered recording. Refer to Chapter 8.4 Configuring Recording Schedule for details.

## 8.9 Configuring POS Event Triggered Recordings

You can configure recordings triggered by connected POS events such as transactions, etc.

**Step 1** Go to **System > POS Settings**.

**Step 2** Configure the POS and select the channel(s) in **Event Linkage** to trigger the recording when a POS event occurs.

**Step 3** Refer to Chapter 14 Smart Analysis for details.

**Step 4** Go to **Camera > Encoding Parameters > Recording Parameters**.

**Step 5** Set the event main stream/sub-stream recording parameters for the camera.

**Step 6** Go to **Storage > Recording Schedule**.

**Step 7** Set the record type to **POS Event**.

**Step 8** Set the schedule for the POS event triggered recording. Refer to Chapter 8.4 Configuring Recording Schedule for details.

## 8.10 Configuring Picture Capture

**Step 1** Picture refers to live picture capture in continuous or event recordings.

**Step 2** Go to **Camera > Encoding Parameters > Capture**.

**Step 3** Set the picture parameters.

- **Resolution:** Set the resolution of the picture to capture.
- **Picture Quality:** Set the picture quality to low, medium, or high. A higher picture quality requires more storage space.
- **Interval:** The interval of capturing live pictures.

**Step 4** Go to **Storage > Capture Schedule**.

**Step 5** Select the camera for which to configure picture capture.




Figure 8-12 Set Picture Capture Schedule

**Step 6** Set the picture capture schedule. See Chapter 8.4 Configuring Recording Schedule.

## 8.11 Configuring Holiday Recording and Capture

### Purpose

Follow these steps to configure the holiday record or capture schedule for the year. You may want to have a different plan for recording and capture on holidays.

**Step 1** Go to **System > Holiday Settings**.

**Step 2** Select a holiday item from the list and click .

**Step 3** Check **Enable** to configure the holiday.

Figure 8-13 Edit Holiday Settings

- 1) Edit the holiday name.
- 2) Set the mode to **by date**, **by week**, or **by month**.
- 3) Set the start and end date of the holiday.
- 4) Click **OK**.

**Step 4** Set the schedule for the holiday recording. Refer to Chapter 8.4 Configuring Recording Schedule for details.

## 8.12 Configuring Redundant Recording and Capture

### Purpose

Enabling redundant recording and capture, which means saving the record files and captured pictures not only in the R/W HDD but also in the redundant HDD, will effectively enhance the data safety and reliability. .

### NOTE

You must set the storage mode to *Group* before you set the HDD property to Redundancy. For detailed information, refer to Chapter 8.2.1 Configuring HDD Group. There should be at least another HDD which is in Read/Write status.

**Step 1** Go to **Storage > Storage Device**.

**Step 2** Select an HDD from the list and click  to enter the Local HDD Settings interface.

**Step 3** Set the HDD property to **Redundancy**.




Figure 8-14 HDD Property-Redundancy

**Step 4** Go to **Storage > Schedule Settings > Record Schedule/Capture Schedule**.

**Step 5** Click **Advanced** to set the camera recording parameters.




Figure 8-15 Record Parameters

**Step 6** Check the Redundant Record/Capture checkbox.

**Step 7** Click **OK** to save the settings.

# Chapter 9 Disk Array (RAID)

## Purpose

A disk array is a data storage virtualization technology that combines multiple physical disk drives into a single logical unit. Also known as a "RAID," an array stores data over multiple HDDs to provide enough redundancy so that data can be recovered if one disk fails. Data is distributed across the drives in one of several ways called "RAID levels" based the redundancy and performance required.



Disk arrays are supported by DS-9600NI-I Series devices only.

## 9.1 Creating a Disk Array

### Purpose

The device supports software-based disk arrays. Enable the RAID function as required. Two ways are available for creating an array: one-touch configuration and manual configuration.

### 9.1.1 Enabling a RAID

#### Purpose

Perform the following steps to enable the disk array function.

**Step 1** Go to **Storage > Advanced**.




Figure 9-1 Advanced

**Step 2** Check **Enable RAID**.

**Step 3** Click **Apply**.

**Step 4** Reboot the device to have the settings take effect.

## 9.1.2 One-Touch Creation

### Purpose

One-touch configuration quickly creates a disk array. By default, the array type created by one-touch configuration is RAID 5.

### Before You Start

Enable the RAID function. For details, refer to Chapter 9.1.1 Enabling a RAID.

Install at least three HDDs. If more than 10 HDDs are installed, two arrays will be created. To maintain reliability and stability when running the HDDs, it is recommended use of enterprise-level HDDs of the same model and capacity.

**Step 1** Go to **Storage > RAID Setup > Physical Disk**.



No.	Capacity	Array	Type	Status	Model	Hot Spare	Task
<input type="checkbox"/> 1	1863.02GB		Normal	Functional	ST2000VX000-1CU164		None
<input type="checkbox"/> 2	2794.52GB		Normal	Functional	ST3000VX000-9YW166		None
<input type="checkbox"/> 5	1863.02GB		Normal	Functional	ST2000VX000-1CU164		None
<input type="checkbox"/> 9	2794.52GB		Normal	Functional	ST3000VX000-1CU166		None
<input type="checkbox"/> 10	1863.02GB		Normal	Functional	ST2000VX000-1CU164		None

Figure 9-2 Physical Disk

**Step 2** Click One-touch Config.

**Step 3** Edit the array name in the **Array Name** text field.

**Step 4** Click **OK** to start configuring.



If you install four or more HDDs, a hot spare disk for array rebuilding will be created.

**Step 5** When a message box pops up when the array creation is complete, click **OK**.

**Step 6** Optionally, the device will automatically initialize the created array. Go to **Storage > RAID Setup > Array** to view the information of the created array.

## 9.1.3 Manual Creation

### Purpose

Manually create a RAID 0, RAID 1, RAID 5, RAID 6, or RAID 10 array.

**Step 1** Go to **Storage > RAID Setup > Physical Disk**.

**Step 2** Click **Create**.




Figure 9-3 Create Array Window

**Step 3** Input the array name.

**Step 4** Select RAID Level as RAID 0, RAID 1, RAID 5, RAID 6, or RAID 10 as required.

**Step 5** Select the physical disks to constitute the array.

Table 9-1 Required Number of HDDs

RAID Level	Required Number of HDDs
RAID 0	At least 2 HDDs
RAID 1	At least 2 HDDs
RAID 5	At least 3 HDDs
RAID 6	At least 4 HDDs
RAID 10	The number of HDDs must be an even range from 4 to 16.

**Step 6** Click **OK**.

**Step 7** Optionally, the device will automatically initialize the created array. Go to **Storage > RAID Setup > Array** to view the information of the created array.




Figure 9-4 Array List

## 9.2 Rebuilding an Array

### Purpose

The array status includes Functional, Degraded, and Offline. To ensure the high security and reliability of the data stored in an array, take immediate and proper maintenance of the array according its status.

- **Functional:** No disk loss in the array
- **Offline:** The number of lost disks has exceeded the limit
- **Degraded:** If any HDD fails in the array, the array degrades. Restore it to Functional status by rebuilding the array.

## 9.2.1 Configuring a Hot Spare Disk

### Purpose

Hot spare disks are required for disk array automatic rebuilding.

**Step 1** Go to **Storage > RAID Setup > Physical Disk**.

No.	Capacity	Array	Type	Status	Model	Hot Spare	Task
1	1863.02GB	Array01	Array	Functional	ST2000VX000-1CU164	—	None
<input type="checkbox"/> 2	2794.52GB		Normal	Functional	ST3000VX000-9YW166	<input checked="" type="checkbox"/>	None
5	1863.02GB	Array01	Array	Functional	ST2000VX000-1CU164	—	None
<input type="checkbox"/> 9	2794.52GB		Normal	Functional	ST3000VX000-1CU166	<input checked="" type="checkbox"/>	None
10	1863.02GB	Array01	Array	Functional	ST2000VX000-1CU164	—	None

Figure 9-5 Physical Disk

**Step 2** Click  of an available HDD to set it as the hot spare disk.

## 9.2.2 Automatically Rebuilding an Array

### Purpose

The device can automatically rebuild degraded arrays with the hot spare disks.

### Before You Start

Create hot spare disks. For details, refer to Chapter 9.2.1 Configuring a Hot Spare Disk.

**Step 1** The device will automatically rebuild degraded arrays with hot spare disks. Go to **Storage > RAID Setup > Array** to view rebuilding progress.

No.	Name	Free Space	Physical Disk	Hot Spare	Status	Level	Rebuild	Delete	Task
1	Array01	3725/3725G	2 5 10		Degraded	RAID 5	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Rebuild(Running) 0%

Figure 9-6 Array List

## 9.2.3 Manually Rebuilding an Array

### Purpose

If no hot spare disks are configured, rebuild a degraded array manually.

### Before You Start

At least one available physical disk must exist to rebuild an array.

**Step 1** Go to **Storage > RAID Setup > Array**.

No.	Name	Free Space	Physical Disk	Hot Spare	Status	Level	Rebuild	Delete	Task
1	Array01	3725/3725G	2 5 10		Degraded	RAID 5			Rebuild(Running) 0%

Figure 9-7 Array List

**Step 2** Click of the degraded array.

**Rebuild Array**

Array Name:

RAID Level:

Array Disk:

Physical Disk:  2  9

Figure 9-8 Rebuild Array

**Step 3** Select the available physical disk.

**Step 4** Click **OK**.

**Step 5** Click **OK** on the pop up message box "Do not unplug the physical disk when it is under rebuilding."

## 9.3 Deleting an Array



Deleting an array will delete all data saved to it.

**Step 1** Go to **Storage > RAID Setup > Array**.

No.	Name	Free Space	Physical Disk	Hot Spare	Status	Level	Rebuild	Delete	Task
1	Array01	3725/3725G	5	10	Degraded	RAID 5			None

Figure 9-9 Array List

**Step 2** Click of the array to delete it.




Figure 9-10 Attention

**Step 3** Click **Yes** on the popup message box.

## 9.4 Checking and Editing Firmware

### Purpose

You can view the firmware information and set the background task speed on the Firmware interface.

**Step 1** Go to **Storage > RAID Setup > Firmware**.

Version	1.1.0.0003
Physical Disk Count	16
Array Count	16
Virtual Disk Count	0
RAID Level	0 1 5 6 10
Hot Spare Type	Global Hot Spare
Support Rebuild	Yes
Background Task Speed	Medium Speed

Figure 9-11 Firmware

**Step 2** Optionally, set the **Background Task Speed**.

**Step 3** Click **Apply**.

# Chapter 10 File Management

## 10.1 Searching and Exporting All Files

### 10.1.1 Searching Files

#### Purpose

Specify detailed conditions to search videos and pictures.

**Step 1** Go to **File Management > All Files**.

**Step 2** Click **Advanced Search** in the menu bar to specify detailed conditions, including time, camera, event type, etc.

The screenshot shows the 'Advanced Search' interface. At the top, there are tabs for 'All Files' and 'Important File'. A date selector is set to 'Today'. On the right, there are tabs for 'All', 'Video', and 'Picture', with a magnifying glass icon and the text 'Advanced ...'. The main area contains several search criteria, each with a dropdown menu or text input field:

- Time: Today
- Camera: [All] Camera
- Tag: (empty text input)
- File Status: None
- Event Type: None
- Tops Color: None
- Gender: None
- Glasses: None
- Age: None
- Backpack: None
- Bicycle: None
- Parent Brand: None
- Plate No: (empty text input)
- Vehicle Color: None
- Vehicle Mode: None
- Area/Country: None

At the bottom, there are three buttons: 'Empty Conditions', 'Search' (highlighted in blue), and 'Save'.

Figure 10-1 Advanced Search

**Step 3** Click **Search** to display results. The matched files are displayed in thumbnails or a list.

**Step 4** Select **Target Picture** or **Source Picture** in the menu bar to display related pictures only. Select **Video** or **Picture** to specify the file type.

- **Target Picture:** Display the search results of vehicle close-ups.
- **Source Picture:** Display the search results of original pictures captured by the camera.
- **Group:** Sort the search results by the selected item.

## 10.1.2 Exporting Files

### Purpose

Export files for backup purposes using a USB device (USB flash drive, USB HDD, USB optical disc drive), SATA optical disc drive, or eSATA HDD.

**Step 1** Search for the vehicle files to export. For details, see 10.1.1 Searching Files.

**Step 2** Click files to select and click **Export**.




Figure 10-2 Export Files

**Step 3** Click **OK** to export pictures to the backup device.

## 10.2 Searching and Exporting Human Pictures

### 10.2.1 Searching Human Pictures

#### Purpose

Specify detailed conditions by which to search human pictures.

#### Before You Start

Configure the human body detection function for the cameras you want to search and export human pictures.

**Step 1** Go to **File Management > People Appearance File**.

**Step 2** Click **Advanced Search** in the menu bar to specify detailed conditions, including time, camera, people appearance, etc.

The screenshot shows the 'Advanced Search' interface. At the top, there are two tabs: 'Target Picture' and 'Source Picture'. To the right of these tabs is a dropdown menu set to 'Today'. Further right are three buttons: 'All', 'Video', and 'Picture', followed by a magnifying glass icon and the text 'Advanced ...'. Below this menu bar, there are several filter categories, each with a dropdown menu: 'Time' (Today), 'Camera' ([All] Camera), 'Tops Color' (None), 'Gender' (None), 'Glasses' (None), 'Age' (None), 'Backpack' (None), and 'Bicycle' (None). At the bottom of the interface, there are three buttons: 'Empty Conditions', 'Search', and 'Save'.

Figure 10-3 Advanced Search

**Step 3** Click **Search** to display results. The matched files are displayed in thumbnails or a list.

**Step 4** Select **Target Picture** or **Source Picture** in the menu bar to display related pictures only. Select **Video** or **Picture** to specify the file type.

- **Target Picture:** Display the search results of people close-ups.
- **Source Picture:** Display the search results of original pictures captured by the camera.
- **Group:** Sort the search results by the selected item.

## 10.2.2 Exporting Human Pictures

### Purpose

Export files for backup purposes using a USB device (USB flash drive, USB HDD, USB optical disc drive), SATA optical disc drive, or eSATA HDD.

**Step 1** Search for the human files to export. For details, see 10.2.1 Searching Human Pictures.

**Step 2** Click files to select and click **Export**.




Figure 10-4 Export Files

**Step 3** Click **OK** to export pictures to the backup device.

## 10.3 Searching and Exporting Vehicle Files

### 10.3.1 Searching Vehicle Pictures

#### Purpose

Specify detailed conditions by which to search vehicle pictures.

#### Before You Start

Configure the vehicle detection function for the cameras you want to search and export vehicle pictures.

**Step 1** Go to **File Management > Vehicle Files**.

**Step 2** Click **Advanced Search** in the menu bar to specify detailed conditions, including time, camera, vehicle appearance, etc.

Figure 10-5 Advanced Search

**Step 3** Click **Search** to display results. The matched files are displayed in thumbnails or a list.

**Step 4** Select **Target Picture** or **Source Picture** in the menu bar to display related pictures only. Select **Video** or **Picture** to specify the file type.

- **Target Picture:** Display the search results of vehicle close-ups.
- **Source Picture:** Display the search results of original pictures captured by the camera.
- **Group:** Sort the search results by selected item.

## 10.3.2 Exporting Vehicle Pictures

### Purpose

Export files for backup purposes to a USB device (USB flash drive, USB HDD, USB optical disc drive), SATA optical disc drive, or eSATA HDD.

**Step 1** Search for the vehicle files to export. For details, see 10.3.1 Searching Vehicle Pictures.

**Step 2** Click files to select and click **Export**.




Figure 10-6 Export Files

**Step 3** Click **OK** to export pictures to the backup device.

## 10.4 Searching History Operation

### 10.4.1 Saving Search Conditions

#### Purpose

You can save the search conditions for future reference and quick searches.

**Step 1** Go to **File Management > All Files/People Appearance File/Vehicle File**.

**Step 2** Click **Advanced Search** in the menu bar and set the search conditions.

**Step 3** Click **Save**.

**Step 4** Enter a name in the text field and click **Finished**. The saved search conditions will be displayed in the Search History list.

### 10.4.2 Calling Search History

#### Purpose

You can quickly search files by calling the Search History.

**Step 1** Go to **File Management > All Files/People Appearance File/Vehicle File**.

**Step 2** Click a saved search condition to search files quickly.

# Chapter 11 Playback

## 11.1 Playing Video Files

### 11.1.1 Instant Playback

Instant Playback enables the device to play video files recorded in the last five minutes. If no video is found, it means there was no recording during the last five minutes.

**Step 1** On the Live View window of the selected camera, move the cursor to the window bottom to access the toolbar.

**Step 2** Click  to start instant playback.



Figure 11-1 Playback Interface

### 11.1.2 Playing Video

**Step 1** Go to Playback.

**Step 2** Select one or more cameras in the camera list.

**Step 3** Select a date in the calendar.

**Step 4** Click **Play** on the toolbar to start playing the video.

**Step 5** You can use the toolbar in the bottom of the playback interface to control the playing and perform a series of operations. Refer to Chapter 11.2 Playback Operations 8.2.



Figure 11-2 Playback Interface




Figure 11-3 Toolbar of Playback

**Step 6** You can click the channel(s) to execute simultaneous playback of multiple channels.

**NOTE**

256x playing speed is supported.

### 11.1.3 Playing Tag Files

#### Purpose

Video tag allows you to record related information such as people and locations of a certain time point during playback. You can use video tag(s) to search for video files and position the time point.

#### Managing Tag Files

**Step 1** Go to **Playback**.

**Step 2** Search and play back the video file(s).

**Step 3** Click  to add the tag.

**Step 4** Edit the tag information.

 **NOTE**

A maximum of 64 tags can be added to a single video file.

**Playing Tag Files**


**Step 5** Go to **Playback**.

**Step 6** Click **Tag** button.

**Step 7** Click **Custom Search** on the left bottom to enter the Search Condition interface.

**Step 8** Click **Smart Search** on the top right corner.

**Step 9** Enter the search conditions for the tag files, including the time and the tag keyword.



The screenshot shows a search interface with the following fields:

- Time:** Custom (dropdown), 2017-08-01 00:00:00 (calendar icon), 2017-08-22 23:59:59 (calendar icon)
- Tag:** A (text input), File Status: None (dropdown)
- Event Type:** None (dropdown)
- Tops Color:** None (dropdown), **Gender:** None (dropdown)
- Glasses:** None (dropdown), **Age:** None (dropdown)
- Backpack:** None (dropdown), **Bicycle:** None (dropdown)
- Parent Brand:** None (dropdown), **Plate No:** (text input)
- Vehicle Color:** None (dropdown), **Vehicle Mode:** None (dropdown)
- Area/Country:** None (dropdown)

Buttons at the bottom: Empty Conditions, Search, Save

Figure 11-4 Tag Search

**Step 10** Click **Search**.




Figure 11-5 Searched Tag Files

**Step 11** On the search results interface, select a tag file and click to start playing the video.



Figure 11-6 Tag Playback

### 11.1.4 Playing by Smart Search

#### Purpose

In Smart Playback mode, the device will analyze the video containing the motion, line, or intrusion detection information, mark it in green, and play it at normal speed. Video without motion will be played in at 16x speed.

The smart playback rules and areas are configurable.

**Step 1** Go to **Playback**.

**Step 2** Start playing the video files by channel or by time.

**Step 3** From the toolbar at the bottom of the playing window, click the motion/line crossing/intrusion icon for search.




Figure 11-7 Playback by Smart Search

**Step 4** Set the rules and areas for smart search by line crossing detection, intrusion detection or motion detection event triggered recording.

- **Line Crossing Detection**

- 1) Click the  icon.
- 2) Click on the image to specify the start point and end point of the line.

- **Intrusion Detection**

- 1) Click the  icon.
- 2) Specify four points to set a quadrilateral region for intrusion detection. Only one region can be set.

- **Motion Detection**

- 1) Click the  icon.
- 2) Hold the mouse on the image to draw the detection area manually.
- 3) Click  to search the matched video and start to play it.

## 11.1.5 Playing Event Files

### Purpose

Play back video files on one or several channels searched by event type (e.g., alarm input, motion detection, line crossing detection, face detection, vehicle detection, etc.).

**Step 1** Go to **Playback**.

**Step 2** Click **Custom Search** on the left bottom to enter the Search Condition interface.

**Step 3** Click **Smart Search** on the top right corner.

**Step 4** Enter the search conditions for the event files, e.g., time, event type, file status, people appearance (for face detection, human detection, etc.), and vehicle information (for vehicle detection event).

Search Criteria	Value
Time	Custom, 2017-08-08 00:00:00, 2017-08-22 23:59:59
Tag	
Event Type	Face (Face Capture)
Tops Color	Yellow
Glasses	All
Backpack	With Baggage
Parent Brand	ALL
Vehicle Color	White
Area/Country	None
File Status	None
Gender	Male
Age	Middle-life
Bicycle	With Bicycle
Plate No	
Vehicle Mode	None

Buttons: Empty Conditions, Search, Save

**Step 5** Click **Search**.

**Step 6** On the search results interface, select an event video file/picture file and click it to start playing the video or double-click it to play the picture.




Figure 11-8 Event Files

**Step 7** Click  or  to select the previous or next event.

 **NOTE**

Refer to Chapter 12

Event and Alarm Settings and Chapter 13 VCA Event Alarm for details for event and alarm settings.

Refer to Chapter 8.7

Configuring Event Triggered Recording for the event triggered recording/capture settings.

### 11.1.6 Playing by Sub-Periods

#### Purpose

The video files can be played in multiple sub-periods simultaneously on the screen.

**Step 1** Go to **Playback**.

**Step 2** Select **Sub-periods** from the drop-down list in the upper-left corner of the page to enter the Sub-Periods Playback interface.

**Step 3** Select a date and start playing the video file. Select the Split-Screen Number from the drop-down list. Up to 16 screens are configurable.




Figure 11-9 Interface of Sub-periods Playback

#### NOTE

According to the defined number of split-screens, the video files on the selected date can be divided into average segments for playback. E.g., if there are video files existing between 16:00 and 22:00, and the 6-screen display mode is selected, then it can play the video files for 1 hour on each screen simultaneously.

### 11.1.7 Playing Log Files

#### Purpose

Play back record file(s) associated with channels after searching system logs.

**Step 1** Go to **Maintenance > Log Information**.

**Step 2** Click the **Log Search** tab to enter Playback by System Logs.

**Step 3** Set search time and type and click **Search**.




Figure 11-10 System Log Search Interface

**Step 4** Choose a log with a video file and click  to start playing the log file.




Figure 11-11 Interface of Playback by Log

## 11.1.8 Playing External Files

### Purpose

You can play files from external storage devices.

### Before You Start

Connect the storage device with the video files to your device.

**Step 1** Go to **Playback**.

**Step 2** Click  at the left bottom corner.

**Step 3** Select and click  or double-click to play the file.




Figure 11-12 External File Playback

## 11.2 Playback Operations

### 11.2.1 Normal/Important/Custom Video

During playback, you can select the following three modes to play the video.

- **Normal:** Video files from continuous recordings
- **Important:** Video files from event and alarm recording triggered recordings
- **Custom:** Video files searched by custom conditions

## 11.2.2 Setting Play Strategy in Important/Custom Mode

### Purpose

In the Important/Custom video playback mode, you can set the playing speed separately for normal video and important/custom video, or you can select to skip the normal video.

**Step 1** In the Important/Custom video playback mode, click  to set the play strategy.

- When **Do not Play Normal Videos** is checked, the device will skip the normal video and play the important (event) video and the custom (searched video) only, in normal speed (x1).
- When **Do not Play Normal Videos** is unchecked, you can set the play speed for the normal video and the important/custom video separately. The speed range is from x1 to xMAX.

### NOTE

You can set the speed in single-channel play mode only.




Figure 11-13 Play Strategy

## 11.2.3 Editing Video Clips

You can take video clips during playback and export the clips.

**Step 1** In Video Playback mode, click  to start the video clipping operation.

- : Set the start time and end time of the video clip.
- : Export the video clips to the local storage device.

## 11.2.4 Switching Between Main Stream and Sub-Stream

You can switch between the main stream and the sub-stream during playback.



: Play the video in main stream.



: Play the video in sub-stream.



**NOTE**

The encoding parameters for the main stream and sub-stream can be configured in **Storage > Encoding Parameters**.

## 11.2.5 Thumbnails View

With the thumbnails view on the playback interface, you can conveniently locate the required video files on the time bar.

In the Video Playback mode, move the mouse to the time bar to preview thumbnails of the video files.




Figure 11-14 Thumbnails View

You can select and double click on a thumbnail to enter full-screen playback.



**NOTE**

Thumbnail view is supported only in 1x single-camera playback mode.

## 11.2.6 Fisheye View

You can enter the fisheye expansion view during the video playback.

**Step 1** Click  to enter the fisheye expansion mode.

- **180° Panorama** (): Switch the Live View image to the 180° panorama view.

- **360° Panorama** (): Switch Live View image to the 360° panorama view.
- **PTZ Expansion** (): The PTZ Expansion is the close-up view of a defined area in the fisheye view or panorama expansion, and it supports the electronic PTZ function, which is also called e-PTZ.
- **Radial Expansion** (): In the radial expansion mode, the whole wide-angle view of the fisheye camera is displayed. This view mode is called Fisheye View because it approximates the vision of a fish's convex eye. The lens produces curvilinear images of a large area, while distorting the perspective and angles of objects in the image.

## 11.2.7 Fast View

Hold the mouse to drag on the time bar to get a fast view of the video files.

**Step 1** In Video Playback mode, hold and drag the mouse through the playing time bar to fast view the video files.

**Step 2** Release the mouse at the required time point to enter full-screen playback.



Fast view is supported only in the 1x single-camera playback mode.

## 11.2.8 Digital Zoom

**Step 1** In Video Playback mode, click  in the toolbar to enter the digital zoom interface.

**Step 2** Move the sliding bar or scroll the mouse wheel to zoom in/out of the image to different magnifications (1x to 16x).



Figure 11-15 Digital Zoom

## 11.2.9 POS Information Overlay

In Video Playback mode, click  to overlay the POS transaction information on the playback video.

 **NOTE**

When the playing speed is higher than 2x, the POS information cannot be overlaid on the video.

# Chapter 12 Event and Alarm Settings

## 12.1 Configuring Arming Schedule

**Step 1** Select the **Arming Schedule** tab.

**Step 2** Choose a day of the week and set the time period. Up to eight time periods can be set each day.



Time periods cannot repeat or overlap.

Area	Arming Schedule	Linkage Action
Mon	00 02 04 06 08 10 12 14 16 18 20 22 24	
Tue	00 02 04 06 08 10 12 14 16 18 20 22 24	
Wed	00 02 04 06 08 10 12 14 16 18 20 22 24	
Thu	00 02 04 06 08 10 12 14 16 18 20 22 24	
Fri	00 02 04 06 08 10 12 14 16 18 20 22 24	
Sat	00 02 04 06 08 10 12 14 16 18 20 22 24	
Sun	00 02 04 06 08 10 12 14 16 18 20 22 24	
Holiday	00 02 04 06 08 10 12 14 16 18 20 22 24	

Figure 12-1 Set Arming Schedule

**Step 3** (Optional) To copy the same arming schedule of the current day to other day(s) of the week or holiday, click to copy the arming schedule settings.

**Step 4** Click **Apply** to save the settings.

## 12.2 Configuring Alarm Linkage Actions

**Step 1** Click **Linkage Action** to set the alarm linkage actions.

Area    Arming Schedule <u>Linkage Action</u>		
<input checked="" type="checkbox"/> Normal Linkage	<input checked="" type="checkbox"/> Trigger Alarm Output	<input type="checkbox"/> Trigger Channel
<input checked="" type="checkbox"/> Full Screen Monitoring	<input checked="" type="checkbox"/> Local->1	<input type="checkbox"/> D1
<input checked="" type="checkbox"/> Audible Warning	<input checked="" type="checkbox"/> Local->2	<input checked="" type="checkbox"/> D2
<input checked="" type="checkbox"/> Notify Surveillance Center	<input checked="" type="checkbox"/> Local->3	
<input checked="" type="checkbox"/> Send Email	<input checked="" type="checkbox"/> Local->4	
	<input checked="" type="checkbox"/> 10.15.2.250:8000->1	

\*Notice: please confirm the event output in "Live View" settings menu is the same with the real event output.

Figure 12-2 Set Linkage Actions

**Step 2** Select the normal linkage actions, trigger alarm output, or trigger the recording channel.

- **Full Screen Monitoring**

When an alarm is triggered, the local monitor displays in full screen the video image from the alarming channel configured for full screen monitoring.

If alarms are triggered simultaneously in several channels, their full-screen images will be switched at an interval of 10 seconds (default dwell time). A different dwell time can be set by going to **System > Live View > Full Screen Monitoring Dwell Time**.

Auto-switch will terminate once the alarm stops and return to the Live View interface.

 **NOTE**

Select the channel(s) you want to trigger full screen monitoring in **Trigger Channel** settings.

- **Audible Warning**

It will trigger an audible *beep* when an alarm is detected.

- **Notify Surveillance Center**

It will send an exception or alarm signal to the remote alarm host when an event occurs. The alarm host refers to the PC installed with Remote Client.



The alarm signal will be transmitted automatically at detection mode when a remote alarm host is configured. Refer to Chapter 16.8 Configure Ports for alarm host configuration.

- **Send Email**

It will send an e-mail with alarm information to the user when an alarm is detected.

Refer to 16.7 Configuring E-Mail for e-mail configuration details.

**Step 3** Check the checkbox to select the alarm output when an alarm is triggered.



To trigger an alarm output when an event occurs, refer to Chapter 12.6.3 Configuring Alarm Output to set the alarm output parameters.

**Step 4** Click **Trigger Channel** and select one or more channels that will record/capture or perform full-screen monitoring when a motion alarm is triggered.



You have to set the recording schedule to realize this function. Refer to Refer to Chapter 8.4 Configuring Recording Schedule for setting the recording schedule.

**Step 5** Click **Apply** to save the settings.

## 12.3 Configuring Motion Detection Alarms

Motion Detection enables the device to detect moving objects in the monitored area and trigger alarms.

**Step 1** Go to **System > Event > Normal Event > Motion Detection**.




Figure 12-3 Set Motion Detection

**Step 2** Select the camera to configure the motion detection.

**Step 3** Check **Enable**.

**Step 4** Set the motion detection area.

- **Full screen:** Click to set full-screen motion detection for the image.
- **Customized area:** Click-and-drag the mouse on the preview screen to draw the customized motion detection area(s).

**Step 5** Click **Clear** to clear the current motion detection area settings and draw again.

**Step 6** Set sensitivity (0-100). The sensitivity allows you to calibrate how readily movement triggers the alarm. A higher value more readily triggers motion detection.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

## 12.4 Configuring Video Loss Alarms

### Purpose

Video Loss Detection detects video loss of a channel and takes alarm response action(s).

**Step 1** Go to **System > Event > Normal Event > Video Loss**.

Camera: [D1] IPCamera 01

Enable

Arming Schedule Linkage Action

	00	02	04	06	08	10	12	14	16	18	20	22	24
Mon	Blue												
Tue	Blue												
Wed	Blue												
Thu	Blue												
Fri	Blue												
Sat	Blue												
Sun	Blue												
Holiday	Blue												

Figure 12-4 Set Video Loss Detection

**Step 2** Select the camera to configure video loss detection.

**Step 3** Check **Enable**.

**Step 4** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 5** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

## 12.5 Configuring Video Tampering Alarms

### Purpose

Video Tampering Detection triggered an alarm when the camera lens is covered and takes alarm response action(s).

**Step 1** Go to **System > Event > Normal Event > Video Tampering**.

**Step 2** Select the camera to configure the video tampering detection.




Figure 12-5 Set Video Tampering Setting

**Step 3** Check **Enable**.

**Step 4** Set the video tampering area. Click-and-drag the mouse on the preview screen to draw the customized video tampering area.

**Step 5** Click **Clear** to clear the current area settings and draw again.

**Step 6** Set sensitivity level (0-2). Three levels are available. The sensitivity calibrates how readily movement triggers the alarm. A higher value more readily triggers the video tampering detection.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

## 12.6 Configuring Sensor Alarms

### Purpose

Set the handling action of an external sensor alarm.

### 12.6.1 Configuring Alarm Inputs

**Step 1** Go to **System > Event > Normal Event > Alarm Input**.

**Step 2** Select an alarm input item from the list and click .

The screenshot shows a configuration window titled "Edit" with a close button in the top right corner. It contains the following fields and options:

- Alarm Input No.:** A dropdown menu with "Local<-1" selected.
- Type:** A dropdown menu with "N.O." selected.
- Alarm Name:** A text input field containing "A".
- Settings:** Three radio buttons: "Nonuse", "Input", and "One-Key Dis..." (which is selected).
- Normal Linkage:** A section with a checked checkbox and five sub-options, each with a checked checkbox:
  - Full Screen Monitori...
  - Audible Warning
  - Notify Surveillance ...
  - Trigger Alarm Output
  - Send Email
- Buttons:** "Copy to" and "Apply" buttons at the bottom right.

Figure 12-6 Alarm Input

**Step 3** Set the alarm input type to N.C. or N.O.

**Step 4** Edit the alarm name.

**Step 5** Check the **Input** radio button.

**Step 6** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 7** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

## 12.6.2 Configuring One-Key Disarming

One-Key Disarming disarms Alarm Input 1 by one-key operation.

**Step 1** Go to **System > Event > Normal Event > Alarm Input**.

**Step 2** Select Alarm Input 1 from the list and click .

**Step 3** Set the alarm input type to N.C. or N.O.

**Step 4** Edit the alarm name.

**Step 5** Check the **Enable One-Key Disarming** radio button.

The screenshot shows a window titled "Edit" with a close button in the top right corner. It contains the following fields and options:

- Alarm Input No.:** A dropdown menu with "Local<-1" selected.
- Type:** A dropdown menu with "N.O." selected.
- Alarm Name:** A text input field containing "A".
- Settings:** Three radio buttons: "Nonuse", "Input", and "One-Key Dis..." (which is selected).
- Action List:** A list of actions, each with a checked checkbox:
  - Normal Linkage
  - Full Screen Monitori...
  - Audible Warning
  - Notify Surveillance ...
  - Trigger Alarm Output
  - Send Email
- Buttons:** "Copy to" and "Apply" buttons at the bottom right.

Figure 12-7 One-Key Alarm Disarming

**Step 6** Select the alarm linkage action(s) you want to disarm for the local Alarm Input .

 **NOTE**

When Alarm Input 1 (Local < -1) is enabled with one-key disarming, the other alarm input settings are not configurable.

**Step 7** Click **Apply** to save the settings.

### 12.6.3 Configuring Alarm Outputs

Trigger an alarm output when an alarm is triggered.

**Step 1** Go to **System > Event > Normal Event > Alarm Output**.

**Step 2** Select an alarm output item from the list and click .

**Step 3** Edit the alarm name.

**Step 4** Select the dwell time (the alarm duration) from 5s to 600s, or **Manually Clear**.

**Step 5 Manually Clear:** You should manually clear the alarm when the alarm occurs. Refer to Chapter 12.9 Triggering or Clearing Alarm Output Manually for detailed instructions.

**Step 6** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Edit**
✕

Alarm Output No.

Alarm Name

Dwell Time

Alarm Status

**Arming Schedule**

	00	02	04	06	08	10	12	14	16	18	20	22	24
Mon	[Armed]												
Tue	[Armed]												
Wed	[Armed]												
Thu	[Armed]												
Fri	[Armed]												
Sat	[Armed]												
Sun	[Armed]												
Holiday	[Armed]												

✕ Delete   🗑️ Delete All

Clear
Copy
Apply

Figure 12-8 Alarm Output

**Step 7** (Optional) Click **Copy** to copy the same settings to other alarm output(s).

## 12.7 Configuring Exceptions Alarms

Exception events can be configured to take the event hint in the Live View window and trigger alarm output and linkage actions.

**Step 1** Go to **System > Event > Normal Event > Exception**.

**Step 2** (Optional) Enable the event hint to display it in the Live View window.

- 1) Check the **Enable Event Hint** checkbox.
- 2) Click  to select the exception type(s) to take the event hint.




Figure 12-9 Event Hint Settings

**Step 3** Select the excetion type from the drop-down list to set the linkage actions.




Figure 12-10 Exceptions Handling

**Step 4** Set the normal linkage and alarm output triggering. Refer to Chapter 10.2 Setting Alarm Linkage Actions.

## 12.8 Setting Alarm Linkage Actions

### Purpose

Alarm linkage actions will be activated when an alarm or exception occurs, including Event Hint Display, Full Screen Monitoring, Audible Warning (buzzer), Notify Surveillance Center, Trigger Alarm Output, and Send Email.

### 12.8.1 Configuring Auto-Switch Full Screen Monitoring

When an alarm is triggered, the local monitor displays in full screen the video image from the alarming channel configured for full screen monitoring. And when the alarm is triggered simultaneously in several channels, you must configure the auto-switch dwell time.

**Step 1** Go to **System > View > General**.

**Step 2** Set the event output and dwell time.

- **Event Output:** Select the output to show the event video.
- **Full Screen Monitoring Dwell Time:** Set the time in seconds to show the alarm event screen. If alarms are triggered simultaneously in several channels, their full-screen images will be switched at an interval of 10 seconds (default dwell time).

**Step 3** Go to the **Linkage Action** interface of the alarm detection (e.g., motion detection, video tampering, face detection, etc.).

**Step 4** Select the **Full Screen Monitoring** alarm linkage action.

**Step 5** Select the channel(s) you want for full screen monitoring in **Trigger Channel** settings.



Auto-switch will terminate once the alarm stops and go back to the Live View interface.

### 12.8.2 Configuring Audio Warning

The audio warning has the system trigger an audible *beep* when an alarm is detected.

**Step 1** Go to **System > View > General**.

**Step 2** Enable the audio output and set the volume.

**Step 3** Go to the **Linkage Action** interface of the alarm detection (e.g., motion detection, video tampering, face detection, etc.).

**Step 4** Select the **Audio Warning** alarm linkage action.

## 12.8.3 Notifying Surveillance Center

The device can send an exception or alarm signal to the remote alarm host when an event occurs. The alarm host refers to the PC installed with client software (e.g., iVMS-4200, iVMS-5200).

**Step 1** Go to **System > Network > Advanced > More Settings**.

**Step 2** Set the alarm host IP and alarm host port.

**Step 3** Go to the **Linkage Action** interface of the alarm detection (e.g., motion detection, video tampering, face detection, etc.).

**Step 4** Select the Notify Surveillance Center.

## 12.8.4 Configuring E-Mail Linkage

The system can send an e-mail with alarm information to a user or users when an alarm is detected. Refer to Chapter 16.7 Configuring E-Mail for details of e-mail configuration.

**Step 1** Go to **System > Network > Advanced**.

**Step 2** Configure the e-mail settings.

**Step 3** Go to the **Linkage Action** interface of the alarm detection (e.g., motion detection, video tampering, face detection, etc.).

**Step 4** Select the **Send Email** alarm linkage action.

## 12.8.5 Triggering Alarm Outputs

The alarm output can be triggered by alarm input, motion detection, video tampering detection, face detection, line crossing detection, and any other event.

**Step 1** Go to the **Linkage Action** interface of the alarm input or event detection (e.g., motion detection, face detection, line crossing detection, intrusion detection, etc.).

**Step 2** Click the Trigger Alarm Output tab.

**Step 3** Select the alarm output(s) to trigger.

**Step 4** Go to **System > Event > Normal Event > Alarm Output**.

**Step 5** Select an alarm output item from the list.



Refer to Chapter 12.6.3 Configuring Alarm Output for the alarm output settings.

## 12.8.6 Configuring PTZ Linkage

The system can trigger the PTZ actions (e.g., call preset/patrol/pattern) when the alarm event or VCA detection event occurs.



Make sure the connected PTZ or speed dome supports PTZ linkage.

**Step 1** Go to the **Linkage Action** interface of the alarm input or VCA detection (e.g., face detection, line crossing detection, intrusion detection, etc.).

**Step 2** Select the **PTZ Linkage**.

**Step 3** Select the camera to perform the PTZ actions.

**Step 4** Select the preset/patrol/pattern No. to call when the alarm events occur.

Figure 12-11 PTZ Linkage



You can set only one PTZ type for the linkage action each time.

## 12.9 Triggering or Clearing Alarm Output Manually

### Purpose

Sensor alarm can be triggered or cleared manually. When **Manually Clear** is selected for the dwell time of an alarm output, the alarm can be cleared only by clicking **Clear**.

**Step 1** Go to **System > Event > Normal Event > Alarm Output**.

**Step 2** Select the alarm output you want to trigger or clear.

**Step 3** Click **Trigger/Clear** to trigger or clear an alarm output.

**Edit** ✕

Alarm Output No.  Dwell Time

Alarm Name  Alarm Status

**Arming Schedule**

	00	02	04	06	08	10	12	14	16	18	20	22	24
Mon	[Blue bar]												
Tue	[Blue bar]												
Wed	[Blue bar]												
Thu	[Blue bar]												
Fri	[Blue bar]												
Sat	[Blue bar]												
Sun	[Blue bar]												
Holiday	[Blue bar]												

Figure 12-12 Alarm Output

# Chapter 13 VCA Event Alarm

The device supports receiving VCA detections sent by connected IP cameras. Enable and configure VCA detection on the IP camera settings interface first.



VCA detections must be supported by the connected IP camera.

Refer to the network camera’s user manual for detailed VCA detection instructions.

## 13.1 Face Detection

### Purpose

The Face Detection function detects faces appearing in the surveillance scene. Linkage actions can be triggered when a human face is detected.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click Face Detection.




Figure 13-1 Face Detection

**Step 3** Select a **Camera** to configure.

**Step 4** Check Enable Face Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured pictures of face detection.

**Step 6** Drag the **Sensitivity** slider to set the detection sensitivity. Sensitivity range: [1-5]. The higher the value, the more easily the face will be detected.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.2 Vehicle Detection

### Purpose

Vehicle Detection is available for road traffic monitoring. In Vehicle Detection, a passed vehicle can be detected and the picture of its license plate can be captured. You can send an alarm signal to notify the surveillance center and upload the captured picture to an FTP server.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Vehicle**.




Figure 13-2 Vehicle Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Vehicle Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured vehicle detection pictures.

**Step 6** Set the **arming** schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 7** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 8** Configure rules, including **Area Settings, Picture, Overlay Content,** and **Blacklist and Whitelist.** Area Settings: Up to four lanes are selectable.

**Step 9** Click **Save.**



Refer to the Network Camera user manual for detailed instructions for vehicle detection.

## 13.3 Line Crossing Detection

### Purpose

Line crossing detection detects people, vehicles, and objects crossing a set virtual line. The detection direction can be set as bidirectional, from left to right or from right to left.

**Step 1** Go to **System > Event > Smart Event.**

**Step 2** Click Line Crossing.

Figure 13-3 Line Crossing Detection

**Step 3** Select a camera to configure.

**Step 4** Check the Enable Line Crossing Detection checkbox.

**Step 5** Optionally, check **Save VCA Picture** to save the captured line crossing detection pictures.

**Step 6** Follow the steps to set the line crossing detection rules and detection areas.

- 1) Select an Arming Region to configure. Up to four arming regions are selectable.

- 2) Select the Direction as A<->B, A->B, or A<-B.

**A<->B:** Only the arrow on the B side shows. An object crossing a configured line in both directions can be detected and trigger alarms.

**A->B:** Only an object crossing the configured line from the A side to the B side can be detected.

**B->A:** Only an object crossing the configured line from the B side to the A side can be detected.

- 3) Drag the Sensitivity slider to set the detection sensitivity. The higher the value, the more easily the detection alarm will be triggered.

- 4) Click Draw Region and set two points in the preview window to draw a virtual line.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.4 Intrusion Detection

### Purpose

The Intrusion Detection Function detects people, vehicles, or other objects that enter and loiter in a pre-defined virtual region. Specific actions can be taken when an alarm is triggered.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click Intrusion.




Figure 13-4 Intrusion Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Intrusion Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured intrusion detection pictures.

**Step 6** Follow these steps to set the detection rules and detection areas.

- 1) Select a Virtual Panel to configure. Up to four virtual panels are selectable.
- 2) Drag the sliders to set Time Threshold, Sensitivity, and Percentage.

**Time Threshold:** The time an object can loiter in the region. When the duration of the object in the defined detection area exceeds the threshold, the device will trigger an alarm. Its range is [1s-10s].

**Sensitivity:** The size of the object that can trigger the alarm. The higher the value, the more easily the detection alarm will be triggered. Its range is [1-100].

**Percentage:** The ratio of the in-region part of the object that can trigger the alarm. For example, if the percentage is 50%, when the object enters the region and occupies half of the whole region, the device will trigger an alarm. Its range is [1-100].

- 3) Click Draw Region and draw a quadrilateral in the preview window by specifying four vertices of the detection region.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.5 Region Entrance Detection

### Purpose

The Region Entrance Detection function detects objects that enter a pre-defined virtual region.

**Step 1** Go to **System Management > Event Settings > Smart Event**.

**Step 2** Click the **Region Entrance Detection** item.




Figure 13-5 Region Entrance Detection

**Step 3** Select a camera to configure.

**Step 4** Check the Enable Region Entrance Detection checkbox.

**Step 5** Optionally, check the **Save VCA Picture** checkbox to save the captured region entrance detection pictures.

**Step 6** Follow these steps to set the detection rules and detection areas.

- 1) Select an Arming Region to configure. Up to four regions are selectable.
- 2) Drag the sliders to set Sensitivity.

**Sensitivity:** The higher the value, the more easily the detection alarm will be triggered. Its range is [0-100].

- 3) Click **Draw Region** and draw a quadrilateral in the preview window by specifying four vertices of the detection region.

**Step 7** Configure Arming Schedule and Linkage Action.

**Step 8** Click **Apply**.

## 13.6 Region Exiting Detection

### Purpose

The Region Exiting Detection function detects objects that exit a pre-defined virtual region.

**Step 1** Go to **System > Event > Smart Event**.


**Step 2 Click Region Exiting.**

Figure 13-6 Region Exiting Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Region Exiting Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured region exiting detection pictures.

**Step 6** Follow these steps to set the detection rules and detection areas.

- 1) Select an Arming Region to configure. Up to four regions are selectable.
- 2) Drag the sliders to set Sensitivity.

**Sensitivity:** The higher the value, the more easily the detection alarm will be triggered. Its range is [0-100].

- 3) Click **Draw Region** and draw a quadrilateral in the preview window by specifying four vertices of the detection region.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.7 Unattended Baggage Detection

### Purpose

The Unattended Baggage Detection function detects objects left in a pre-defined region such as baggage, purses, dangerous materials, etc., and a series of actions can be taken when the alarm is triggered.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Unattended Baggage**.




Figure 13-7 Unattended Baggage Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Unattended Baggage Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured unattended baggage detection pictures.

**Step 6** Follow these steps to set the detection rules and detection areas.

- 1) Select an **Arming Region** to configure. Up to four regions are selectable.
- 2) Drag the sliders to set **Time Threshold** and **Sensitivity**.

**Time Threshold:** The time the objects are left in the region. If the value is 10, an alarm is triggered after the object is left in the region for 10s. Its range is [5s-20s].

**Sensitivity:** Similarity of the background image to the object. The higher the value, the more easily the detection alarm will be triggered.

- 3) Click **Draw Region** and draw a quadrilateral in the preview window by specifying four vertices of the detection region.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.8 Object Removal Detection

### Purpose

The Object Removal Detection function detects objects removed from a pre-defined region such as exhibits on display, and a series of actions can be taken when the alarm is triggered.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Object Removable**.




Figure 13-8 Object Removal Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Object Removable Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured object removable detection pictures.

**Step 6** Follow these steps to set the detection rules and detection areas.

- 1) Select an Arming Region to configure. Up to four regions are selectable.
- 2) Drag the sliders to set Time Threshold and Sensitivity.

**Time Threshold:** The time of the objects removed from the region. If the value is 10, alarm will be triggered after the object disappears from the region for 10s. Its range is [5s-20s].

**Sensitivity:** The similarity of the background image. If the sensitivity is high, a very small object taken from the region will trigger the alarm.

- 3) Click **Draw Region** and draw a quadrilateral in the preview window by specifying four vertices of the detection region.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.9 Audio Exception Detection

### Purpose

Audio exception detection detects abnormal sounds in the surveillance scene such as a sudden increase/decrease in sound intensity.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Audio Exception**.

Figure 13-9 Audio Exception Detection

**Step 3** Select a camera to configure.

**Step 4** Optionally, check **Save VCA Picture** to save the captured audio exception detection pictures.

**Step 5** Set the detection rules:

- 1) Select the **Exception Detection** tab.
- 2) Check the **Audio Loss Exception, Sudden Increase of Sound Intensity Detection,** and/or **Sudden Decrease of Sound Intensity Detection** checkbox(es).

**Audio Loss Exception:** Detects a steep sound rise in the surveillance scene. You can set the detection sensitivity and threshold for steep sound rise by configuring its **Sensitivity** and **Sound Intensity Threshold**.

- **Sensitivity:** The smaller the value, the more severe the change must be to trigger the detection. Range [1-100].
- **Sound Intensity Threshold:** It can filter the sound in the environment. The louder the environment sound, the higher the value should be. Adjust it according to the environment. Range [1-100].

**Sudden Decrease of Sound Intensity Detection:** Detects a steep sound drop in the surveillance scene. You need set the detection sensitivity [1-100].

**Step 6** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 7** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 8** Click **Apply**.

## 13.10 Sudden Scene Change Detection

### Purpose

Scene change detection detects the change of the surveillance environment affected by external factors such as intentional rotation of the camera.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Sudden Scene Change**.




Figure 13-10 Sudden Scene Change

**Step 3** Select a camera to configure.

**Step 4** Check Enable Sudden Scene Change Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured sudden scene change detection pictures.

**Step 6** Drag the **Sensitivity** slider to set the detection sensitivity. Sensitivity range: [1-100]. The higher the value, the more easily the change of scene will trigger an alarm.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.11 Defocus Detection

### Purpose

Image blur caused by lens defocus can be detected.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **Defocus**.

Figure 13-11 Defocus Detection

**Step 3** Select a camera to configure.

**Step 4** Check Enable Defocus Detection.

**Step 5** Optionally, check **Save VCA Picture** to save the captured defocus detection pictures.

**Step 6** Drag the **Sensitivity** slider to set the detection sensitivity. Sensitivity range: [1-100]. The higher the value, the more easily the defocus image will be detected.

**Step 7** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 8** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 9** Click **Apply**.

## 13.12 PIR Alarm

### Purpose

A PIR (Passive Infrared) alarm is triggered when an intruder moves within the detector vision field. The heat energy dissipated by a person or any other warm blooded creature such as dogs, cats, etc., can be detected.

**Step 1** Go to **System > Event > Smart Event**.

**Step 2** Click **PIR Alarm**.




Figure 13-12 FIR Alarm

**Step 3** Select a camera to configure.

**Step 4** Check PIR Alarm.

**Step 5** Optionally, check **Save VCA Picture** to save the captured PIR alarm pictures.

**Step 6** Set the arming schedule. Refer to Chapter 12.1 Configuring Arming Schedule.

**Step 7** Set the linkage actions. Refer to Chapter 12.2 Configuring Alarm Linkage Actions.

**Step 8** Click **Apply**.

# Chapter 14 Smart Analysis

With the configured VCA detection, the device supports smart analysis for people counting and heat map.

## 14.1 People Counting

### Purpose

Counting calculates the number of people entering or leaving a configured area and creates daily/weekly/monthly/annual reports for analysis.

**Step 1** Go to **Smart Analysis > Counting**.

**Step 2** Select the camera.

**Step 3** Set the report type to Daily Report, Weekly Report, Monthly Report, or Annual Report.

**Step 4** Set the **Date** to analyze. Then the people counting graphic will show.




Figure 14-1 People Counting Interface

**Step 5** (Optional) Click **Export** to export the report in Microsoft Excel format.

## 14.2 Heat Map

### Purpose

Heat Map is a graphical representation of data. The heat map function is used to analyze how many people visited and stayed in a specific area.



The Heat Map function must be supported by the connected IP camera and the corresponding configuration must be set.

**Step 1** Go to **Smart Analysis > Heat Map**.

**Step 2** Select a camera.

**Step 3** Set the report type as Daily Report, Weekly Report, Monthly Report, or Annual Report.

**Step 4** Set the **Data** to analyze.




Figure 14-2 Heat Map Interface

**Step 5** Click **Counting**. The results will be displayed in graphics marked in different colors.

 **NOTE**

As shown in the figure above, red color block (255, 0, 0) indicates the most trafficked area, and blue color block (0, 0, 255) indicates the less-popular area.

**Step 6** (Optional) Click **Export** to export the statistics report in Microsoft Excel format.

# Chapter 15 POS Configuration

The device can be connected to a POS machine/server and receive a transaction message to overlay on the image during Live View or playback, as well as trigger a POS event alarm.



The POS feature is supported by DS-9600/7700/7600-I (/P) Series devices only.

## 15.1 Configuring POS Settings

### 15.1.1 Configuring POS Connection

**Step 1** Go to **System > POS Settings**.

**Step 2** Click **Add** to enter the POS adding interface.

**Step 3** Select a POS device from the drop-down list.

**Step 4** Check **Enable**.



The number of POS devices supported by each device is half of its number of channels, e.g., Eight POS devices are supported by the DS-9616NI-I8 model.

Figure 15-1 POS Settings


**Step 5** Set the POS protocol to **Universal Protocol**, **EPSON**, **AVE**, or **NUCLEUS**.



When a new protocol is selected, reboot the device to activate the new settings.

- **Universal Protocol**

Click **Advanced** to expand more settings when selecting the universal protocol. You can set the start line identifier, line break tag, and end line tag for the POS overlay characters, and the case-sensitive property of the characters. You can also optionally check the filtering identifier and the XML protocol.



The image shows a dialog box titled "Universal Protocol Settings". It contains several configuration options:

- Start Line Identifier**: A text input field is empty, followed by the label "Hex" and a checked checkbox.
- Line Break**: A text input field contains "0D0A", followed by the label "Hex" and a checked checkbox.
- End Line Identifier**: A text input field is empty, followed by the label "Hex" and a checked checkbox.
- Case Sensitive**: A checked checkbox.
- Filtering Identifier**: A checked checkbox.
- Enable XML Prot...**: A checked checkbox.

At the bottom of the dialog box, there are two buttons: a blue "OK" button and a grey "Cancel" button.

Figure 15-2 Universal Protocol Settings


- **EPSON**

The fixed start and end line tag are used for EPSON protocol.

- **AVE**

The fixed start and end line tag are used for AVE protocol. Serial port and virtual serial port connection types are supported.

- 1) Click **Custom** to configure the AVE settings.
- 2) Set the rule to VSI-ADD or VNET.
- 3) Set the address bit of the POS message to send.
- 4) Click **OK** to save the settings.



The screenshot shows a dialog box titled 'AVE Settings'. It contains two input fields: 'Rule' with a dropdown menu set to 'VSI-ADD', and 'Address' with a text box containing '0'. At the bottom of the dialog, there are two buttons: a blue 'OK' button and a grey 'Cancel' button.

Figure 15-3 AVE Settings

- **NUCLEUS**

- 1) Click **Custom** to configure the NUCLEUS settings.
- 2) Enter the employee No. shift No. and the terminal No. in the field. The matching message sent from the POS device will be used as the valid POS data.


 **NOTE**

The NUCLEUS protocol must be used in the RS-232 connection communication.

**Step 6** Set the connection mode to **TCP Reception**, **UDP Reception**, **Multicast**, **RS-232**, **USB-to-RS-232**, or **Sniff**, and click **Parameters** to configure the parameters for each connection mode.

- **TCP Connection**

- 1) When using TCP connection, the port must be set from 1 to 65535, and the port for each POS machine must be unique.
- 2) Set the **Allowed Remote IP Address** of the device sending the POS message.



The image shows a dialog box titled "TCP Connection Settings". It has two input fields. The first is labeled "Port" and contains the text "10010". The second is labeled "Allowed Remote IP A..." and contains the text "192 . 0 . 0 . 64". At the bottom right of the dialog, there are two buttons: "OK" and "Cancel".

Figure 15-4 TCP Connection Settings

- **UDP Connection**

- 1) When using UDP connection, the port must be set from 1 to 65535, and the port for each POS machine must be unique.
- 2) Set the **Allowed Remote IP Address** of the device sending the POS message.

- **USB-to-RS-232 Connection**

Configure the USB-to-RS-232 convertor port parameters, including the port serial number, baud rate, data bit, stop bit, parity, and flow ctrl.

USB-to-RS-232 Settings	
Serial Port Number	1
Baud Rate	4800
Data Bit	5
Stop Bit	1
Parity	None
Flow Ctrl	None
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

Figure 15-5 USB-to-RS-232 Settings

- **RS-232 Connection**


Connect the device and the POS machine via RS-232. The RS-232 settings can be configured in **Menu > Configuration > RS-232**. The Usage must be set to Transparent Channel.

- **Multicast Connection**

When connecting the device and the POS machine via Multicast protocol, set the multicast address and port.

- **Sniff Connection**

Connect the device and the POS machine via Sniff. Configure the source address and destination address settings.



The image shows a 'Sniff Settings' dialog box with the following fields and options:

- Enable Source Port Filter:**
- Source Address:** 18 . 16 . 1 . 1
- Source Port:** 10020
- Enable Destination Address Filter:**
- Enable Destination Port Filter:**
- Destination Address:** 20 . 18 . 1 . 24
- Destination Port:** 10030
- Buttons:** OK, Cancel

Figure 15-6 Sniff Settings

## 15.1.2 Configuring POS Text Overlay

**Step 1** Go to **System > POS Settings**.

**Step 2** Click **Channel Linkage and Display** tab.

**Step 3** Select the linked channel to overlay the POS characters.

**Step 4** Set the characters overlay for the enabled POS.

- Character encoding format: currently the Latin-1 format is available
- Overlay mode of the characters to display in scrolling or page mode
- Font size and font color
- Display time (sec) of the characters. The value ranges 5-3600 sec.
- Timeout of POS event. The value ranges 5-3600 sec. When the device has not received the POS message within the defined time, the transaction ends.

**Step 5** In the **Privacy Settings**, set the POS privacy information to not display on the image, e.g., the card number, user name, etc.

**Step 6** Result: The defined privacy information will be displayed using \*\*\* on the image instead.

**Step 7** (optional) Check the checkbox to enable the **Overlay POS in Live View**. When this feature is enabled, the POS information is overlaid on the Live View image.

Channel Linkage and Display
Event Linkage



Linked Channel: [D1] IPCamera 01

Character Encod...: Latin-1(iso-8859-1)

Overlay Mode: Page

Font Size: Large Medium Small

Font Color: [Color Selection]

Display for:

Timeout:

Privacy Settings:

For example, the entered card number will be shown as \*\*\*\*\*

Overlay POS in ...

Apply

Figure 15-7 Overlay Character Settings



Drag the frame to adjust the textbox size and position on the POS settings interface preview screen.

**Step 8** Click **Apply** to activate the settings.

## 15.2 Configuring POS Alarm

### Purpose

A POS event can trigger channels to start recording, trigger full screen monitoring or an audio warning, notify the surveillance center, send e-mail, etc.

**Step 1** Go to **Storage > Recording Schedule**.

**Step 2** Set the POS event's arming schedule.

**Step 3** Go to **System > POS Settings**.

**Step 4** Click the **Event Linkage** tab on the POS adding or editing interface.

**Step 5** **Select** the normal linkage actions: full screen monitoring, audio warning, or send e-mail.

**Step 6** Select **one** or more alarm output(s) to trigger.

**Step 7** Select one or more channels to record or become full-screen monitoring when a POS alarm is triggered.

Channel Linkage and Display Event Linkage

<input checked="" type="checkbox"/> Normal Linkage	<input type="checkbox"/> Trigger Alarm Output	<input type="checkbox"/> Trigger Channel
<input checked="" type="checkbox"/> Full Screen Monitoring	<input checked="" type="checkbox"/> Local->1	<input checked="" type="checkbox"/> D1
<input checked="" type="checkbox"/> Audible Warning	<input type="checkbox"/> Local->2	<input checked="" type="checkbox"/> D2
<input checked="" type="checkbox"/> Send Email	<input checked="" type="checkbox"/> Local->3	<input type="checkbox"/> D3
	<input type="checkbox"/> Local->4	<input type="checkbox"/> D4
	<input type="checkbox"/> 10.15.2.250:8000->1	

\*Notice: please confirm the event output in "Live View" settings menu is the same with the real event output.

Figure 15-8 Set Trigger Cameras of POS

**Step 8** Click **Apply** to save the settings.

# Chapter 16 Network Settings

## 16.1 Configuring TCP/IP Settings

### Purpose

TCP/IP settings must be properly configured before the device will operate over a network.

### 16.1.1 Device with Dual Network Interface

**Step 1** Go to **System > Network > TCP/IP**.

The screenshot shows the TCP/IP configuration page with the following settings:

- TCP/IP** (selected tab), DDNS, PPPoE, NTP, NAT
- Working Mode:** Net Fault-Tolerance
- Select NIC:** bond0
- NIC Type:** 10M/100M/1000M Self-adap
- Enable DHCP:**
- Enable Obtain DNS...:**
- IPv4 Address:** 10 . 15 . 2 . 107
- Preferred DNS Server:** [Empty field]
- IPv4 Subnet Mask:** 255 . 255 . 255 . 0
- Alternate DNS Server:** [Empty field]
- IPv4 Default Gateway:** 10 . 15 . 2 . 254
- MAC Address:** a4:14:37:aa:09:a3
- MTU(Bytes):** 1500
- Main NIC:** LAN1
- Apply** button

Figure 16-1 TCP/IP Settings

**Step 2** Select Net-Fault Tolerance or Multi-Address Mode under Working Mode.

- **Net-Fault Tolerance:** The two NIC cards use the same IP address, and you can select the main NIC to LAN1 or LAN2. In this way, in case of one NIC card failure, the device will automatically enable the other standby NIC card so as to ensure normal running of the system.
- **Multi-Address Mode:** The parameters of the two NIC cards can be configured independently. You can select LAN1 or LAN2 under Select NIC for parameter settings. Select one NIC card as the default route. When the system connects with the extranet, the data will be forwarded through the default route.

**Step 3** Configure other IP settings as needed.



Check the **Enable DHCP** checkbox to obtain IP settings automatically if a DHCP server is available on the network.

Valid MTU value range is 500 to 9676.

**Step 4** Click **Apply**.

## 16.1.2 Device with a Single Network Interface

**Step 1** Go to **System > Network > TCP/IP**.

Figure 16-2 TCP/IP Settings

**Step 2** Configure network parameters as needed.



Check the **Enable DHCP** checkbox to obtain IP settings automatically if a DHCP server is available on the network.

Valid MTU value range is 500 to 9676.


**Step 3** Click **Apply**.

## 16.2 Configuring Hik-Connect

### Purpose

Hik-Connect provides the mobile phone application as well as the service platform to access and manage your connected devices with remote access to the surveillance system.

**Step 1** Go to **System > Network > Advanced > Platform Access**.



Enable

Access Type

Server Address   Custom

Enable Stream Encrypt...

Verification Code

Status Offline

Scan the QR code via the Ezviz app application to add the device.



Figure 16-3 Hik-Connect Settings

**Step 2** Check the **Enable** checkbox and a **Service Terms** window will pop up. Create your verification code, check to agree to the service terms, and click **OK**.

**Step 3** (Optional) Check the **Custom** checkbox and enter the server address as needed. The default server address is dev.hik-connect.com.

**Step 4** (Optional) Check the **Enable Stream Encryption** checkbox and a verification code will be required for remote access and Live View.

**Step 5** Click **Apply**.



After configuration, you can access and manage your devices through Hik-Connect app or [www.hik-connect.com](http://www.hik-connect.com).

For more detailed instructions of Hik-Connect, refer to help on [www.hik-connect.com](http://www.hik-connect.com).

## 16.3 Configuring DDNS

### Purpose

You can set Dynamic DNS service for network access. Different DDNS modes are available: **DynDNS**, **PeanutHull**, and **NO-IP**.

### Before You Start

You must register the DynDNS, PeanutHull, or NO-IP service with your ISP before configuring DDNS settings.

**Step 1** Go to **System > Network > TCP/IP > DDNS**.

**Step 2** Check **Enable**.

**Step 3** Select **DynDNS** under **DDNS Type**.



PeanutHull and NO-IP are also available under DDNS Type, and required information should be entered accordingly.

**Step 4** Enter **Server Address** for **DynDNS** (i.e., members.dyndns.org).

**Step 5** Under **Device Domain Name**, enter the domain name obtained from the DynDNS Website.

**Step 6** Enter the **User Name** and **Password** registered in the DynDNS Website.

TCP/IP **DDNS** PPPoE NTP NAT

Enable

DDNS Type  User Name

Server Address  Password

Device Domain Name

Status DDNS is disabled.

Figure 16-4 DDNS Settings

**Step 7** Click **Apply**.

## 16.4 Configuring PPPoE

If the device is connected to the Internet through PPPoE, you need to configure the user name and password accordingly under **System > Network > TCP/IP > PPPoE**.



Contact your Internet service provider for details about PPPoE service.

## 16.5 Configuring NTP

### Purpose

Connection to a network time protocol (NTP) server can be configured on your device to ensure the system's date and time accuracy.

**Step 1** Go to **System > Network > TCP/IP > NTP**.

TCP/IP	DDNS	PPPoE	<u>NTP</u>	NAT
Enable			<input checked="" type="checkbox"/>	
Interval (min)			<input type="text" value="180"/>	
NTP Server			<input type="text" value="au.pool.ntp.org"/>	
NTP Port			<input type="text" value="123"/>	
<input type="button" value="Apply"/>				

Figure 16-5 NTP Settings

**Step 2** Check **Enable**.

**Step 3** Configure NTP settings as need.

- **Interval (min)**: Time interval between two time synchronization with NTP server
- **NTP Server**: IP address of the NTP server
- **NTP Port**: Port of the NTP server

**Step 4** Click **Apply**.

## 16.6 Configuring SNMP


### Purpose

You can configure SNMP settings to get device status and parameter information.

### Before You Start

Download the SNMP software to receive device information via the SNMP port. By setting the trap address and port, the device is allowed to send alarm events and exception messages to the surveillance center.

**Step 1** Go to **System > Network > Advanced > SNMP**.



The image shows a web-based configuration interface for SNMP settings. At the top, there are three tabs: 'SNMP' (which is selected and underlined in orange), 'Email', and 'More Settings'. Below the tabs, there are several configuration options:

- Enable:** A checkbox that is currently unchecked.
- SNMP Version:** A dropdown menu set to 'V2'.
- SNMP Port:** A text input field containing '161'.
- Read Community:** A text input field containing 'public'.
- Write Community:** A text input field containing 'private'.
- Trap Address:** An empty text input field.
- Trap Port:** A text input field containing '162'.

At the bottom of the form is a blue button labeled 'Apply'.

Figure 16-6 SNMP Settings

**Step 2** Check the **Enable** checkbox. A message will pop up to notify about a possible security risk. Click **Yes** to continue.

**Step 3** Configure the SNMP settings as needed.

- **Trap Address:** SNMP host IP address.
- **Trap Port:** SNMP host port.

**Step 4** Click **Apply**.

## 16.7 Configuring E-Mail

### Purpose

The system can be configured to send an e-mail notification to all designated users when a specified event occurs such as when an alarm or motion event is detected, the administrator password is changed, etc.

## Before You Start

The device must be connected to a local area network (LAN) that contains an SMTP mail server. The network must also be connected to either an intranet or the Internet depending on the location of the e-mail accounts to which you want to send notifications.

**Step 1** Go to **System > Network > Advanced > Email**.

Figure 16-7 E-mail Settings

**Step 2** Configure the following e-mail settings.

- **Enable Server Authentication:** Check to enable the function if the SMTP server requires user authentication, and enter the user name and password accordingly.
- **SMTP Server:** IP address of SMTP Server or host name (e.g., smtp.263xmail.com).
- **SMTP Port:** The default TCP/IP port used for SMTP is 25.
- **Enable SSL/TLS:** Check to enable SSL/TLS if required by the SMTP server.
- **Sender:** The sender's name.
- **Sender's Address:** The sender's address.
- **Select Receivers:** Select the receiver. Up to three receivers can be configured.
- **Receiver:** The receiver's name.
- **Receiver's Address:** The e-mail address of the user to be notified.

- **Enable Attached Picture:** Check to send e-mail with attached alarm images. The interval is the time between sending two subsequent alarm images.

**Step 3** Click **Apply**.

**Step 4** (Optional) Click **Test** to send a test e-mail.

## 16.8 Configure Ports

You can configure different types of ports to enable relevant functions.

**Step 1** Go to **System > Network > Advanced > More Settings** and configure port settings as needed.

- **Alarm Host IP/Port:** With a remote alarm host configured, the device will send the alarm event or exception message to the host when an alarm is triggered. The remote alarm host must have the client management system (CMS) software installed.

The Alarm Host IP refers to the IP address of the remote PC on which the CMS software (e.g., iVMS-4200) is installed, and the Alarm Host Port (7200 by default) must be the same as the alarm monitoring port configured in the software.

- **Server Port:** Server port (8000 by default) should be configured for remote client software access, and its valid range is 2000 to 65535.
- **HTTP Port:** HTTP port (80 by default) should be configured for remote Web browser access.
- **Multicast IP:** Multicast can be configured to enable Live View for cameras that exceed the maximum number allowed through network. A multicast IP address covers Class-D IP ranging from 224.0.0.0 to 239.255.255.255 and it is recommended to use an IP address ranging from 239.252.0.0 to 239.255.255.255.

When adding a device to the CMS software, the multicast address must be the same as that of the device.

- **RTSP Port:** RTSP (Real Time Streaming Protocol) is a network control protocol designed to control streaming media servers. The port is 554 by default.

SNMP	Email	More Settings
Alarm Host IP		<input type="text"/>
Alarm Host Port		<input type="text" value="0"/>
Server Port		<input type="text" value="8000"/>
HTTP Port		<input type="text" value="80"/>
Multicast IP		<input type="text"/>
RTSP Port		<input type="text" value="554"/>

Figure 16-8 Port Settings

# Chapter 17 Hot Spare Device Backup

## Purpose

The device can form an N+1 hot spare system. The system consists of several working devices and a hot spare device; when the working device fails, the hot spare device switches into operation, thus increasing the reliability of the system. Contact your dealer for details of models that support the hot spare function.

A bidirectional connection shown in the figure below is required to be built between the hot spare device and each working device.




Figure 17-1 Building a Hot Spare System

## Before You Start

At least two devices must be online.

## 17.1 Set Hot Spare Device

### Purpose

Hot spare devices take over device tasks when working devices fail.

**Step 1** Go to **System > Hot Spare**.

**Step 2** Set the Work Mode to **Hot Spare Mode**.




Figure 17-2 Hot Spare

**Step 3** Click **Apply**.

**Step 4** Click **Yes** in the popup attention box to reboot the device.



The camera connection will be disabled when the device works in hot spare mode.

It is highly recommended to restore the the device defaults after switching the working mode of the hot spare device to normal mode to ensure normal operation afterwards.

## 17.2 Set Working Device

**Step 1** Go to **System > Hot Spare**.

**Step 2** Set the Work Mode to **Normal Mode**.

**Step 3** Check **Enable**.

**Step 4** Enter the IP address and admin password of the hot spare device.

Work Mode	Normal Mode
Enable	<input checked="" type="checkbox"/>
IPv4 address of the hot sp...	10 . 15 . 1 . 19
Password of the hot spare ...	*****
Working Status	

\*Notice: After the hot spare is enabled, you must link the working device to the hot spare devic...

Figure 17-3 Hot Spare

**Step 5** Click **Apply**.

## 17.3 Manage Hot Spare System

**Step 1** Go to **System > Hot Spare** in the hot spare device.

**Step 2** Check working devices on the device list and click **Add** to link the working device to the hot spare device.



A hot spare device can connect up to 32 working devices.




Figure 17-4 Add Working Device

Table 17-1 Working Status Description

Working Status	Description
No record	The working device works properly.
Backing up	If the working device goes offline, the hot spare device will record the video of the IP camera connected to the working device for backup The record back up functions for one working device at a time.
Synchronizing	When the working device comes back online, the lost video files will be restored by the record synchronization function. The record synchronization function can be enabled for one working device at a time.

# Chapter 18 System Maintenance

## 18.1 Storage Device Maintenance

### 18.1.1 Configuring Disk Clone

#### Purpose

Select the HDDs to clone to the eSATA HDD.

#### Before You Start

Connect an eSATA disk to the device.

**Step 1** Go to **Maintenance > HDD Operation > HDD Clone**.

Clone Source

Label	Capacity	Status	Property	Type	Free Space	Group
<input type="checkbox"/> 1	1863.02GB	Normal	RAW	Local	1858.00GB	1
<input type="checkbox"/> 2	2794.52GB	Normal	RAW	Local	2794.00GB	1
<input type="checkbox"/> 5	1863.02GB	Normal	RAW	Local	1862.00GB	1
<input type="checkbox"/> 9	2794.52GB	Normal	RAW	Local	2794.00GB	1
<input type="checkbox"/> 10	1863.02GB	Normal	RAW	Local	1862.00GB	1

Clone Destination

eSATA:  Refresh

Capacity:  Clone

Figure 18-1 HDD Clone

**Step 2** Check the HDD to clone. The capacity of the selected HDD must match the capacity of the clone destination.

**Step 3** Click **Clone**.

**Step 4** Click **Yes** on the popup message box to continue creating the clone.




Figure 18-2 Message Box

## 18.1.2 S.M.A.R.T. Detection

### Purpose

HDD detection functions such as S.M.A.R.T. and Bad Sector Detection techniques. S.M.A.R.T. (Self-Monitoring, Analysis, and Reporting Technology) are HDD monitoring systems to detect various reliability indicators in the hopes of anticipating failures.

**Step 1** Go to **Maintenance > HDD Operation > S.M.A.R.T.**

**Step 2** Select the HDD to view its S.M.A.R.T. information list.

**Step 3** Select the self-test types as Short Test, Expanded Test, or Conveyance Test.

**Step 4** Click **Self-Test** to start the S.M.A.R.T. HDD self-evaluation.

**Step 5** The related S.M.A.R.T. information is shown, and you can check the HDD status.

Continue to use this disk when self-evaluation is failed.

HDD No.

Self-Test Type

Temperature...  Self-Evaluation

Working Time...  All-Evaluation

S.M.A.R.T Infor

ID	Attribute Name	Status	Flags	Threshold	Value	Worst	Raw Value
0x1	Raw Read Error R...	OK	2f	51	200	200	8
0x3	Spin Up Time	OK	27	21	113	107	7316
0x4	Start/Stop Count	OK	32	0	98	98	2657
0x5	Reallocated Sector...	OK	33	140	200	200	0
0x7	Seek Error Rate	OK	2e	0	200	200	0
0x9	Power-on Hours C...	OK	32	0	88	88	9369
0xa	Spin Up Retry Count	OK	32	0	100	100	0
0xb	Calibration Retry C...	OK	32	0	100	100	0

Figure 18-3 S.M.A.R.T. Settings Interface



To use the HDD even when S.M.A.R.T. checking has failed, check the **Continue to use the disk when self-evaluation is failed** checkbox.

### 18.1.3 Bad Sector Detection

- Step 1** Go to **Maintenance > HDD Operation > Bad Sector Detection**.
- Step 2** Select the HDD No. you want to configure in the drop-down list.
- Step 3** Select **All Detection** or **Key Area Detection** as the detection type.
- Step 4** Click **Self-Test** to start the detection.




Figure 18-4 Bad Sector Detection

**Step 5** You can pause/resume or cancel the detection.

**Step 6** After testing has been completed, click **Error Information** to see the detailed damage information.

### 18.1.4 HDD Health Detection

#### Purpose

You can view the health status of a 4 TB to 8 TB Seagate HDD manufactured after October 1, 2017. Use this function to help troubleshoot HDD problems. Health Detection shows a more detailed HDD status than the S.M.A.R.T. function.

**Step 1** Go to **Maintenance > HDD Operation > Health Detection**.




Figure 18-5 Health Detection

**Step 2** Click an HDD to view details.

## 18.2 Search and Export Log Files

### Purpose

The device operation, alarm, exception, and information can be stored in log files, which can be viewed and exported at any time.

### 18.2.1 Searching the Log Files

**Step 1** Go to **Maintenance > Log Information**.

The screenshot displays the Log Search Interface. At the top, there is a 'Time' field with two date pickers: the first is set to '2017-08-18 00:00:00' and the second to '2017-08-18 23:59:59'. A blue 'Search' button is positioned to the right of the second date picker. Below the time field is a 'Major Type' dropdown menu currently set to 'All'. Underneath that is a 'Minor Type' section with a checked checkbox for 'Select All'. In the top right corner of the interface, there is a grey button labeled 'Export ALL'. The main area of the interface is a scrollable list of log entries, each with a checked checkbox on the left. The entries include: Alarm Input, Alarm Output, Motion Detection Started, Motion Detection Stopped, Video Tampering Detection Started, Video Tampering Detection Stopped, POS Started, POS Stopped, Line Crossing Detection Alarm Started, Line Crossing Detection Alarm Stopped, Intrusion Detection Alarm Started, Intrusion Detection Alarm Stopped, Audio Loss Exception Alarm Started, Audio Loss Exception Alarm Stopped, Sudden Change of Sound Intensity Alarm Started, Sudden Change of Sound Intensity Alarm Stopped, Face Detection (Face Capture) Alarm Started, and Face Detection (Face Capture) Alarm Stopped.

Figure 18-6 Log Search Interface

**Step 2** Set the log search conditions, including the time, major type, and minor type.

**Step 3** Click **Search** to start searching the log files.

**Step 4** The matched log files will be displayed on the list, as shown below.

Time: 2017-08-18 00:00:00 - 2017-08-18 23:59:59 Search

Major Type: All

Minor: Search Result

No.	Major Type	Time	Minor Type	Parameter	Play	Details
103	Alarm	18-08-2017 07:07:31	Motion Detection ...	N/A	▶	ⓘ
104	Alarm	18-08-2017 07:07:43	Motion Detection ...	N/A	▶	ⓘ
105	Alarm	18-08-2017 07:16:27	Motion Detection ...	N/A	▶	ⓘ
106	Alarm	18-08-2017 07:16:37	Motion Detection ...	N/A	▶	ⓘ
107	Inform...	18-08-2017 07:17:19	System Running ...	N/A	—	ⓘ
108	Inform...	18-08-2017 07:17:19	System Running ...	N/A	—	ⓘ
109	Inform...	18-08-2017 07:18:00	HDD S.M.A.R.T.	N/A	—	ⓘ
110	Inform...	18-08-2017 07:18:00	HDD S.M.A.R.T.	N/A	—	ⓘ
111	Inform...	18-08-2017 07:27:20	System Running ...	N/A	—	ⓘ

Total: 1151 P: 2/12

Export Back

Export ALL

Sudden Change of Sound Intensity Alarm Started  
 Sudden Change of Sound Intensity Alarm Stopped  
 Face Detection (Face Capture) Alarm Started  
 Face Detection (Face Capture) Alarm Stopped

Figure 18-7 Log Search Results

### NOTE

Up to 2,000 log files can be displayed each time.

#### Step 5 Related Operation:

- Click  or double-click it to view detailed information.
- Click  to view the related video file.

## 18.2.2 Exporting Log Files

### Before You Start

Connect a storage device to the NVR.

**Step 1** Search the log files. Refer to Chapter 18.2.1 Searching the Log Files.

**Step 2** Select the log files you want to export, and click **Export** or click **Export ALL** on the Log Search interface to export all the system logs to the storage device.




Figure 18-8 Export Log Files

**Step 3** On the Export interface, select the storage device from the **Device Name** drop-down list.

**Step 4** Select the format of the log files to be exported. Up to 15 formats are selectable.

**Step 5** Click **Export** to export the log files to the selected storage device.

- Click **New Folder** to create a new folder in the storage device.
- Click **Format** to format the storage device before exporting the log(s).

## 18.3 Importing/Exporting IP Camera Configuration Files

### Purpose

The IP camera information, including IP address, manage port, password of admin, etc., can be saved in Microsoft Excel format and backed up to the local device. The exported file can be edited on a PC, including adding or deleting the content and copying the setting to other devices by importing the Excel file to it.

### Before You Start

When importing a configuration file, connect the storage device that contains the configuration file to the NVR.

**Step 1** Go to **Camera > IP Camera Import/Export**.

**Step 2** Click the **IP Camera Import/Export** tab, and the detected external device contents appear.

**Step 3** Export or import the IP camera configuration files.

- Click **Export** to export the configuration files to the selected local backup device.
- To import a configuration file, select the file from the selected backup device and click **Import**.

 **NOTE**

After the importing process is completed, you must reboot the device to activate the settings.

## 18.4 Importing/Exporting Device Configuration Files

### Purpose

The device configuration files can be exported to a local device for backup; and the configuration files of one device can be imported to multiple devices if they are to be configured with the same parameters.

### Before You Start

Connect a storage device to your device. To import the configuration file, the storage device must contain the file.


**Step 1** Go to **Maintenance > Import/Export**.

Figure 18-9 Import/Export Config File

**Step 2** Export or import the device configuration files.

- Click **Export** to export configuration files to the selected local backup device.
- To import a configuration file, select the file from the selected backup device and click **Import**.



After having finished importing the configuration files, the device will reboot automatically.

## 18.5 Upgrading the System

### Purpose

The firmware on your device can be upgraded with a local backup device or remote FTP server.

### 18.5.1 Upgrading with a Local Backup Device

#### Before You Start

**Step 1** Connect your device to a local storage device that contains the firmware update file.

**Step 2** Go to **Maintenance > Upgrade**.

**Step 3** Click the **Local Upgrade** tab to enter the local upgrade interface.




Figure 18-10 Local Upgrade Interface

**Step 4** Select the firmware update file from the storage device.

**Step 5** Click **Upgrade** to start upgrading.

**Step 6** After the upgrade is complete, the device will reboot automatically to activate the new firmware.

### 18.5.2 Upgrading by FTP

#### Before You Start

Ensure the network connection of the PC (running FTP server) and the device are valid and correct. Run the FTP server on the PC and copy the firmware into the corresponding directory of your PC.

**Step 1** Go to **Maintenance > Upgrade**.

**Step 2** Click the **FTP** tab to enter the local upgrade interface.




Figure 18-11 FTP Upgrade Interface

**Step 3** Enter the **FTP Server Address** in the text field.

**Step 4** Click **Upgrade** to start upgrading.

**Step 5** After upgrading is complete, reboot the device to activate the new firmware.

## 18.6 Restore Default Settings

**Step 1** Go to **Maintenance > Default**.




Figure 18-12 Restore Defaults

**Step 2** Select the restore type from the following three options.

- **Restore Defaults:** Restore all parameters, except the network (including IP address, subnet mask, gateway, MTU, NIC working mode, default route, server port, etc.) and user account parameters, to the factory default settings.
- **Factory Defaults:** Restore all parameters to the factory default settings.
- **Restore to Inactive:** Restore the device to inactive status.



The device will reboot automatically after restoring to the default settings.

# Chapter 19 General System Settings

## 19.1 Configuring General Settings

### Purpose

You can configure the BNC output standard, VGA output resolution, and mouse pointer speed in the **System > General interface**.

**Step 1** Go to **System > General**.

Language	English	VGA/HDMI Resolution	1920*1080/60HZ(1080P)
Time Zone	(GMT+08:00) Beijing, Urumc	VGA2/HDMI2 Resolution	1920*1080/60HZ(1080P)
Date Format	DD-MM-YYYY	Mouse Pointer Speed	Slow <input type="range"/> Fast
System Date	22-08-2017	Enable DST	<input checked="" type="checkbox"/>
System Time	11:34:09	DST Mode	<input type="radio"/> Auto <input checked="" type="radio"/> Manual
Device Name	Network Video Recorder	Start Time	Apr 1st Sun 2 :00
Device No.	255	End Time	Oct last Sun 2 :00
Auto Log out	Never	DST Bias	60 Minutes
Enable Wizard	<input checked="" type="checkbox"/>		
Enable Password	<input type="checkbox"/>		

Apply

Figure 19-1 General Settings Interface

**Step 2** Configure the following settings.

- **Language:** The default language used is *English*.
- **Output Standard:** Set the output standard to NTSC or PAL, which must be the same as the video input standard.
- **Resolution:** Configure the video output resolution.
- **Device Name:** Edit the name of the device
- **Device No.:** Edit the device serial number. The Device No. can be set in the range of 1 to 255, and the default No. is 255. The number is used for the remote and keyboard control.

- **Auto Logout:** Set the timeout time for menu inactivity. E.g., when the timeout time is set to *5 minutes*, the system will exit from the current operation menu to the Live View screen after five minutes of menu inactivity.
- **Mouse Pointer Speed:** Set the speed of the mouse pointer; four levels are configurable.
- **Enable Wizard:** Enable/disable the Wizard when the device starts up.
- **Enable Password:** Enable/disable the use of the login password.

**Step 3** Click **Apply** to save the settings.

## 19.2 Configuring the Date and Time

**Step 1** Go to **System > General**.

**Step 2** Configure the date and time.

- **Time Zone:** Select the time zone.
- **Date Format:** Select the date format.
- **System Date:** Select the system date.
- **System Time:** Set the system time.

Time Zone	(GMT+08:00) Beijing, Urumc	▼
Date Format	DD-MM-YYYY	▼
System Date	22-08-2017	📅
System Time	11:34:09	🕒

Figure 19-2 Date and Time Settings

**Step 3** Click **Apply** to save the settings.

## 19.3 Configuring the DST Settings

DST (daylight saving time) refers to the period of the year when clocks are moved one period ahead. In some areas worldwide, this has the effect of creating more sunlit hours in the evening during months when the weather is the warmest.

We advance our clocks ahead a certain period (depends on the DST bias you set) at the beginning of DST, and move them back the same period when we return to standard time (ST).

**Step 1** Go to **System > General**.

**Step 2** Check the **Enable DST** checkbox.

The screenshot shows the DST Settings interface with the following configuration:

- Enable DST:**
- DST Mode:**  Auto  Manual
- Start Time:** Apr 1st Sun 2 :00
- End Time:** Oct last Sun 2 :00
- DST Bias:** 60 Minutes

Figure 19-3 DST Settings Interface

**Step 3** Set the DST mode to **Auto** or **Manual**.

- **Auto:** Automatically enable the default DST period according to the local DST rules.
- **Manual:** Manually set the start time and end time of the DST period, and the DST bias.
- **DST Bias:** Set the time (30/60/90/120 minutes) offset from the standard time.

**Example:** DST begins at 2:00 a.m. on the second Sunday of March and ends at 2:00 a.m. on the first Sunday of November, with 60 minutes ahead.

**Step 4** Click **Apply** to save the settings.

## 19.4 Managing User Accounts

### Purpose

The *Administrator* user name is *admin* and the password is set when you start the device for the first time. The *Administrator* has the permission to add and delete users and configure user parameters.

### 19.4.1 Adding a User

**Step 1** Go to **System > User**.

No	User Name	Security	Priority	User's MAC Address	Permission
1	admin	Strong Password	Admin	00:00:00:00:00:00	✔

Figure 19-4 User Management Interface

**Step 2** Click **Add** to enter the operation permission interface.

**Step 3** Input the admin password and click **OK**.

Figure 19-5 Add User

**Step 4** In the Add User interface, enter the information for a new user, including **User Name**, **Password**, **Confirm** (password), **User Level** (Operator/Guest), and **User's MAC Address**.


 **WARNING**

**Strong Password Recommended** – We highly recommend you create a strong password of your own choosing (using a minimum of eight characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. We also recommend that you reset your password regularly. Especially in high security systems, resetting the password monthly or weekly can better protect your product.

- **User Level:** Set the user level to Operator or Guest. Different user levels have different operating permission.
  - **Operator:** An *Operator* user level has of Two-Way Audio permission in Remote Configuration and all operating permissions in Camera Configuration by default.
  - **Guest:** A Guest user has no Two-Way Audio permission in Remote Configuration and only local/remote playback in the Camera Configuration by default.
- **User's MAC Address:** The MAC address of the remote PC that logs onto the device. If it is configured and enabled, it allows only the remote user with this MAC address to access the device.

**Step 5** Click **OK** to finish adding the new user account.

**Step 6** In the User Management interface, the added new user is displayed on the list.



No	User Name	Security	Priority	User's MAC Address	Permission
1	admin	Strong Password	Admin	00:00:00:00:00:00	✓
2	A01	Strong Password	Operator	00:00:00:00:00:00	✓
3	A02	Strong Password	Operator	00:00:00:00:00:00	✓

Figure 19-6 User List

## 19.4.2 Setting User Permissions

For an added user, you can assign different permissions, including local and remote operation of the device.

**Step 1** Go to **System > User**.

**Step 2** Select a user from the list, and then click  to enter the permission settings interface.




Figure 19-7 User Permission Settings Interface

**Step 3** Set the user's operating permissions for Local Configuration, Remote Configuration, and Camera Configuration.

- **Local Configuration**
  - **Local Log Search:** Searching and viewing logs and system information of device.
  - **Local Parameters Settings:** Configuring parameters, restoring factory default parameters, and importing/exporting configuration files.
  - **Local Camera Management:** Adding, deleting, and editing IP cameras.
  - **Local Advanced Operation:** Operating HDD management (initializing HDD, setting HDD property), upgrading system firmware, clearing I/O alarm output.
  - **Local Shutdown Reboot:** Shutting down or rebooting the device.
- **Remote Configuration**
  - **Remote Log Search:** Remotely viewing logs that are saved on the device.
  - **Remote Parameters Settings:** Remotely configuring parameters, restoring factory default parameters, and importing/exporting configuration files.

- **Remote Camera Management:** Remote adding, deleting, and editing IP cameras.
- **Remote Serial Port Control:** Configuring RS-232 and RS-485 port settings.
- **Remote Video Output Control:** Sending remote button control signals.
- **Two-Way Audio:** Operating the two-way radio between the remote client and the device.
- **Remote Alarm Control:** Remotely arming (notify alarm and exception message to the remote client) and controlling the alarm output.
- **Remote Advanced Operation:** Remotely operating HDD management (initializing HDD, setting HDD property), upgrading system firmware, clearing I/O alarm output.
- **Remote Shutdown/Reboot:** Remotely shutting down or rebooting the device.
- **Camera Configuration**
  - **Remote Live View:** Remotely viewing live video of the selected camera(s).
  - **Local Manual Operation:** Locally starting/stopping manual recording and alarm output of the selected camera(s).
  - **Remote Manual Operation:** Remotely starting/stopping manual recording and alarm output of the selected camera(s).
  - **Local Playback:** Locally playing back recorded files of the selected camera(s).
  - **Remote Playback:** Remotely playing back recorded files of the selected camera(s).
  - **Local PTZ Control:** Locally controlling PTZ movement of the selected camera(s).
  - **Remote PTZ Control:** Remotely controlling PTZ movement of the selected camera(s).
  - **Local Video Export:** Locally exporting recorded files of the selected camera(s).
  - **Local Live View:** View live video of the selected camera(s) locally.

**Step 4** Click **OK** to save the settings.



Only the admin user account has the permission to restore factory default parameters.

### 19.4.3 Setting Local Live View Permission for Non-Admin Users

**Step 1** Go to **System > User**.

**Step 2** Click  of the admin user.

**Step 3** Input admin password and click **OK**.

**Step 4** Select cameras that a non-admin user can view locally, and click **OK**.




Figure 19-8 Enable Live View Permissions

**Step 5** Click  of non-admin user.

**Step 6** Click the Camera Configuration tab.

**Step 7** Select Camera Permission as Local Live View.

**Step 8** Select cameras to display in Live View.

**Step 9** Click **OK**.

## 19.4.4 Editing the Admin User

You can modify the admin user account's password and unlock pattern.

**Step 1** Go to **System > User**.

**Step 2** Select the admin user from the list and click **Modify**.

The screenshot shows a dialog box titled "Edit User" with a close button (X) in the top right corner. The dialog contains the following elements:

- User Name:** admin
- Password:** A text input field containing seven asterisks (\*\*\*\*\*).
- Confirm:** A text input field containing seven asterisks (\*\*\*\*\*).
- Note:** Valid password range [8-16]. You can use ...
- Password Stre...:** A progress indicator consisting of three horizontal bars.
- User's MAC Ad...:** A text input field containing the MAC address 00 : 00 : 00 : 00 : 00 : 00.
- Unlock Pattern:** A checkbox labeled "Enable Unlock Pattern" which is checked, followed by a gear icon.
- GUID File:** A checkbox labeled "Export" which is unchecked.
- Discard C...:** A button located to the right of the password and confirm fields.
- OK:** A blue button at the bottom right of the dialog.

Figure 19-9 Edit User (Admin)

**Step 3** Edit the admin user information as desired, including a new admin password (strong password is required) and MAC address.

**Step 4** Edit the unlock pattern for the admin user account.

- 1) Check the **Enable Unlock Pattern** checkbox to enable the use of an unlock pattern when logging in to the device.
- 2) Use the mouse to draw a pattern among the nine dots on the screen, and release the mouse when the pattern is done.

 **NOTE**

Refer to Chapter 3.3 Configuring the Login Unlock Pattern for detailed instructions.




Figure 19-10 Set Admin User Unlock Pattern

- Step 5** Click the  of **Export GUID** to enter the reset password interface to export the GUID file for the admin user account.
- Step 6** When the admin password is changed, export the new GUID to the connected USB flash disk in the Import/Export interface for future password resetting.
- Step 7** Click **OK** to save the settings.
- Step 8** For an **Operator** or **Guest** user account, click  on the user management interface to edit the permissions.

### 19.4.5 Editing an Operator/Guest User

You can edit the user information, including user name, password, permission level, and MAC address. Check the **Change Password** checkbox to change the password, and input the new password in the **Password** and **Confirm** text fields. A strong password is recommended.

- Step 1** Go to **System > User**.
- Step 2** Select a user from the list and click **Modify**.

**Edit User** [Close]

User Name: A01

Password: \*\*\*\*\* Discard C...

Confirm: \*\*\*\*\*

Note: Valid password range [8-16]. You can use ...

Password Stre... [Progress Bars]

User Level: Operator

User's MAC Ad...: 00 : 00 : 00 : 00 : 00 : 00

OK

Figure 19-11 Edit User (Operator/Guest)

**Step 3** Edit the user information as desired, including the new password (strong password is required) and MAC address.

### 19.4.6 Deleting a User

The admin user account has permission to delete an operator/guest user account.

**Step 1** Go to **System > User**.

**Step 2** Select a user from the list.

**Step 3** Click **Delete** to delete the selected user account.

# Chapter 20 Appendix

## 20.1 Glossary

- **Dual Stream:** Dual stream is a technology used to record high resolution video locally while transmitting a lower resolution stream over the network. The two streams are generated by the device, with the main stream having a maximum resolution of 4CIF and the sub-stream having a maximum resolution of CIF.
- **HDD:** Acronym for Hard Disk Drive. A storage medium that stores digitally encoded data on platters with magnetic surfaces.
- **DHCP:** Dynamic Host Configuration Protocol (DHCP) is a network application protocol used by devices (DHCP clients) to obtain configuration information for operation in an Internet Protocol network.
- **HTTP:** Acronym for Hypertext Transfer Protocol. A protocol to transfer hypertext request and information between servers and browsers over a network.
- **DDNS:** Dynamic DNS is a method, protocol, or network service that provides the capability for a networked device, such as a router or computer system using the Internet Protocol Suite, to notify a domain name server to change, in real time (ad-hoc) the active DNS configuration of its configured hostnames, addresses, or other information stored in DNS.
- **PPPoE:** Stands for "Point-to-Point Protocol over Ethernet." PPPoE is a network configuration used to establish a PPP connection over Ethernet protocol.
- **Hybrid device:** A hybrid device is a combination of a DVR and device.
- **NTP:** Acronym for Network Time Protocol. A protocol designed to synchronize the clocks of computers over a network.
- **NTSC:** Acronym for National Television System Committee. NTSC is an analog television standard used in such countries as the United States and Japan. Each frame of an NTSC signal contains 525 scan lines at 60 Hz.
- **Device:** Network Video Recorder. A device can be a PC-based or embedded system used for centralized management and storage for IP cameras, IP domes, and other devices.
- **PAL:** Acronym for Phase Alternating Line. PAL is also another video standard used in broadcast televisions systems in large parts of the world. A PAL signal contains 625 scan lines at 50 Hz.
- **PTZ:** Acronym for Pan, Tilt, Zoom. PTZ cameras are motor driven systems that allow the camera to pan left and right, tilt up and down, and zoom in and out.
- **USB:** Acronym for Universal Serial Bus. USB is a plug-and-play serial bus standard to interface devices to a host computer.

## 20.2 Troubleshooting

- No image displayed on the monitor after starting up normally.

Possible Reasons:

- No VGA or HDMI connections.
- Connection cable is damaged.
- Input mode of the monitor is incorrect.

**Step 1** Verify the device is connected to the monitor via HDMI or VGA cable.

**Step 2** If not, connect the device to the monitor and reboot.

**Step 3** Verify the connection cable is good.

**Step 4** If there is still no image displayed on the monitor after rebooting, check if the connection cable is good, and change the cable and connect again.

**Step 5** Verify Input mode of the monitor is correct.

**Step 6** Check that the monitor input mode matches the output mode of the device (e.g., if the device's output mode is HDMI, then the monitor input mode must be HDMI). If not, modify the monitor's input mode.

**Step 7** Check if the fault is solved by step 1 to step 3.

**Step 8** If it is solved, finish the process.

**Step 9** If not, contact a Hikvision engineer for further process.

- There is an audible warning sound "Di-Di-Di-DiDi" after a new device starts up.

Possible Reasons:

- No HDD is installed in the device.
- The installed HDD has not been initialized.
- The installed HDD is not compatible with the device or is broken.

**Step 1** Verify at least one HDD is installed in the device.

- If not, install a compatible HDD.



Refer to the *Quick Start Guide* for the HDD installation steps.

- If you don't want to install an HDD, go to **Menu > System > Event > Normal Event > Exception**, and uncheck the "HDD Error" Audible Warning checkbox.

**Step 2** Verify the HDD is initialized.

- 1) Go to **Menu > Storage > Storage Device**.
- 2) If the HDD status is "Uninitialized," check the checkbox of the corresponding HDD and click **Init**.

**Step 3** Verify the HDD is detected and is in good condition.

- 1) Select **Menu > Storage > Storage Device**.
- 2) If the HDD is not detected or the status is "Abnormal," replace the dedicated HDD according to the requirement.

**Step 4** Check if the fault is solved by step 1 to step 3.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.

- The status of the added IP camera displays as "Disconnected" when it is connected through Private Protocol. Select **Menu > Camera > Camera > IP Camera** to get the camera status.

Possible Reasons:

- Network failure, and the device and IP camera lost connection.
- The configured parameters are incorrect when adding the IP camera.
- Insufficient bandwidth.

**Step 1** Verify the network is connected.

- 1) Connect the device and PC with the RS-232 cable.
- 2) Open the Super Terminal software, and execute the ping command. Input "ping IP" (e.g. ping 172.6.22.131).



Simultaneously press **Ctrl** and **C** to exit the ping command.

- 3) If there exists return information and the time value is small, the network is normal.

**Step 2** Verify the configuration parameters are correct.

- 1) Go to **Menu > Camera**.

- 2) Verify the parameters are the same as those of the connected IP devices, including IP address, protocol, management port, user name, and password.

**Step 3** Verify the bandwidth is enough.

- 1) Go to **Menu > Maintenance > Net Detect > Network Stat**.
- 2) Check the usage of the access bandwidth, and see if the total bandwidth has reached its limit.

**Step 4** Check if the fault is solved by step 1 to step 3.

- 3) If it is solved, finish the process.
- 4) If not, contact a Hikvision engineer for further process.

- The IP camera frequently goes online and offline and the status displays as “Disconnected.”

Possible Reasons:

- The IP camera and the device versions are not compatible.
- Unstable IP camera power supply.
- Unstable network between IP camera and device.
- Limited flow by the switch connected with IP camera and device.

**Step 1** Verify the IP camera and the device versions are compatible.

- 1) Go to **Menu > Camera**, and view the firmware version of the connected IP camera.
- 2) Go to **Menu > Maintenance > System Info > Device Info** and view the firmware version of the device.

**Step 2** Verify that the IP camera power supply is stable.

- 1) Verify the power indicator is normal.
- 2) When the IP camera is offline, try the ping command on a PC to check if the PC connects to the IP camera.

**Step 3** Verify that the network between the IP camera and device is stable.

- 1) When the IP camera is offline, connect a PC and the device with an RS-232 cable.
- 2) Open the Super Terminal and use the ping command to keep sending large data packages to the connected IP camera, and check if there is packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

**Example:** Input ping 172.6.22.131 -l 1472 -f.

**Step 4** Verify the switch is not configured for flow control.

- 1) Check the brand and model of the switch connecting the IP camera and the device, and contact the manufacturer of the switch to check if it has a flow control function. If so, turn it down.

**Step 5** Check if the fault is solved by step 1 to step 4.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.

- No monitor is connected to the device locally, and when you manage the IP camera to connect with the device by Web browser remotely, the status displays as Connected. If you then connect the device with the monitor via the VGA or HDMI interface and reboot the device, there is a black screen with the mouse cursor.
- Connect the device with the monitor before startup via the VGA or HDMI interface, and manage the IP camera to connect with the device locally or remotely, the status of IP camera displays as Connected. If you then connect the device with CVBS, there is a black screen.

Possible Reasons:

- After connecting the IP camera to the device, the image is output via the main spot interface by default.

**Step 1** Enable the output channel.

**Step 2** Go to **Menu > System > Live View > General**, and select video output interface in the drop-down list and configure the window you want to view.



**NOTE**

The view settings can only be configured by local operation of the device.

Different camera orders and window-division modes can be set for different output interfaces separately, and digits such as "D1" and "D2" stand for the channel number, and "X" means the selected window has no image output.

**Step 3** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.

- Live view becomes stuck when video is output locally.

Possible Reasons:

- Poor network between the device and IP camera, and there is packet loss during the transmission.
- The frame rate has not reached the real-time frame rate.

**Step 1** Verify that the network between the device and the IP camera is connected.

- 1) When the image is stuck, connect the RS-232 ports on a PC and the rear panel of the device with the RS-232 cable.
- 2) Open the Super Terminal, and execute the command "**ping 192.168.0.0 -l 1472 -f**" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

**Step 2** Verify the frame rate is real-time frame rate.

- 1) Go to **Menu > Camera > Encoding Parameters**, and set the Frame rate to Full Frame.

**Step 3** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
  - 2) If not, contact a Hikvision engineer for further process.
- Live view is stuck when video is output remotely via Internet Explorer or platform software.

Possible Reasons:

- Poor network between device and IP camera, and there exists packet loss during the transmission.
- Poor network between device and PC, and there exists packet loss during the transmission.
- The hardware used is not good enough, including CPU, memory, etc.

**Step 1** Verify the network between the device and the IP camera is connected.

- 1) When the image is stuck, connect the RS-232 ports on a PC and the rear panel of the device with the RS-232 cable.
- 2) Open the Super Terminal, and execute the command "**ping 192.168.0.0 -l 1472 -f**" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press **Ctrl** and **C** to exit the ping command.

**Step 2** Verify the network between the device and the PC is connected.

- 1) Open the cmd window in the Start menu, or press “windows + R” shortcut key to open it.
- 2) Use the ping command to send large packets to the device, execute the command “ping 192.168.0.0 -l 1472 -f” (the IP address may change according to the real condition), and check if there exists packet loss.

 **NOTE**

Simultaneously press **Ctrl** and **C** to exit the ping command.

**Step 3** Verify the hardware of the PC is adequate.

- 1) Simultaneously press **Ctrl**, **Alt**, and **Delete** to enter the windows task management interface, as shown in the following figure.




Figure 20-1 Windows task management interface

- 2) Select the “Performance” tab; check the status of the CPU and memory.
- 3) If the resource is not enough, end unnecessary processes.

**Step 4** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
  - 2) If not, contact a Hikvision engineer for further process.
- When using the device to get the Live View audio, there is no sound, there is too much noise, or the volume is too low.

Possible Reasons:

- Cable between the pickup and IP camera is not connected well; impedance mismatches or incompatible.
- The stream type is not set as "Video & Audio."
- The encoding standard is not supported by the device.

**Step 1** Verify the cable between the pickup and IP camera is connected well and impedance matches and is compatible.

- 1) Log in the IP camera directly, and turn the audio on. Check if the sound is normal. If not, contact the IP camera manufacturer.

**Step 2** Verify the setting parameters are correct.

- 1) Go to **Menu > Camera > Encoding Parameters**, and set the Stream Type as "Audio & Video."

**Step 3** Verify the IP camera's audio encoding standard is supported by the device.

- 1) The device supports G722.1 and G711 standards, and if the encoding parameter of the input audio is not one of the previous two standards, log in the IP camera to configure it to a supported standard.

**Step 4** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.

- The image gets stuck when the device is playing back single or multi-channel.

Possible Reasons:

- Poor network between device and IP camera, and there exists packet loss during the transmission.
- The frame rate is not the real-time frame rate.
- The device supports up to 16-channel synchronize playback at 4CIF resolution, if you want 16-channel synchronize playback at 720p resolution, frame extracting may occur, which leads to the image being slightly stuck.

**Step 5** Verify the network between the device and the IP camera is connected.

- 1) When the image is stuck, connect the RS-232 ports on a PC and the rear panel of the device with the RS-232 cable.
- 2) Open the Super Terminal, and execute the command "**ping 192.168.0.0 -l 1472 -f**" (the IP address may change according to the real condition), and check if there exists packet loss.



Simultaneously press the **Ctrl** and **C** to exit the ping command.

**Step 6** Verify the frame rate is real-time frame rate.

- 1) Select **Menu > Record > Parameters > Record**, and set the Frame Rate to "Full Frame."

**Step 7** Verify the hardware supports the playback.

- 1) Reduce the channel number of playback.
- 2) Go to **Menu > Camera > Encoding Parameters**, and set a lower bitrate and resolution.

**Step 8** Reduce the number of local playback channels.

- 1) Go to **Menu > Playback**, and uncheck unnecessary channel checkboxes.

**Step 9** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.

- No record file is found in device's local HDD, and a "No record file found" prompt is displayed.

Possible Reasons:

- The time setting of system is incorrect.
- The search condition is incorrect.
- The HDD is in error or not detected.

**Step 1** Verify the system time setting is correct.

- 1) Go to **Menu > System > General**, and verify that the "Device Time" is correct.

**Step 2** Verify the search condition is correct.

- 1) Go to the playback interface, and verify that the channel and time are correct.

**Step 3** Verify that the HDD status is normal.

- 1) Go to **Menu > Storage > Storage Device** to view the HDD status, and verify that the HDD is detected and can be read and written normally.

**Step 4** Check if the fault is solved by the above steps.

- 1) If it is solved, finish the process.
- 2) If not, contact a Hikvision engineer for further process.



First Choice for Security Professionals