

ITEM# 86285

Chocolate Cherry 46" Folding Corner TV Cart

Leick
Home
SINCE 1910

2219 S. 19th St.


Sheboygan, WI 53081

Ph: 920-451-4060

Fax: 920-451-4063

info@leickhome.com





www.leickhome.com



Hardware List

Item	Description	Qty
a	Bolt 1/4"X1-1/8"	4PCS
b	Allen wrench	1PC
c	Washer 1/4"X12mm	4PCS
d	Flat Shelf Supports	4PCS
e	Door Pull	1PC
f	Machine screw for door pull 5/32"X3/4"	2PCS
g	Rounded Shelf Supports	4PCS


Parts List

Item	Description	Qty
A	 Cabinet	1PC
B	 Top Panel	1PC
C	 Bottom Panel	1PC
D	 Middle Adjustable Shelf	1PC

Assembly Instructions


Step 1

Pull the face frame to unfold the cabinet.




Step 2

Open the door and screw-in four round shelf supports onto vertical panels, insert the bottom panel.



Step 3

Put the top panel on and fasten with 4 bolts.



Step 4

Insert the flat shelf supports onto vertical panels, put the shelf on and install the door pull.

