


# SIMPLIHOME®

## Riverside / Lawson / Cayley

---

TV Media Stand

MODEL # 3AXCRIV-05



brooklyn + max™

WyndenHall™  
HOME DECOR

# SIMPLIHOME®


## Great quality is a right.

Thank you for shopping with Simpli Home,  
America's top brand for high-value furniture.



## It's time to register your product warranty.

It's quick and easy. And you'll be happy you did.




- ✓ Activate your 1-year warranty.
- ✓ Automatic entry to win a \$500 gift certificate.
- ✓ Earn instant rewards and save.

[simpli-home.com/product-registration](https://simpli-home.com/product-registration)

# SIMPLIHOME®

## Review your product and collect rewards!


Thank you for your purchase! We hope you enjoy it. We'd love your feedback. Please share a review and get instant rewards!




*[simpli-home.com/product-review](https://simpli-home.com/product-review)*



## Share photos and get your cash back!




Send us images or share them on social and qualify for instant rewards. You may even receive store credit on your entire purchase!



*[simpli-home.com/share-images](https://simpli-home.com/share-images)*

# SIMPLIHOME®

## For fastest customer service:



1. Open your phone's camera.
2. Point your phone's camera at the QR code to scan.
3. Click on the pop up.
4. You'll be taken to our customer service page.
5. Fill the form with your order information and issue.
6. Submit form.
7. A customer service associate will contact you.

## Other ways to contact us...



### Email Us

[customerservice@simpli-home.com](mailto:customerservice@simpli-home.com)



### Visit Us

Visit our site directly at  
[www.simpli-home.com](http://www.simpli-home.com)



### Call Us

1-866-518-0120  
Monday to Friday  
9am to 5pm EST

**\*If you've purchased from a retailer and you wish to return the product, please contact the retailer directly.**

**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

## **Safety Information**

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all the parts and hardware required. Hardware package may have spare parts.

**WARNING:** This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets.

We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

**May require 2 people for ease of assembly.**

## Care & Maintenance

**This furniture is designed for indoor use.**

Damage to furniture can come from temperature changes in relative humidity (RH) in our homes. Humid air oxidizes metal which results in rusting, corrosion, tarnishing and roughness. Wood absorbs water as relative humidity rises and falls, and in doing so it swells and shrinks.

To protect against the humidity effect, the metal is powder coated. The powder coat layer protects the metal from oxidizing, corrosion, tarnishing and scratching and keeps it looking good for years to come. The wood is sealed and lacquered to protect against humidity.


**To help protect your furniture, follow these steps:**




- Use a humidifier, preferably one with an automatic control system that can sense the humidity level and adjust itself accordingly
- Dust with a soft dry cloth
- Wipe up spills promptly
- Clean with a dry cloth
- Do not use abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach, and furniture polish
- Use soft felt base coasters, placemats to help prevent scratches
- Keep furniture out of direct sunlight, which can cause cracking or roughness on the protective layer
- If it can be avoided, do not put furniture near heating vents
- Keep the furniture 3 to 4 inches away from the wall, giving heat and air space to circulate

## Warning

The maximum diagonal CRT television screen size is 25 inch to 27 inch (63.50 cm to 68.58 cm).  
For use with televisions weighing 200 lbs or less. Using larger or heavier televisions may cause instability or tip over which can lead to serious injury or even death.

The recommended maximum width of the television intended for use is 66 inch.




-  **WARNING** Do not place toys, food, etc. on the top shelves or upper drawers. Serious injury or death may occur when children climb on furniture. A remote control or items placed on the furniture may encourage a child to climb on the furniture and as a result make it top-heavy and cause it to tip over on the child.
-  **WARNING** Do not place a TV that exceeds the weight limits or size guidelines shown in the instructions specified for the furniture. Do not overload shelves or place heavy items on top shelves or drawers.  
Improper use of furniture to support TVs may result in serious injury or death.
-  **WARNING** Do not relocate audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment. Do not move furniture without shelves or drawers unloaded. Furniture can collapse or tip over and cause physical injury or death.

This TV Stand does not come with legible instructions pertaining to the risk of fire and electric shock that is associated with the use of electrical components such as operation, user-maintenance, loading, storage and as applicable electrical issues including grounding or double-insulation.

Any use of this item other than that recommended by the manufacturer in this manual may cause fire, burns, electric shock and/or serious injuries or death


**Part Description**

**A**




BOTTOM  
QTY 1

**B**



SIDE  
QTY 2

**C**



TOP  
QTY 1

**Hardware Description**

**1**



ALLEN KEY BOLT  
M8 x 20 mm  
QTY 16

**2**



ALLEN KEY  
QTY 1

**3**




LOCK WASHER  
QTY 12


**4**



WASHER  
Ø 20 mm  
QTY 12




## Step 1




1. Align one Side (B) to Bottom (A) by matching the letters (P1) to (P1).
2. Use three Allen Key Bolts (1) three Lock Washers (3) and three Washers (4) to attach the Bottom (A) to Side (B).
3. Use Allen Key (2) to tighten. Do not over tighten.

## Step 2




1. Align second Side (B) to Bottom (A) by matching the letters (P2) to (P2).
2. Use three Allen Key Bolts (1) three Lock Washers (3) and three Washers (4) to attach the Bottom (A) to Side (B).
3. Use Allen Key (2) to tighten. Do not over tighten.

## Step 3




1. Place the assembled TV stand on its side on a smooth, flat surface.
2. Slide Top (C) in side slots.

## Step 4



1. Align Top (C) to one Side (B) by matching the letters (P1) to (P1).
2. Use three Allen Key Bolts (1) three Lock Washers (3) and three Washers (4) to attach the Side (B) to Top (C).
3. Use Allen Key (2) to tighten. Do not over tighten.

## Step 5



1. Align Top (C) to the second Side (B) by matching the letters (P2) to (P2).
2. Use three Allen Key Bolts (1) three Lock Washers (3) and three Washers (4) to attach the Side (B) to Top (C).
3. Use Allen Key (2) to tighten. Do not over tighten.

**NOTE:** Levelers on the bottom of the sides can be adjusted if floor is uneven.