

TROUBLESHOOTING

Operation	Why won't my unit turn on?	Make sure it is plugged into a functional outlet.
		Make sure the oven door is closed.
		Call Consumer Service at 1-800-726-0190.
Programming	Can I change my function while cooking?	First interrupt current function by pressing Stop/Clear twice. Then reprogram the oven to desired function.
	Can I change time while cooking?	Yes. Simply turn the selector dial during cooking to change time.
	Can I change power level or temperature when the unit is already cooking?	You need to first interrupt the current cooking function by pressing Stop/Clear twice. Then reprogram the oven to your desired temperature or power level.
Microwave Cooking	Why is my food not cooked evenly, undercooked, or not fully defrosted?	If you used non-microwave safe materials, make sure to use microwave-safe cookware only.
		Food might not be fully defrosted; add additional time using the defrost function.
		You may need more time or power; make sure you adjust cooking time and power level accordingly.
		Try turning or stirring food for more even cooking.
	Food might have been positioned in the center of the turntable; try positioning food off-center for more even cooking.	
	Why is my food overcooked?	Cooking time or power level might have been incorrect; try adjusting these accordingly.
Why is there arcing or sparking?	Make sure to use microwave-safe cookware only. Do not use AirFry accessories in microwave mode.	
	Do not operate the microwave empty. Make sure food is in the microwave before operating.	
	There might have been spilled food in the cavity; make sure to clean the cavity with a wet towel.	
Oven/AirFry Cooking	Why is my food undercooked?	There may be too much food in the basket. Try smaller batches of food and single layers, rather than stacking food on top of each other. The temperature might be too low; try adjusting to a higher temperature.
	Why is my food not crispy or fried evenly?	Some foods may require more oil than others. If not crispy enough, spray, brush, or add some oil on the food.
		Make sure food is spread evenly in one single layer with no overlap. If needed, toss or flip food halfway through cycle.
		Put the food in for additional cooking time. Make sure to check periodically until food reaches desired brownness. Do not leave oven unattended.
	Why do condensation and steam come out of my unit?	With greasy foods, oil may leak into pan, producing steam. This will not affect results, but may fog up the viewing window.
		Foods with high moisture content can cause condensation. This will not affect results, but may fog up the viewing window.
The pan or basket may contain grease residue from previous use. Make sure to clean the accessories properly after each use.		
Cleaning	Are the parts dishwasher safe?	Do not put the accessories in the dishwasher; instead, hand-wash with warm, sudsy water.
	How do I clean tough residue from accessories?	To remove baked-on grease, soak the accessories in hot, sudsy water or use a nonabrasive cleanser.

QUICK REFERENCE GUIDE

Cuisinart®

3-in-1 Microwave AirFryer Plus



CONTROL PANEL

MICROWAVE COOKING
Manually program your desired time and power level.

AIRFRY PRESETS
Preprogrammed temperatures and times for your fried favorites.

MICROWAVE PRESETS
Preprogrammed settings for all your microwave necessities.

OVEN/AIRFRY COOKING
Manually program your desired temperature and time to AirFry or convection cook/bake.

MUTE ON/OFF
Convenient mute setting to turn audible alerts on/off.

SELECTOR DIAL
Turn and push to select your desired settings.

+30 SECONDS/ EXPRESS COOK
Shortcut to program your microwave to cook for 30 seconds at 10P. To add time in 30-second increments, keep pressing the button.

FUNCTIONS
| MICROWAVE | OVEN/AIRFRY | DEFROST |

COMBI COOKING | **STAGE COOKING** | **ON/OFF**

AIRFRY PRESETS
| FRIES | WINGS | SNACKS |

MICROWAVE PRESETS
| POPCORN | POTATO | VEGGIE |

| BEVERAGE | MELT/SOFTEN | REHEAT |

TIME & TEMP
- +

STOP CLEAR | **START +30SEC**

NOTE: See page 7 in the Instruction Booklet for more details on the control panel buttons and display icons.

IMPORTANT!

Do not throw away these instructions.
Read before operating your new 3-in-1 Microwave AirFryer Plus.
Keep for future reference.

These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure safe operation and optimum performance, please read the entire Instruction Booklet.

Please see next page for Operating Instructions

MICROWAVE COOKING

MANUAL COOK

To use the microwave function and manually program your cooking time and power level, follow these steps:

- Put food in a microwave-safe cooking container into oven.
NOTE: See guide for materials to use/avoid on page 9 of the Instruction Booklet. Do not use AirFry basket or pan in microwave mode.
- Select Microwave.
- Set and confirm cooking time.
- Set power level.
- Press Start.

Note: Refer to recommendations and cooking charts on pages 12–15 of the Instruction Booklet.

PRESETS

Preset Microwave functions are preprogrammed to cook many popular foods using professionally recommended power levels and cooking times.

- Press the button for the desired preset function. The display will show the first option for that function.
NOTE: Refer to the cooking guide inside the oven door for more details on the presets.
- Rotate the dial until the desired option appears on the display.
- Once you have made your selection, press the Start button to begin cooking.

NOTE: Refer to pages 12–13 of the Instruction Booklet for more details on the presets.

MICROWAVE PRESET COOKING GUIDE

FUNCTION	SUB-OPTIONS	DISPLAY	WEIGHT/AMOUNT
Popcorn	Personal Size	1.75	1.75–3 oz.
	Regular Size	3.0	
Potato	1 pc.	1	6–30 oz.
	2 pc.	2	
	3 pc.	3	
Veggie	Frozen Veggies A1	4	4–16 oz.
		8	
		16	
	Fresh Veggies A2	4	
		8	
		16	
Beverage	4 oz.	4	4–12 oz.
	8 oz.	8	
	12 oz.	12	
Melt/Soften	Butter Melt	A3	½ stick (4 tbsp.)
	Butter Soften	A4	½ stick (4 tbsp.)
	Chocolate Melt	A5	4 oz.
Reheat	Dinner Plate/Leftovers		1 plate

REFER TO THE INSTRUCTION BOOKLET FOR MORE INFORMATION

AIRFRY/CONVECTION OVEN COOKING

MANUAL COOK

To use the AirFry or convection oven functions and manually program your temperature and cooking time, follow these steps:

- Put food in a proper cooking container into the oven.
NOTE: See guide for materials to use/avoid on page 9 of the Instruction Booklet.
- Select Oven/AirFry.
- Select and confirm cooking temperature.
- Set cooking time.
- Press Start.

NOTE: Refer to recommendations and cooking charts on pages 10–11 of the Instruction Booklet.

AIRFRY PRESETS

Preset AirFry functions are preprogrammed to cook many popular foods using professionally recommended cooking temperatures and times.

- Press the button for the desired preset function.
- Confirm or adjust the displayed temperature.
- Confirm or adjust the displayed time.
- Press the Start button to begin cooking.


NOTE: Refer to the cooking guide inside the oven door and pages 10–11 of the Instruction Booklet for more details on the presets.

AIRFRY PRESET COOKING GUIDE

FUNCTION	SUB-OPTIONS	RECOMMENDED QUANTITY
Fries	Frozen Fries (F1)	1-½ lb.
	Fresh-Cut Fries (F2)	
Wings	Chicken Wings/Drumsticks	2 lb.
Snacks	Frozen Snacks	1-½ lb.

MUTE ON/OFF

MUTE ON/OFF

Press the Mute button to turn sound off. When pressed  will be displayed. Press the Mute button again to turn sound back on. See details on page 17 of the Instruction Booklet.

REFER TO THE INSTRUCTION BOOKLET FOR MORE INFORMATION

Please see next page for Troubleshooting