


10-Port Industrial USB 3.0 (5 Gbps) Hub | USB 3.2 Gen 1 to 10x USB-A | ESD & Surge Protection

Product ID: **HB30A10AME, ST1030USBM**



Component	Function
1 2-Wire Terminal Block	<ul style="list-style-type: none"> Used to connect an external DC Power Source (7~24V DC Input) to the Hub.
2 Screw Locks (x 10)	<ul style="list-style-type: none"> Used to securely lock a USB Device to the USB-A Port on the Hub. Screw Lock Dimensions: Center to center 19 mm, thread size 4 - 40.
3 Power LED	<ul style="list-style-type: none"> Green: Indicates that the Hub is receiving power.
4 USB-B Host Port	<ul style="list-style-type: none"> Used to connect a Host Computer to the Hub. Screw Lock Dimensions: Center to center 24 mm, thread size 4 - 40.
5 USB-A Ports (x 10)	<ul style="list-style-type: none"> Used to connect USB Devices (x 10) to the Hub. Used to charge connected USB-A Devices. USB-A Ports support surge and 15KV ESD (Electrostatic Discharge) Protection.

Requirements

For the latest requirements, please visit www.startech.com/HB30A10AME or www.startech.com/ST1030USBM

- Phillips Head Screwdriver
- Writing Utensil
- Level
- Mounting Screws (x 2)

Installation

Notes: It is recommended to use an external **DC Power Source** (+7 - 24V DC) connected to the **2-Wire Terminal Block** to ensure sufficient power/current is delivered to each **USB-A Port** on the **Hub**.


Powering the Hub Using the Universal Power Adapter

1. Connect the **Universal Power Adapter** to the **Terminal Block** and to a **AC Electrical Outlet**.
Note: Universal power adapter included with **HB30A10AME; ST1030USBM** does not include power adapter (**sold separately**).
2. Connect a **USB-B to USB Cable** (the end will depend on USB Port you are connecting to) to the **USB-B Host Port** and to a USB port on the **Host Computer**.
3. The **Host Computer's Operating System** should detect the **Hub** and automatically install it.
4. Connect your **USB Devices** to the **USB-A Ports** (x 10) on the **Hub**.

Powering the Hub Using the 2-Wire Terminal Block

1. Remove the **Terminal Block Connector Housing** from the **Hub's Casing**.
2. Using a small screwdriver (Phillips or Flat Head), loosen the screws on the **Terminal Block Connectors**.
3. Connect the **Power** and **Ground Wires** from your **DC Power Source** (+7 - 24V DC) to the proper **Terminal Block Connectors**, the terminals are marked on the **Hub's Casing**.

Note: Ensure the polarity of the input power is correctly matched with the **Terminal Block Pins** to ensure proper function.



Terminal Block Pins

4. Insert the **Terminal Block Housing** onto the **Hub's Casing**.

Mounting

DIN Rail Mounting

1. Align the **Din Rail Brackets** (x 2) with the **Mounting Holes** (x 4) on the back of the **Hub**.
2. Insert the **Mounting Screws** (x 4) through the **Din Rail Brackets** and into the **Hub**.
3. Using a **Phillips Head Screwdriver** tighten the **Mounting Screws**. Be careful not to over-tighten the **Mounting Screws**.
4. Clip the **Din Rail Brackets** onto a **Din Rail**, securing the **Hub** to the **Din Rail**.




Din Rail Mounting

Wall Mounting

It is recommended that you use **Wall Studs** when wall mounting the **Hub**.

Note: Wall-mounting screws are not included. Please use appropriate screws suitable for your wall type and installation.

1. Align the **Hub** on the wall in the position you want to mount the **Hub**.
2. Using a **Writing Utensil** mark off both of the **Mounting Holes**.
3. Using a **Level**, draw a line connecting the two **Mounting Holes**, making sure that the line is level.
4. Align the **Mounting Holes** on the **Hub** with the **Mounting Hole Marks**.
5. Insert the **Mounting Screws** through the **Wall Mounting Holes** and into the **Wall**.
6. Using a **Phillips Head Screwdriver** tighten the **Mounting Screws** until the **Hub** is securely fasten to the **Wall**.



StarTech.com Ltd.
45 Artisans Cres
London, Ontario
N5V 5E9
Canada

StarTech.com LLP
4490 South Hamilton
Road
Groveport, Ohio
43125
U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Rd,
Brackmills
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp