

## Storage

The kettle must be cool, clean and dry before storing in a cool, dry place. Never wrap the cord tightly around the kettle; wrap it loosely to avoid causing damage.

## Specifications

Product code: EK6559

Input: 220–240 V ~ 50–60 Hz

Output: 3000 W

Power consumption (off mode): 0 W

# User manual

Kettle






**UK ONLY**  
To register for your extended guarantee, scan the QR code or visit [guarantee.uspic.com/progress](http://guarantee.uspic.com/progress) and register your product within 30 days of purchase.  
For any further queries, visit [www.progresscookshop.com](http://www.progresscookshop.com).

Manufactured by:  
Ultimate Products UK Ltd.,  
Victoria Street, Manchester OL9 0DD. **UK.**  
Ultimate Products Europe Ltd.,  
19 Baggot Street Lower, Dublin D02 X658. **ROI.**

**MADE IN CHINA.**  
©Progress trademark. All rights reserved.  
CD190924/MD250925/V2

**progress**  
since 1931

## Description of parts



- |                           |                      |
|---------------------------|----------------------|
| 1. Kettle                 | 7. Water fill gauge  |
| 2. Power base             | 8. Lid               |
| 3. Power switch           | 9. Lid button        |
| 4. Handle                 | 10. Spout            |
| 5. Min. fill mark (0.5 L) | 11. Limescale filter |
| 6. Max. fill mark (1.7 L) |                      |

Please retain instructions for future reference.

## Dos and don'ts



Exercise caution when using the kettle, as steam will be emitted from the spout and/or lid, especially whilst refilling. Always allow the kettle to cool thoroughly before touching or opening the lid. Take care when returning the kettle to the base; the heating element will remain hot after use. Switch off the kettle and disconnect it from the mains power supply before changing or fitting the filter.



Do not open the lid whilst the kettle is boiling. Do not fill the kettle above its max. fill mark. Overfilling the kettle may cause boiling water to be ejected. Never use the kettle if it has been dropped, if there are visible signs of damage or if it is leaking. Never use the kettle if the water level is less than the min. fill mark. Do not put any liquid other than water into the kettle.

## Boil-dry sensor

The kettle is equipped with a boil-dry sensor. If the kettle is accidentally turned on whilst empty, the boil-dry sensor will activate causing the power to switch off. The kettle will then remain inactive and the power switch will not function for several minutes until the kettle is cool. Do not try to use the kettle during this time; once it has cooled down, it will resume its normal function.

## Care and maintenance

Wipe the kettle and power base with a soft, damp cloth then allow it to dry thoroughly.

Never use harsh or abrasive cleaning detergents or scourers to clean the kettle, as this could cause damage.

## Removing limescale

Limescale can develop over time and may affect the performance and lifespan of the kettle.

It is recommended to descale the kettle regularly, at least once every three months, especially if the kettle is used in a hard water area. Frequent descaling will improve the performance and lifespan of the kettle.

**STEP 1:** Fill the kettle to the max. fill mark with cold water.

**STEP 2:** Add a commercial descaling agent to the kettle, adhering to the manufacturer's instructions. It is not recommended to use vinegar to descale the kettle.

**STEP 3:** Allow the kettle to boil, switch it off and leave to soak for at least 20 minutes or for the length of time specified on the descaling product.

**STEP 4:** Empty the kettle and refill to the max. fill mark with clean water. Boil the kettle once more and pour the water away after it has cooled. The kettle should now be descaled.



**NOTE:** If the kettle switches off before it has boiled or a white deposit is noticed on the inside of the kettle, it needs to be descaled.

## Instructions for use

### Before first use

Check that the limescale filter is attached



**NOTE:** When using the kettle for the first time, a slight odour may be emitted. This is normal and will soon subside. Allow for sufficient ventilation around the kettle.



**WARNING:** The kettle is not suitable for dishwasher use.

## Removing the 'new kettle' taste

Fill the kettle to the max. fill mark and boil the water, following the instructions in the section entitled 'Using the kettle'. If any slight 'new kettle' taste or odour remains in the boiled water, discard this and refill the kettle to three-quarters full. Once boiled, add two tablespoons of bicarbonate of soda and leave to stand overnight. Discard the water then re-boil a couple of times to remove any residue.

## Using the kettle

**STEP 1:** Remove the kettle from the power base.

**STEP 2:** Press the lid button to open the lid and fill the kettle to the desired water level between the min. fill mark and the max. fill mark. Close the lid ensuring it is secure and place the kettle back onto the power base.

**STEP 3:** Plug in and switch on the kettle at the mains power supply and flip the power switch to the 'on' position until it clicks; it will illuminate to indicate that it is switched on.

**STEP 4:** Once the kettle has boiled, the power switch will automatically flip back into the off position.



**NOTE:** The boiling process can be cancelled at any time by flicking the power switch back into the off position.



**CAUTION:** Allow the kettle to cool thoroughly before touching the body or opening the lid. After boiling, pour the water slowly to prevent any splashing or spillage.



**WARNING:** Allow the kettle to rest for approx. 5–10 seconds after the switch turns off, as the water remains in a rolling boil state.

# Important safety

Please read carefully

Please retain instructions for future reference.

## SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed.
- Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities and knowledge, if they have been supervised/instructed and understand the hazards involved.
- Children shall not play with the appliance.
- Children should not perform cleaning or user maintenance, unless they are older than 8 and supervised.
- This appliance is not a toy.
- If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, cease using the product immediately to avoid potential injury.
- This appliance contains no user serviceable parts, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
- Keep the appliance and its power supply cord out of the reach of children.
- Keep the appliance out of the reach of children when it is switched on or cooling down.
- Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.
- Keep the power supply cord away from any parts of the appliance that may become hot during use.
- Keep the appliance away from other heat emitting appliances.
- Do not allow the power supply cord to hang over worktops, touch hot surfaces or become twisted.
- Do not immerse the electrical components of this appliance in water or any other liquid.
- Do not operate the appliance with wet hands or if any connections are wet.
- Do not leave the appliance unattended whilst connected to the mains power supply.
- Do not remove the appliance from the mains power supply by pulling the cord; switch it off and remove the plug by hand.
- Do not pull or carry the appliance by its power supply cord.
- Do not use the appliance for anything other than its intended use.
- Do not use any accessories other than those supplied.
- Do not use this appliance outdoors.
- Do not store the appliance in direct sunlight or in high humidity conditions.
- Do not move the appliance whilst it is in use.
- If this appliance falls or accidentally becomes immersed in water, unplug it from the wall outlet immediately. Do not reach into the water.
- Always unplug the appliance after use and allow it to cool fully before any cleaning, user maintenance or storing away.
- Always use the appliance on a stable, heat-resistant surface, at a height that is comfortable for the user.
- This appliance should not be operated by means of an external timer or separate remote control system.
- Use of an extension cord with the appliance is not recommended.
- This appliance is intended for domestic use only. It should not be used for commercial purposes.



**CAUTION:** Hot surface – do not touch hot sections or heating components of the appliance.



**WARNING:** Boiling water and steam can cause serious injury; exercise extreme caution when using this appliance.

**UK  
CA CE**

**EN | Disposal of Waste Batteries and Electrical and Electronic Equipment**



This product is labelled with this crossed out wheel bin symbol in accordance with European Directive 2012/19/EC to indicate that it must not be disposed of with your other household waste. Due to the presence of hazardous substances, mixtures or components, electrical and electronic devices that are not subject to selective sorting are potentially dangerous to the environment and human health. Please check your local city office or waste disposal service for the return and recycling of this product.

Manufactured by:  
Ultimate Products UK Ltd.,  
Victoria Street, Manchester OL9 0DD. **UK.**  
Ultimate Products Europe Ltd.,  
19 Baggot Street Lower, Dublin D02 X658. **ROI.**

**MADE IN CHINA.**

CD260324/MD000000/V1