

PERFORMANCE DATA

To View Performance Data:

- Press and hold the **▼** (Down) button for two seconds (Fig 1).
- While holding the **▼** (Down) button, press and hold the **▶** (Domestic Hot Water) (DHW) button (hold both buttons at the same time) (Fig 1).
- Use the **▲** (Up) and **▼** (Down) buttons (Fig 2) to scroll to the desired information described in Table 1. Performance Data.
- The data for the performance number automatically appears in the display (Fig 3).
- To exit performance data, repeat step 2 above.




Fig 1. "Down" and "DHW" Buttons Fig 2. "Up" and "Down" Buttons Fig 3. Data Appearing in Display

Table 1. Performance Data

#	Data	Unit	#	Data	Unit
01	Water Pressure	PSI/bar ¹	08	Venturi Cycles	x100
02	Water Flow Rate	x0.1 GPM/LPM ¹	09	Pump Cycles	x100
03	Supply Temperature	*F/°C	10	Pump Hours	x10
04	Return Temperature	*F/°C	02	Pump for Boiler	0=OFF, 1=ON
05	Freeze Protection Temperature	*F/°C	03	Pump for System (Pumps 1-3) See Table 1(B) for more information.	0=OFF, 1=ON
06	Exhaust Temperature	*F/°C	04	Pump for System (Pump 4)	0=OFF, 1=ON
07	Outgoing Temperature	*F/°C	05	Outdoor Temperature	*F/°C
08	Inlet Temperature	*F/°C	06	Additional Controllers Connected	See Table 3
09	Heat Exchanger Outlet Temperature	*F/°C	07	Fan Frequency	Hz
10	Water Flow Control Position	0=Mid, 1=Open, 2=Closed	08	Water Flow Control Position	Degrees of Opening
11	Bypass Flow Control Position	0=Mid, 1=DHW, 2=CH	09	3-Way Valve Control Cycles	x100
12	3-Way Valve Control Cycles	x100	10	Venturi Position	0=Closed, 1=Open

¹ See "Units of Measurement" section below.

Units of Measurement

- Press the "Settings" button.
- Press the **▲** (Up) or **▼** (Down) arrow to select a unit of measurement (refer to Table 2).

Units of Measurement	Temp.	Water Flow	Pressure
1: English	*F	gal/min	psi
2: Metric	*C	L/min	bar

Table 1(B). Pump for System (1-3)

System Pump	ON	OFF
Pump 1	__-1__	__-0__
Pump 2	__-1__	__-0__
Pump 3	__-1__	__-0__

Table 2. Units of Measurement

Controllers Connected	Connected	Not Connected
Controller Model	1__	__
Additional Controller (BC)	1__	__0__
Additional Controller (BSC)	__1__	__0__
Additional Controller (BSC2)	__1__	__0__

Note: BC, BSC and MC are PCB recognition position.

Fig 9. "Up" and "DHW" Buttons

Table 8. Diagnostic Codes

Code	Description
00	Too Long DHW Continuous Operation
01	Air Supply or Exhaust Blockage/Condensate Trap is Full
02	No Ignition (Unit Not Turning On)
03	Water Flow Control (Combi Only)
04	By-Pass (Combi Only)
05	3-Way Valves (Combi Only)
06	Hot Water Supply Temperature Abnormally (Combi Only)
07	PC Board
08	Solenoid Valve Circuit
09	Flame Rod
10	Freeze Issue
11	High Outgoing Temperature
12	Electrical Grounding
13	Data Transfer Error
14	Gas Valve Adjustment Limit
15	Condensate Pump (Accessory)
16	Freeze Protection Thermistor
17	Outgoing Thermistor (Combi Only)
18	Heat Exchanger Thermistor (Combi Only)
19	Inlet Thermistor (Combi Only)
20	Supply Thermistor
21	Return Thermistor
22	Exhaust Thermistor
23	Outdoor Thermistor
24	Pressure Sensor
25	High/Low Water Pressure
26	Solenoid Valve Circuit
27	Low Water Cut-Off (LWCO)
28	Capacity is Insufficient
29	Pump or Fan Even With No Demand

Table 7. Error Reset

Code	Description	Reset Method
Power Reset	Venturi Control (150), Gas Valve Adjustment Limit (180), Gas Valve Adjustment (220), High Exhaust Temperature (540), and Freeze Issue (890) can be reset by shutting down power to the boiler.	Press and hold the ▶ (Domestic Hot Water) (DHW) button for two seconds, and then the ▲ (Up) button simultaneously (Fig 9).
Interlock Reset	Venturi (170) and Solenoid Valve (520) allow only interlock reset on the surface of the thermistor.	Press and hold the ▶ (Domestic Hot Water) (DHW) button for two seconds, and then the ▲ (Up) button simultaneously (Fig 9).
Combustion Error During DHW	Error can be reset by closing faucet.	Press and hold the ▶ (Domestic Hot Water) (DHW) button for two seconds, and then the ▲ (Up) button simultaneously (Fig 9).
Other Reset	Other error can be reset by Domestic "On/Off" button or "Central Heating" (CH) button.	Press and hold the ▶ (Domestic Hot Water) (DHW) button for two seconds, and then the ▲ (Up) button simultaneously (Fig 9).

- High Exhaust Temperature**
 - Make sure boiler pump activates during operation.
 - Check the exhaust thermistor wiring for damage.
 - Clean the surface of the thermistor.
 - Measure the resistance of the exhaust thermistor.*
 - If the sensor has been replaced and the error still appears, check the return thermistor.
 - If boiler is used in a hard water area, flush the DHW plate heat exchanger.
 - Check the exhaust duct, seal, and venting for damage.
- Too Long DHW Continuous Operation**
 - Using DHW beyond maximum continuous operating time by parameter i8 setting.
 - Ensure the parameter setting is correct.
 - Check the water leakage of DHW.
- Air Supply or Exhaust Blockage/Condensate Trap is Full**
 - Fan current initial check error.
 - Ensure condensate line and trap is not blocked.
 - Ensure internal air filter is clean with no obstructions.
 - Ensure high altitude setting is set properly (See High Altitude Setting).
 - Ensure combustion air, and exhaust vents are not blocked and the approved venting materials are being used.
 - Ensure either the exhaust ring or intake cap is removed properly.
 - Ensure vent length is within limits.
 - Check fan for debris and ensure wheel turns freely.
 - Verify fan check valve is not stuck between fan casing and burner body.
- No Ignition (Unit Not Turning On)**
 - Ignition Error. Check that the gas is turned on at the boiler, gas meter, and/or propane cylinder.
 - If the unit is installed in a propane system, ensure that gas is in the tank.
 - Bleed all air from the gas lines.
 - Check the ground wire for the PCB board.
 - Ensure the flame rod wire is connected.
 - Ensure the igniter is operational.*
 - Ensure the venting is installed in accordance to this manual.
 - Check that the surface of the electrode and flame rod are clean.
 - Check gas solenoid valves for open or short circuits.*
 - Verify gas orifice installed is correct for the gas system the unit is installed in.
 - Check flame rod voltage to ground during ignition.
- Water Flow Control (Combi Only)**
 - Measure the resistance values and voltage of the water flow control.*
 - Ensure the harness and connector are not wet.
 - If the voltage from the PC Board is abnormal, replace the PC Board; otherwise, replace the water flow sensor valve.
- By-Pass (Combi Only)**
 - Measure the resistance values and voltage of the bypass servo valve.*
 - Ensure the harness and connector are not wet.
 - If the voltage from the PC Board is abnormal, replace the PC Board; otherwise, replace the bypass servo valve.
- 3-Way Valves (Combi Only)**
 - Check the CH system water quality.
 - Measure the resistance values and voltage of the 3-way valve control.*
 - Replace the 3-way valve control device.
- Hot Water Supply Temperature Abnormally (Combi Only)**
 - If the DHW water temperature is higher than the set point temperature because the boiler bypass servo fails to close.
 - Measure resistance values and voltage of the bypass flow control.*
 - Replace the bypass flow control device if needed; otherwise, check the inlet thermistor and heat exchanger thermistor wiring for damage.
 - Measure the resistance of the sensor. Replace if needed.
 - Clean the sensor of any scale buildup present.
- PC Board**
 - PC Board circuit error. Replace PC Board.
- Solenoid Valve Circuit**
 - Ensure Dip switch 5 on the PC Board is in the OFF position (default).
 - Ensure the gas control wire is not loose or damaged.
 - Ensure the heater circuit is not grounded.
 - Ensure outgoing thermistor works without error by using DHW (Combi only). Replace the PC Board.
- Flame Rod**
 - Check the flame rod and wire for damage.
 - Ensure the flame rod and wire are not wet.
 - If there is no issue with the flame rod or wiring, replace the PC Board.
- Freeze Issue**
 - The boiler checks the heat exchanger temperature at the time of operation. If the temperature is too low, an error will occur.
 - Check if there is freezing in the boiler or CH system.
- Scale Buildup in Heat Exchanger (Combi Only)**
 - Flush the DHW plate heat exchanger.
 - The LC code will reset automatically when scaling is removed.
 - If LC code remains, check the DHW thermistor, flow sensor or boiler pump.
- Maintenance Indicator**
 - This code is a placeholder in diagnostic code history indicating a service provider performed maintenance or service.
 - Enter this code after performing service by pressing the following buttons at the same time: UP, DOWN, and DHW. FFF appears on the monitor (right image).
- Service Soon (S5)**
 - Service Soon (S5) is a time-based service indicator set during installation.
 - See parameter i8 in the "Parameter Settings" section for more information.
 - To reset S5 code, press Central Heating button 5 times until S5 disappears.
- Nothing Happens When DHW Water Flow is Activated (Combi Only)**
 - Verify the minimum flow rate required to fire the boiler is seen.
 - Measure the resistance of the flow control sensor.*
 - Clean the inlet water supply filter.
 - On new installations, ensure the hot and cold water lines are not reversed.
 - Confirm the inlet water temperature is not too high.
 - Ensure the integrated boiler pump operates properly.
 - Ensure the DHW operation switch is on.
- Decreasing or Fluctuating DHW Water Flow Volume (Combi Only)**
 - Ensure the gas pressure is proper.
 - Ensure the water pressure is proper.
 - Ensure the inlet water filter for DHW is clean.
 - Ensure there is no lime scale buildup present.
 - Ensure the vent and vent settings are properly set up.
 - If a DHW recirculation system is used, DHW flow volume may vary slightly.
 - Ensure all air has been purged from the system.
- Fluctuating DHW Outgoing Temperature (Combi Only)**
 - Ensure the gas pressure is proper.
 - Ensure the water pressure is proper.
 - Ensure the DHW thermistor, flow servo, and bypass servo are in good condition.
 - Ensure the inlet filter for DHW is clean.
 - If a DHW recirculation system is used, the DHW temperature may vary slightly.
 - Ensure all air is removed from the system.
- Boiler Does Not Start Heating With a Heating Demand Present**
 - Supply temperature or return temperature inside the boiler may be too hot.
 - Ensure the pump operates properly.
 - If there is a demand immediately after using DHW, wait at least three minutes for operation.
- Cannot Turn Off ECO Mode**
 - During DHW recirculation, ECO switch will always be on (Combi only).
- Cannot Set Up Lock**
 - Lock is available only when the controller has the priority. (When connecting additional remote controller) (Combi only).
- DHW Recirculation Does Not Begin (Combi Only)**
 - Ensure DHW recirculation pump is connected to the DHW_Pump terminal.
 - Ensure parameter number i8 is ON.
 - Ensure DHW recirculation plumbing type is set properly per Parameter i2.
 - Ensure DHW recirculation with timer relay input is set properly per Parameter i3.
 - Ensure the wiring to the external timer is correct.
 - Ensure the external timer is ON, if in use.
 - The recirculation logic has an OFF interval after use.
- Simultaneous DHW and CH is Not Functional (Combi Only)**
 - Ensure parameter number i8 is ON.
 - If CH set point temperature is lower than 140°F/60°C, it is not permitted (this includes outdoor reset temperature settings).
 - Ensure the DHW inlet temperature is not too hot.
 - Ensure the heating load for DHW and CH are within limits to handle both simultaneously.
- Cannot Change the DHW Set Point Temperature (Combi Only)**
 - When DHW is being produced, the temperature setting can only be adjusted between 98°F (37°C) and 110°F (43°C).
- Supply Temperature is Different From the Setting Temperature on the Controller**
 - During outdoor sensor control, the supply temperature will vary dependent on the outdoor temperature.
 - During simultaneous operation of DHW and CH, the supply temperature for CH is based on DHW control (Combi Only).
- CH Capacity is Insufficient**
 - Ensure the parameters are properly set for the installation.
 - Ensure simultaneous operation of DHW and CH, flow volume to heating can be reduced (Combi Only).
- Pump or Fan Even With No Demand**
 - The boiler may start or operate the pump for freeze protection operation.
 - The pump may intermittently operate to prevent it from becoming stuck.

ELECTRICAL DIAGNOSTICS

Table 4. Diagnostic Points

COMPONENT	WIRE COLOR	VOLTAGE	RESISTANCE	PCB CONNECTOR	PCB PIN
Power Supply	Black-White	AC108~132V	N/A	CN200	1-3
Flame Rod	Yellow-Body	more than 0.5VAC	N/A	CN8	20
Spark Electrode	Black-Body	more than 0.5VAC	N/A	CN7	1
Combustion Fan	White-Black	11~14VDC*	N/A	CN8	2-3
	Red-Black	7~14VDC*	N/A	CN7	4-9
	White-Black	2~14VDC*	N/A	CN7	16-18
	Yellow-Black	11~14VDC*	N/A	CN7	17-18
	Red-Pink	N/A	40~60Ω	CN12	9-10
	White-Blue	N/A	40~60Ω	CN12	7-8
Water Flow Control Device	Grey-Orange	11~14VDC	N/A	CN12	5-15
	Brown-Grey	Servo Valve Fully Open or Closed: Less than 1VDC Servo Valve in a Mid Position: 4~6VDC	N/A	CN12	15-17
Venturi Control Device	Blue-Black	N/A	350~550Ω	CN11	1-9, 2-9, 3-9, 8-9, 4-9
	Red-Black	N/A	8-11, 8-12, 8-13, & 8-14	CN11	8-11, 8-12, 8-13, & 8-14
By-Pass Flow Control Device	Red-Pink	N/A	40~60Ω	CN12	13-14
	White-Blue	N/A	40~60Ω	CN12	11-12
	Brown-Grey	Servo Valve Fully Open or Closed: Less than 1VDC Servo Valve in a Mid Position: 4~6VDC	N/A	CN12	16-18
3-way Valve	Orange-Grey	11~14VDC	N/A	CN12	6-16
	Pink-Red	N/A	40~60Ω	CN12	3-4
	White-Blue	N/A	40~60Ω	CN12	1-2
Gas Solenoid Valve	Yellow-Black	11~14VDC	15~25Ω	CN8	11-12
	White-White	N/A	59°F: 11.4-14kΩ 86°F: 6.4-7.8kΩ 113°F: 3.6-4.5kΩ 149°F: 2.2-2.7kΩ 221°F: 0.6-0.8kΩ	CN7	4-6, 9 12-14 9-10 3-6 11-14
Outgoing Thermistor	White-Black	N/A	Disconnect the connector and measure at thermistor side.	CN7	5-6
Inlet Thermistor	White-White	N/A	Disconnect the connector and measure at thermistor side.	CN7	8-10
Exhaust Thermistor	White-White	N/A	Disconnect the connector and measure at thermistor side.	CN7	5-6
Heat Exchanger Thermistor	White-White	N/A	Disconnect the connector and measure at thermistor side.	CN7	8-10
Supply Thermistor	White-White	N/A	Disconnect the connector and measure at thermistor side.	CN7	5-6
Return Thermistor	White-White	N/A	Disconnect the connector and measure at thermistor side.	CN7	8-10
Freeze Protection Thermistor	Black-Black	N/A	32°F: 38k-43k 50°F: 22k-26k 68°F: 14k-17k Disconnect the connector and measure at thermistor side.	CN7	7-10

Table 4. Diagnostic Points (Continued)

COMPONENT	WIRE COLOR	VOLTAGE	RESISTANCE	PCB CONNECTOR	PCB PIN
Transformer	White-Grey	AC108~132V	N/A	CN202	1-2
	Red-Red	AC20~30V (Possible to measure at Output terminal as substitute position)	N/A	CN202	3-4
Overheat Switch	Black-Black	less than 1VDC	less than 2Ω	CN8	4-15
	Black-Red	11~14VDC	N/A	CN8	6-7
Water Flow Sensor	Yellow-Black	4~7VDC. Comment: More than 6Hz (0.26Gpmin)	N/A	CN8	7-8
	Red-Black	11~14VDC	N/A	CN8	5-9
Water Pressure Sensor	Yellow-Black	0 kPa: 655-745 mV; 200 kPa: 2,155-2,245 mV; 400 kPa: 3,655-3,745 mV	N/A	CN8	1-9
Water Level Electrode	White-White	11~14VDC	N/A	CN8	13-14
Integrated Pump	White-Black	AC108~132V	N/A	CN101	1-2
Control Panel	Black-Black	11~14VDC	N/A	CN6	1-2
Additional Controller(s)	White-White	11~14VDC	N/A	CN4	1-3

* When the unit is operating.

PC BOARD BUTTONS




Fig 4. PC Board Buttons

Table 5. PC Board Buttons

Item #	PC Board Switch #	Primary Function	Notes
1	Button 1	Parameter Setting Mode	Refer to section "12.4 Parameter Settings" in Boiler Installation and Operation Manual.
2	Button 2	Deaeration Mode	Refer to section "10. Commissioning" in Boiler Installation and Operation Manual.
3	Button 3	Data Transfer Mode/ Test Combustion Mode/Flushing Mode	This is for transferring PCB data when replacing the PCB. Refer to the instructions included in the replacement parts. Also, this is used for setting the boiler into forced combustion mode and flushing mode.

Important Safety Notes

- There are a number of (live) tests required when performing electrical diagnostics on this product. Proceed with caution at all times to avoid contact with energized components inside the boiler.
- Only trained and qualified service technicians should attempt to repair this product. Before checking for resistance readings, disconnect the power source to the unit and isolate the item from the circuit (unplug it).
- Electrical Grounding**
 - Refer to the Wiring Diagram attached to the back of the boiler front cover.
- Flame Rod**
 - Place one lead of your meter to the flame rod and the other to the ground. When the unit is attempting to ignite, you should read more than 2 VAC.
- Amp Fuses**
 - This unit has six (10) amp glass fuses located on the PC Board. Remove the fuses and check continuity through it. If you have continuity through each fuse, then it is functioning. Otherwise, the fuse is blown and must be replaced.

PARAMETER SETTINGS

- To access the parameter settings, press and hold the SW 1 button on the PC Board for five seconds (Fig 5). 00-R appears on the display (Fig 6).




Fig 5. SW 1 Button on PC Board

- Press the **▲** (Up) or **▼** (Down) arrows to select a parameter setting. Then, press the "Select" button (Fig 7).




Fig 6. "00-R" shown in display Fig 7. "Up," "Down" and "Select" Buttons

- Press the **▲** (Up) or **▼** (Down) arrows to change the selection for the setting number (such as i1-R or i1-b). Then, press the "Select" button (Fig 8).




Fig 8. "Up," "Down" and "Select" Buttons

- To exit parameter settings and enter normal operation mode, press the SW1 button on the PC Board.


For more information on parameter settings, refer to the "1-Series Plus Condensing Boiler Installation and Operation Manual."

Table 6. Parameter Settings





Parameter #	Setting Description	A (Default)	Selection	b	c	d	e	f	h
00	Outdoor Temperature Sensor: Enables or disables the outdoor temperature sensor.	In Use	Not In Use						
01	Outdoor Reset Curve: (*) This parameter shows up only when selecting Outdoor Temperature Sensor "In Use" as selecting parameter number 00. For selecting outdoor reset curve as below: Curve 1, Curve 2, Curve 3, Curve 4, Curve 5, Curve 6, and Curve 7 (Custom). Refer to Boiler Installation and Operation Manual for complete curve details.	1	2	3	4	5	6	7	
02	Boost: Available when parameter i0 is selected as "A." Boost Mode increases the CH set temperature above the outdoor reset curve target when the boiler has been running on an unusually long call for heat.	30 Minutes	60 Minutes						
03	Maximum Outdoor Temperature: Available when parameter i0 is set to "A." Sets maximum outdoor temperature the boiler will fire in CH mode and can prevent boiler from firing in warm outdoor temperatures.	No Maximum	77°F (25°C)						
04	Service Soon: S5 is a time-based service indicator set during installation.	Disabled	0.5 Year	1 Year	2 Years				
05	Pressure Indication on Controller Panel: The current pressure will cycle on the controller display. If an external pressure gauge is present, it is permissible to change the setting to "No."	Yes	No						
06	De-Rate: This parameter is to limit maximum input when it is necessary.	No	Setting 1	Setting 2					
08	Simultaneous Central Heating and Domestic Hot Water: Enables simultaneous operation between Central Heating and Domestic Hot Water.	Domestic Hot Water Priority	Simultaneous CH and DHW Permitted						
09	DHW Recirculation: Enables the DHW Recirculation function for Pump 4 connection.	Pump 4 Connection Enabled for CH Zone Pump	DHW recirculation ON (Pump 4 connection for DHW Recirculation Pump)						
10	Maximum DHW Setting Temperature: This selects the maximum DHW set point temperature. When 140°F, it is recommended to have a mixing valve to prevent scalding.								



Gas Conversion Kits			
Models	Gas Type	Kit Number	
IP060160C	NG/LPG	804000124	
IP090099C			
IP090160C			
IP090199C			
IP120199C			
IP150199C			



Part number 411 and 412 includes 4 of part number 411



ITEM	DESCRIPTION	PART NUMBER	IP150199C	IP120199C	IP090199C	IP090160C	IP090099C	IP060160C
001	Front Cover-Panel Assembly-FR	809000306	1	1	1	1	1	1
003	Wall Mount Bracket	109000594	2	2	2	2	2	2
007	Connection Reinforcement Plate	809000307	1	1	1	1	1	1
008	Rubber Bushing	CF79-4120-A	4	4	4	4	4	4
010	Residential Screw and Washer	106000645	1	1	1	1	1	1
011	Ground Screw	109000076	1	1	1	1	1	1
012	Combustion Chamber Support Plate	109000597	2	2	2	2	2	2
015	Latch	109001393	2	2	2	2	2	2
018	Plate HEX Bracket	809000166	1	1	1	1	1	1
100	Burner Assembly-Large	806000082	1	1	1	1	1	1
101	Burner Gasket-Large	109000609	1	1	1	1	1	1
102	Burner Plate Assembly-Large	806000050	1	1	1	1	1	1
103	Combustion Check Valve Assembly	108000135	1	1	1	1	1	1
105	Burner Assembly-Medium	806000083	1	1	1	1	1	1
106	Burner Gasket-Medium	109000610						
107	Burner Plate Assembly-Medium	806000052						
110	Combustion Fan Assembly	108000130	1	1	1	1	1	1
111	Fan Mounting Packing	109000396	1	1	1	1	1	1
112	O-ring	109000612	1	1	1	1	1	1
113	Hexagon Head Screw	ZQA0514UK	3	3	3	3	3	3
114	Gas Valve Assembly	806000084	1	1	1	1	1	1
115	O-ring	109000252	2	2	2	2	2	2
116	Gas Connection Pipe	806000085	1	1	1	1	1	1
117	Gas Tube Bracket	106000119	1	1	1	1	1	1
118	Inlet Gas Supply Connection	106000165	1	1	1	1	1	1
119	Inlet Gas Test Port Screw	106000138	2	2	2	2	2	2
121	Noise Filter	M108-13-4	2	2	2	2	2	2
130	Heat Exchanger Assembly-Large	106000271	1	1	1	1	1	1
131	Heat Exchanger Assembly-Medium	807000235	1	1	1	1	1	1
136	OHS Bracket	109000614	1	1	1	1	1	1
145	Condensate Trap	807000236	1	1	1	1	1	1
147	Condensate Drain tube	807000237	1	1	1	1	1	1
148	Drain Tube at Air Intake	807000238	1	1	1	1	1	1
150	Electrode/Flame Rod Assembly	805000150	1	1	1	1	1	1
151	Electrode	805000151	1	1	1	1	1	1
152	Flame Rod	805000152	1	1	1	1	1	1
153	Electrode Gasket	805000153	1	1	1	1	1	1
154	Electrode Plate	109001401	1	1	1	1	1	1
156	Electrode Sleeve	109000620	1	1	1	1	1	1
200	Exhaust Duct Assy	808000044	1	1	1	1	1	1
201	Exhaust Gasket	109001403	2	2	2	2	2	2
202	Intake Gasket	109001404	1	1	1	1	1	1
203	Air Supply Seal Ring	109001405	1	1	1	1	1	1
204	Exhaust Thermistor	105002024	1	1	1	1	1	1
205	O-ring	107000323	1	1	1	1	1	1
206	Exhaust Duct Gasket	808000051	1	1	1	1	1	1
207	Thermistor Screw	109000622	1	1	1	1	1	1
210	Rubber Cap	108000132	1	1	1	1	1	1
212	Exhaust Adapter Ring	109001407	1	1	1	1	1	1
213	Air Inlet Seal Ring - 2 Inch	109001408	1	1	1	1	1	1
214	Air Inlet Gasket	109001409	1	1	1	1	1	1
220	Duct Assembly	108000133	1	1	1	1	1	1
221	Air Inlet Filter	108000086	1	1	1	1	1	1

ITEM	DESCRIPTION	PART NUMBER	IP150199C	IP120199C	IP090199C	IP090160C	IP090099C	IP060160C
222	Air Inlet Cap	108000134	1	1	1	1	1	1
400	Water Supply Connection	807000177	1	1	1	1	1	1
401	Water Supply Filter Plug Assembly	107000646	1	1	1	1	1	1
402	Rectifier	M8D1-15	1	1	1	1	1	1
403	Water Flow Servo Assy	807000299	1	1	1	1	1	1
404	Water Connection Joint Assy	807000240	1	1	1	1	1	1
405	Bypass Pipe	807000241	1	1	1	1	1	1
406	Bypass Servo Assy	807000242	1	1	1	1	1	1
407	Cover	107000093	3	3	3	3	3	3
409	Flow Turbine Assembly	107000621	1	1	1	1	1	1
410	CH Outlet Connection	807000182	2	2	2	2	2	2
411	Plate HEX-Large	807000183	1	1	1	1	1	1
412	Plate HEX-Medium	807000184	1	1	1	1	1	1
413	Water Pressure Sensor Assembly	807000185	1	1	1	1	1	1
414	Plug Band	109000018	1	1	1	1	1	1
415	Plate HEX-CH Heating Connection	807000186	1	1	1	1	1	1
417	3-Way Valve Assembly	807000187	1	1	1	1	1	1
418	Circulation Pump Assembly	807000188	1	1	1	1	1	1
419	Pump Connection Assembly	807000221	1	1	1	1	1	1
421	Pump-Plate HEX Connection Tube	807000190	1	1	1	1	1	1
422	Pump Stand	807000191	1	1	1	1	1	1
430	Hot Water Pipe	807000192	1	1	1	1	1	1
431	Heat Exchanger Pipe Connection	807000223	1	1	1	1	1	1
432	DHW Outlet	807000194	1	1	1	1	1	1
433	Trap Drain Plug Assy	807000195	1	1	1	1	1	1
440	HEX-CH Heating Connection Pipe	807000196	1	1	1	1	1	1
441	Heat Exchanger Pipe Connection Assy-Medium	807000197	1	1	1	1	1	1
443	Secondary Heat Exchanger Inlet Fitting	807000198	1	1	1	1	1	1
444	Secondary Heat Exchanger Inlet Fitting	807000199	1	1	1	1	1	1
445	Primary-Secondary Pipe Assy-Large	807000200	1	1	1	1	1	1
446	Primary-Secondary Pipe Assy-Medium	807000201	1	1	1	1	1	1
447	Primary-Secondary Connecting Fitting	807000202	1	1	1	1	1	1
450	Pipe Bracket	U211-322X01	1	1	1	1	1	1
451	Pipe Bracket	809000168	2	2	2	2	2	2
452	Retention Clip	809000169	2	2	2	2	2	2
453	Pipe Bracket	809000170	1	1	1	1	1	1
454	Clip	809000171	2	2	2	2	2	2
460	Thermistor Sensor	805000154	1	1	1	1	1	1
461	Thermistor Sensor	805000155	1	1	1	1	1	1
462	Thermistor Sensor	105002020	1	1	1	1	1	1
463	Thermistor Sensor	105002025	1	1	1	1	1	1
464	TWIN Thermistor	105002026	1	1	1	1	1	1
470	O-ring	807000215	3	3	3	3	3	3
471	O-ring	807000203	3	3	3	3	3	3
472	O-ring	807000204	14	14	14	14	14	14
473	O-ring	807000205	2	2	2	2	2	2
474	O-ring	M108-2-4	2	2	2	2	2	2
476	O-ring	M108-2-14	2	2	2	2	2	2
477	O-ring	M108-2-16	3	3	3	3	3	3
478	O-ring	M108-2-18	1	1	1	1	1	1
479	O-ring	807000206	2	2	2	2	2	2
480	O-ring	807000207	1	1	1	1	1	1
500	Clip	109000636	2	2	2	2	2	2
501	Clip	809000172	4	4	4	4	4	4

ITEM	DESCRIPTION	PART NUMBER	IP150199C	IP120199C	IP090199C	IP090160C	IP090099C	IP060160C
502	Clip	809000173	2	2	2	2	2	2
504	Clip	809000174	1	1	1	1	1	1
505	Clip	109000639	2	2	2	2	2	2
506	Clip	109000638	6	6	6	6	6	6
700	PC Board - Combi Large	805000156	1	1	1	1	1	1
701	PC Board - Combi Middle	805000157	1	1	1	1	1	1
703	PCB Cover	809000309	1	1	1	1	1	1
705	Power Transformer	805000158	1	1	1	1	1	1
707	Controller Unit	805000159	1	1	1	1	1	1
708	Controller Unit Harness	105002042	1	1	1	1	1	1
710	Power Cord	805000160	1	1	1	1	1	1
711	Sensor Harness-1	805000161	1	1	1	1	1	1
714	Heater/Ground Harness	805000162	1	1	1	1	1	1
715	Pump Harness	805000163	1	1	1	1	1	1
716	Over Heat Switch	805000164	1	1	1	1	1	1
717	Water Pressure Connection Harness	805000090	1	1	1	1	1	1
718	Thermistor Sensor	109000648	2	2	2	2	2	2
719	Igniter Ground Harness	U217-449	7	7	7	7	7	7
720	Igniter Seal	109000176	1	1	1	1	1	1
730	Igniter Assembly (Module)	805000183	1	1	1	1	1	1
731	Igniter Plate	805000184	1	1	1	1	1	1
800	Screw	109000746	4	4	4	4	4	4
801	Screw	CP-30583	4	4	4	4	4	4
802	Screw	ZBA0408UK	3	3	3	3	3	3
803	Screw	CP-30580	3	3	3	3	3	3
804	Screw	109000648	2	2	2	2	2	2
807	Screw	U217-449	7	7	7	7	7	7
808	Screw	109001417	5	5	5	5	5	5
809	Screw	CP-80452	1	1	1	1	1	1
810	Screw	109000179	3	3	3	3	3	3
811	Screw	109001416	3	3	3	3	3	3
812	Screw	109000649	4	4	4	4	4	4
816	Screw	CP-20883-410UK	1	1	1	1	1	1
818	Screw	209000203	2	2	2	2	2	2
819	Thermistor Screw	109001300	2	2	2	2	2	2
820	Screw	109000598	14	14	14	14	14	14
821	Truss Screw	ZFA0406UK	2	2	2	2	2	2
822	Screw	809000178	4	4	4	4	4	4
823	Screw	ZA04048UK	2	2	2	2	2	2
824	Screw	809000179	1	1	1	1	1	1
825	Ground Screw	109000793	4	4	4	4	4	4
828	Screw	809000182	10	10	10	10	10	10
829	Screw	809000310	2	2	2	2	2	2
840	Cable Clip	109001297	1	1	1	1	1	1
841	Cable Clip	809000311	1	1	1	1	1	1
842	Cable Clip	CP-90124-3	2	2	2	2	2	2
860	Wall Bracket	109000628	1	1	1	1	1	1
861	Vent Screen Set	108000104	1	1	1	1	1	1
863								