

## PERFORMANCE DATA

### To View Performance Data:

- Press and hold the **▼** (Down) button for two seconds (Fig 1).
- While holding the **▼** (Down) button, press and hold the "Domestic Hot Water" (DHW) button (hold both buttons at the same time) (Fig 1).
- Use the **▲** (Up) and **▼** (Down) buttons (Fig 2) to scroll to the desired information described in Table 1(A), Performance Data.
- The data for the performance number automatically appears in the display (Fig 3).
- To exit performance data, repeat step 2 above.




Fig 1. "Down" and "DHW" Buttons




Fig 2. "Up" and "Down" Buttons




Fig 3. Data Appearing in Display

Table 1(A), Performance Data

#	Data	Unit
00	Water Pressure	PSI/bar*
01	Supply Temperature	°F/°C
02	Return Temperature	°F/°C
03	Freeze Protection Temperature	°F/°C
04	Exhaust Temperature	°F/°C
05	Fan Frequency	Hz
06	Venturi Position	0=Closed, 1=Open
07	Venturi Cycles	x100
08	Pump Cycles	x100
09	Pump Hours	x10
10	Pump for Boiler	0=OFF, 1=ON
11	Pump for System (Pumps 1-3)	0=OFF, 1=ON
12	See Table 1(B) to right for more information.	

#	Data	Unit
13	Pump for System (Pump 4)	0=OFF, 1=ON
14	Indirect Tank Thermistor Temperature	°F/°C
15	Outdoor Temperature	°F/°C
16	Secondary System Temperature	°F/°C
17	Energyization Hours	x100
18	Combustion Hours	x10
19	Combustion Cycles	x100
20	Commissioning Cycles	x1

\* See "Units of Measurement" section to right.

Table 1(B), Pump for System (1-3)

System Pump	Pump for System (1-3)	
	ON	OFF
Pump 1	___1	___0
Pump 2	__1_	_0_0
Pump 3	_1__	_0__

### Units of Measurement

- Press the "Settings" button.
- Press the **▲** (Up) or **▼** (Down) arrows to select a unit of measurement (refer to Table 2).

Table 2, Units of Measurement

Units of Measurement	Temp.	Water Flow	Pressure
1: English	°F	gal/min	psi
2: Metric	°C	L/min	bar

## DIAGNOSTIC CODES

### To Display Diagnostic Codes:

- Press and hold the "DHW" button for two seconds and then the **▲** (Up) button simultaneously (Fig 9).
- The last nine maintenance codes display and flash one after the other.
- To exit diagnostic codes and return the boiler to normal operation, press and hold the "DHW" button for two seconds, and then the **▲** (Up) button simultaneously.




Fig 9. "Up" and "DHW" Buttons

Table 6, Error Reset

Table 7, Diagnostic Codes

Code	Description
100	<b>Air Supply or Exhaust Blockage/Condensate Trap is Full</b> <ul style="list-style-type: none"> <li>Fan current initial check error.</li> <li>Ensure condensate line and trap is not blocked.</li> <li>Ensure internal air filter is clean with no obstructions.</li> <li>Ensure high altitude setting is set properly (See High Altitude Setting).</li> <li>Ensure combustion air and exhaust vents are not blocked and the approved venting materials are being used.</li> <li>Ensure either the exhaust ring or intake cap is removed properly.</li> <li>Ensure vent length is within limits.</li> <li>Check fan for debris and ensure wheel turns freely.</li> <li>Verify fan check valve is not stuck between fan casing and burner body.</li> </ul>
101	<b>No Ignition (Unit Not Turning On)</b> <ul style="list-style-type: none"> <li>Ignition Error.</li> <li>Check that the gas is turned on at the boiler, gas meter, and/or propane cylinder.</li> <li>If the unit is installed in a propane system, ensure that gas is in the tank.</li> <li>Bleed all air from the gas lines.</li> <li>Check the ground wire for the PC Board.</li> <li>Ensure the flame rod wire is connected.</li> <li>Ensure the igniter is operational.*</li> <li>Ensure the venting is installed in accordance to this manual.</li> <li>Check that the surface of the electrode and flame rod are clean.</li> <li>Check gas solenoid valves for open or short circuits.*</li> <li>Verify gas orifice installed is correct for the gas system the unit is installed in.</li> <li>Check flame rod voltage to ground during ignition.</li> </ul>

Code	Description
540	<b>High Exhaust Temperature</b> <ul style="list-style-type: none"> <li>Make sure boiler pump activates during operation.</li> <li>Check the exhaust thermostat wiring for damage.</li> <li>Clean the surface of the thermistor.</li> <li>Measure the resistance of the exhaust thermistor.*</li> <li>If the sensor has been replaced and the error still appears, check the return thermistor.</li> <li>If boiler is used in a hard water area, flush the DHW plate heat exchanger.</li> <li>Check the exhaust duct, seal, and venting for damage.</li> </ul>
60	<b>Combustion Fan</b> <ul style="list-style-type: none"> <li>Check the motor wire harness for loose or damaged connections.</li> <li>Measure resistance and voltage of motor wire harness.*</li> <li>Ensure the combustion fan spins freely.</li> </ul>

Code	Description
102	<b>Flame Failure</b> <ul style="list-style-type: none"> <li>Boiler has flame failure.</li> <li>If the unit is installed in a propane system, ensure that gas is in the tank.</li> <li>Ensure the venting is installed in accordance to this manual.</li> <li>Ensure the flame rod wire is connected.</li> <li>Ensure the gas type and inlet gas pressure are correct.</li> <li>Bleed all air from the gas lines.</li> <li>Check the ground wire to the PC Board.</li> <li>Check flame rod voltage to ground during ignition.</li> </ul>
103	<b>Heat Exchanger Overheat</b> <ul style="list-style-type: none"> <li>Overheat switch is tripped.</li> <li>Measure the resistance of the Overheat Switch.*</li> <li>Check the heat exchanger surface for hot spots which may indicate blockage due to scale buildup.</li> <li>Ensure the boiler pump is not locked up.</li> <li>Ensure that all of the valves in the CH circuit are open.</li> <li>Ensure the boiler and CH circuit does not have a freezing condition.</li> <li>The surface of the heat exchanger may turn to a black color as stainless steel is tempered even in normal conditions. This does not indicate an abnormal condition.</li> <li>Check for damage on the exhaust, seal, and venting.</li> </ul>

Code	Description
700	<b>PC Board</b> <ul style="list-style-type: none"> <li>PC Board circuit error.</li> <li>Replace PC Board.</li> </ul>
701	<b>Solenoid Valve Circuit</b> <ul style="list-style-type: none"> <li>Ensure Dip switch 5 on the PC Board is in the OFF position (default).</li> <li>Ensure the gas control wire is not loose or damaged.</li> <li>Ensure the heater circuit is not grounded.</li> <li>Replace the PC Board.</li> </ul>

Code	Description
104	<b>Flame Rod</b> <ul style="list-style-type: none"> <li>Check the flame rod and wire for damage.</li> <li>Ensure the flame rod and wire are not wet.</li> <li>If there is no issue with the flame rod or wiring, replace the PC Board.</li> </ul>
105	<b>0-10V Input</b> <ul style="list-style-type: none"> <li>0-10V input overrange detection.</li> <li>Check the external controller settings.</li> </ul>

Code	Description
801	<b>Indirect Tank Temperature</b> <ul style="list-style-type: none"> <li>Indirect tank runs for more than twelve hours without cycling off.</li> <li>Check if the tank size is adequate.</li> <li>Check the thermistor location.</li> <li>Confirm that primary-secondary piping is utilized (such as low loss header, closely spaced tees, etc.)</li> <li>Check if the supply temperature for the tank is higher than the tank setting temperature (see parameter 30 in "Parameter Setting" section).</li> <li>Check sensor wiring for damage.</li> <li>Measure resistance of sensor.*</li> <li>If something is wrong on the sensor, replace the sensor.</li> </ul>
802	<b>Freeze Issue</b> <ul style="list-style-type: none"> <li>The boiler checks the heat exchanger temperature at the time of operation. If the temperature is too low, an error will occur.</li> <li>Check if there is freezing in the boiler or CH system.</li> </ul>

Code	Description
106	<b>Venturi Control</b> <ul style="list-style-type: none"> <li>Venturi operation error.</li> <li>Ensure the venturi motor is operating correctly.*</li> <li>Replace the gas valve assembly.</li> </ul>
107	<b>Venturi Blockage</b> <ul style="list-style-type: none"> <li>Check the venturi and silencer for blockage.</li> <li>Before resetting this error, check if the condensate drain is block and if the venting is connected properly.</li> </ul>

Code	Description
803	<b>Maintenance Indicator</b> <ul style="list-style-type: none"> <li>This code is a placeholder in diagnostic code history indicating a service provider performed maintenance or service.</li> <li>Enter this code after performing service by pressing the following buttons at the same time: UP, DOWN, and DHW. FFF appears on the monitor (right image).</li> </ul>

Code	Description
108	<b>Electrical Grounding</b> <ul style="list-style-type: none"> <li>Secondary circuit ground fault.</li> <li>Check all electrical components for electrical short.</li> </ul>
109	<b>Condensate Pump (Accessory)</b> <ul style="list-style-type: none"> <li>Boiler will operate for 60 seconds.</li> <li>Confirm wire connections and harnesses are good.</li> <li>Ensure the condensate reservoir is empty and condensate pump is operational.</li> </ul>

Code	Description
804	<b>Boiler Does Not Start Heating With a Heating Demand Present</b> <ul style="list-style-type: none"> <li>Supply temperature or return temperature inside the boiler may be too hot.</li> <li>Ensure the pump operates properly.</li> <li>If there is a demand immediately after using DHW, wait at least three minutes for operation.</li> </ul>
805	<b>Boiler does not start heating the indirect tank although the indirect tank is calling for heat.</b> <ul style="list-style-type: none"> <li>After the tank priority time (Parameter 34) passes, the boiler will be in heating priority for 60 minutes.</li> </ul>

Code	Description
110	<b>Supply Thermistor</b> <ul style="list-style-type: none"> <li>Check sensor wiring for damage.</li> <li>Clean the surface of the sensor.</li> <li>Measure the resistance of the sensor.</li> <li>Check the return thermistor.</li> <li>Replace if necessary.</li> </ul>
111	<b>Return Thermistor</b> <ul style="list-style-type: none"> <li>Check sensor wiring for damage.</li> <li>Measure the resistance of the sensor.</li> <li>Replace if necessary.</li> </ul>

Code	Description
806	<b>CH Capacity is Insufficient</b> <ul style="list-style-type: none"> <li>Ensure the parameters are properly set for the installation.</li> </ul>
807	<b>Fan Even With No Demand</b> <ul style="list-style-type: none"> <li>The boiler may start or operate the pump for freeze protection operation.</li> <li>The pump may intermittently operate to prevent it from becoming stuck.</li> </ul>

Code	Description
112	<b>Freeze Protection Thermistor</b> <ul style="list-style-type: none"> <li>Check sensor wiring for damage.</li> <li>Measure the resistance of the sensor.</li> <li>Replace if necessary.</li> </ul>
113	<b>Supply Thermistor</b> <ul style="list-style-type: none"> <li>Check sensor wiring for damage.</li> <li>Clean the surface of the sensor.</li> <li>Measure the resistance of the sensor.</li> <li>Check the return thermistor.</li> <li>Replace if necessary.</li> </ul>

Code	Description
808	<b>Service Soon (S5)</b> <ul style="list-style-type: none"> <li>Service Soon (S5) is a time-based service indicator set during installation.</li> <li>See parameter 01 in the "Parameter Settings" section for more information.</li> <li>After the S5 code, press the Central Heating (CH) button 5 times until S5 disappears.</li> </ul>

Code	Description
114	<b>External Pump Running at Freeze Protection Operation</b> : Selects the mode of external pump running when freeze protection operation. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat to the system for keeping system piping from freezing. But it could reduce the temperature inside heat exchanger.
115	<b>Freeze Protection Level</b> : This selects the freeze protection level. Selecting "b" will prevent the boiler from operating in freeze protection mode more than believed necessary.

Code	Description
809	<b>Altitude Setting</b> : Sets the elevation of the boiler installation.

Code	Description
116	<b>The Differential Temperature From Extinguishing Fire to Fire Again</b> : How much temperature drop is permitted by the supply water thermistor before the boiler will fire again. When selecting "Quick", the boiler will fire more frequently and achieve more temperature control.
117	<b>The Time Which Not Allow to Fire Again for CH</b> : For selecting time which not allow to fire again for CH after shutdown burner. This is setting for whether preventing from frequently operating unit or allowing frequent operation for quick heating up again.

Code	Description
810	<b>Model</b> : Manufacture Use Only
811	<b>Thermostat Usage</b> : Changes the mode between Thermostat Usage and Central Heating Button.

Code	Description
118	<b>Heating Eco Mode On Time</b> : This setting changes the on time of the heating Eco mode. This mode enables greater energy savings by reducing the length of time the boiler is operating. The output temperature of the boiler is slower in this mode.
119	<b>Air Handler Connection</b> : The setting changes to enable to AH output with linking pump 3.
120	<b>Air Handler Post Pump Extension Setting</b> : Extending the post Pump timing of pump 3.

Code	Description
812	<b>Cascade Units in Standby</b> : Sets which unit in the cascade is the primary unit..
813	<b>Gas Type</b> : For selecting gas type when conducting gas conversion.
814	<b>Vent Material Used</b> : This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.

Code	Description
121	<b>0-10V Input Setting</b> : Extending the post Pump timing of pump 3.
122	<b>N/A: Manufacture Use Only</b>
123	<b>Thermostat Usage</b> : Changes the mode between Thermostat Usage and Central Heating Button.
124	<b>System Thermistor Control</b> : Enables system temperature control using the system thermistor on the secondary loop of a cascade system.

Code	Description
815	<b>Cascade</b> : Setting Primary or Secondary unit assignment.
816	<b>Cascade Units in Standby</b> : Sets which unit in the cascade is the primary unit..
817	<b>Gas Type</b> : For selecting gas type when conducting gas conversion.
818	<b>Model</b> : Manufacture Use Only
819	<b>Vent Material Used</b> : This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.
820	<b>Altitude Setting</b> : Sets the elevation of the boiler installation.

Code	Description
125	<b>Linked Operation Among Each CH Pumps</b> : This parameter enables linked operation among each CH pumps. For example, when parameter b is selected and T/T 1 is active, both pump 1 and 2 are ON. The T/T wire must be connected to the T/T1 connection. Note: Selection d is not available when using an indirect tank.
126	<b>Linked Operation Between Main Boiler Pump and CH Pump 1</b> : This enables the linked operation between the main boiler pump and CH pump 1. Example: when the main pump is on, pump 1 is also on.
127	<b>Main Pump Runs When the Target Temperature is Reached</b> : This selects the mode of the main pump running when the target setpoint is achieved. This setting is for whether running on intervals to reduce pump operation or continuously running to reduce wait time to re-fire. Intervals are 10 minutes ON and 30 minutes OFF.
128	<b>External Pump Runs When the Temperature is Reached</b> : For selecting the mode of external pump running when the temperature is reached to stop. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat in heat exchanger.
129	<b>External Pump Running at Freeze Protection Operation</b> : Selects the mode of external pump running when freeze protection operation. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat to the system for keeping system piping from freezing. But it could reduce the temperature inside heat exchanger.
130	<b>Freeze Protection Level</b> : This selects the freeze protection level. Selecting "b" will prevent the boiler from operating in freeze protection mode more than believed necessary.
131	<b>The Differential Temperature From Extinguishing Fire to Fire Again</b> : How much temperature drop is permitted by the supply water thermistor before the boiler will fire again. When selecting "Quick", the boiler will fire more frequently and achieve more temperature control.
132	<b>The Time Which Not Allow to Fire Again for CH</b> : For selecting time which not allow to fire again for CH after shutdown burner. This is setting for whether preventing from frequently operating unit or allowing frequent operation for quick heating up again.
133	<b>Heating Eco Mode On Time</b> : This setting changes the on time of the heating Eco mode. This mode enables greater energy savings by reducing the length of time the boiler is operating. The output temperature of the boiler is slower in this mode.
134	<b>Air Handler Connection</b> : The setting changes to enable to AH output with linking pump 3.
135	<b>Air Handler Post Pump Extension Setting</b> : Extending the post Pump timing of pump 3.

Code	Description
821	<b>0-10V Input Setting</b> : Extending the post Pump timing of pump 3.
822	<b>N/A: Manufacture Use Only</b>
823	<b>Thermostat Usage</b> : Changes the mode between Thermostat Usage and Central Heating Button.
824	<b>System Thermistor Control</b> : Enables system temperature control using the system thermistor on the secondary loop of a cascade system.
825	<b>Cascade</b> : Setting Primary or Secondary unit assignment.
826	<b>Cascade Units in Standby</b> : Sets which unit in the cascade is the primary unit..
827	<b>Gas Type</b> : For selecting gas type when conducting gas conversion.
828	<b>Model</b> : Manufacture Use Only
829	<b>Vent Material Used</b> : This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.
830	<b>Altitude Setting</b> : Sets the elevation of the boiler installation.

Code	Description
136	<b>Linked Operation Among Each CH Pumps</b> : This parameter enables linked operation among each CH pumps. For example, when parameter b is selected and T/T 1 is active, both pump 1 and 2 are ON. The T/T wire must be connected to the T/T1 connection. Note: Selection d is not available when using an indirect tank.
137	<b>Linked Operation Between Main Boiler Pump and CH Pump 1</b> : This enables the linked operation between the main boiler pump and CH pump 1. Example: when the main pump is on, pump 1 is also on.
138	<b>Main Pump Runs When the Target Temperature is Reached</b> : This selects the mode of the main pump running when the target setpoint is achieved. This setting is for whether running on intervals to reduce pump operation or continuously running to reduce wait time to re-fire. Intervals are 10 minutes ON and 30 minutes OFF.
139	<b>External Pump Runs When the Temperature is Reached</b> : For selecting the mode of external pump running when the temperature is reached to stop. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat in heat exchanger.
140	<b>External Pump Running at Freeze Protection Operation</b> : Selects the mode of external pump running when freeze protection operation. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat to the system for keeping system piping from freezing. But it could reduce the temperature inside heat exchanger.
141	<b>Freeze Protection Level</b> : This selects the freeze protection level. Selecting "b" will prevent the boiler from operating in freeze protection mode more than believed necessary.
142	<b>The Differential Temperature From Extinguishing Fire to Fire Again</b> : How much temperature drop is permitted by the supply water thermistor before the boiler will fire again. When selecting "Quick", the boiler will fire more frequently and achieve more temperature control.
143	<b>The Time Which Not Allow to Fire Again for CH</b> : For selecting time which not allow to fire again for CH after shutdown burner. This is setting for whether preventing from frequently operating unit or allowing frequent operation for quick heating up again.
144	<b>Heating Eco Mode On Time</b> : This setting changes the on time of the heating Eco mode. This mode enables greater energy savings by reducing the length of time the boiler is operating. The output temperature of the boiler is slower in this mode.
145	<b>Air Handler Connection</b> : The setting changes to enable to AH output with linking pump 3.
146	<b>Air Handler Post Pump Extension Setting</b> : Extending the post Pump timing of pump 3.


Code	Description
831	<b>0-10V Input Setting</b> : Extending the post Pump timing of pump 3.
832	<b>N/A: Manufacture Use Only</b>
833	<b>Thermostat Usage</b> : Changes the mode between Thermostat Usage and Central Heating Button.
834	<b>System Thermistor Control</b> : Enables system temperature control using the system thermistor on the secondary loop of a cascade system.
835	<b>Cascade</b> : Setting Primary or Secondary unit assignment.
836	<b>Cascade Units in Standby</b> : Sets which unit in the cascade is the primary unit..
837	<b>Gas Type</b> : For selecting gas type when conducting gas conversion.
838	<b>Model</b> : Manufacture Use Only
839	<b>Vent Material Used</b> : This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.
840	<b>Altitude Setting</b> : Sets the elevation of the boiler installation.

Code	Description
147	<b>Linked Operation Among Each CH Pumps</b> : This parameter enables linked operation among each CH pumps. For example, when parameter b is selected and T/T 1 is active, both pump 1 and 2 are ON. The T/T wire must be connected to the T/T1 connection. Note: Selection d is not available when using an indirect tank.
148	<b>Linked Operation Between Main Boiler Pump and CH Pump 1</b> : This enables the linked operation between the main boiler pump and CH pump 1. Example: when the main pump is on, pump 1 is also on.
149	<b>Main Pump Runs When the Target Temperature is Reached</b> : This selects the mode of the main pump running when the target setpoint is achieved. This setting is for whether running on intervals to reduce pump operation or continuously running to reduce wait time to re-fire. Intervals are 10 minutes ON and 30 minutes OFF.
150	<b>External Pump Runs When the Temperature is Reached</b> : For selecting the mode of external pump running when the temperature is reached to stop. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat in heat exchanger.
151	<b>External Pump Running at Freeze Protection Operation</b> : Selects the mode of external pump running when freeze protection operation. This is setting for whether stopping external pump running to reduce pump operation timing or operating as same as main pump operation to enable to deliver remained heat to the system for keeping system piping from freezing. But it could reduce the temperature inside heat exchanger.
152	<b>Freeze Protection Level</b> : This selects the freeze protection level. Selecting "b" will prevent the boiler from operating in freeze protection mode more than believed necessary.
153	<b>The Differential Temperature From Extinguishing Fire to Fire Again</b> : How much temperature drop is permitted by the supply water thermistor before the boiler will fire again. When selecting "Quick", the boiler will fire more frequently and achieve more temperature control.
154	<b>The Time Which Not Allow to Fire Again for CH</b> : For selecting time which not allow to fire again for CH after shutdown burner. This is setting for whether preventing from frequently operating unit or allowing frequent operation for quick heating up again.
155	<b>Heating Eco Mode On Time</b> : This setting changes the on time of the heating Eco mode. This mode enables greater energy savings by reducing the length of time the boiler is operating. The output temperature of the boiler is slower in this mode.
156	<b>Air Handler Connection</b> : The setting changes to enable to AH output with linking pump 3.
157	<b>Air Handler Post Pump Extension Setting</b> : Extending the post Pump timing of pump 3.


Code	Description
841	<b>0-10V Input Setting</b> : Extending the post Pump timing of pump 3.
842	<b>N/A: Manufacture Use Only</b>
843	<b>Thermostat Usage</b> : Changes the mode between Thermostat Usage and Central Heating Button.
844	<b>System Thermistor Control</b> : Enables system temperature control using the system thermistor on the secondary loop of a cascade system.
845	<b>Cascade</b> : Setting Primary or Secondary unit assignment.
846	<b>Cascade Units in Standby</b> : Sets which unit in the cascade is the primary unit..
847	<b>Gas Type</b> : For selecting gas type when conducting gas conversion.
848	<b>Model</b> : Manufacture Use Only
849	<b>Vent Material Used</b> : This selects the venting material used. The boiler is set from the factory to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this may be adjusted. See the section on PVC Safety Switch for more information.
850	<b>Altitude Setting</b> : Sets the elevation of the boiler installation.




Gas Conversion Kits		
Models	Gas Type	Kit Number
IP1755	NG/LPG	804000124
IP199S		



ITEM	DESCRIPTION	PART NUMBER	IP199S	IP175S
001	Front Cover Panel Assembly FF	809000313	1	1
003	Wall Mount Bracket	109000594	2	2
007	Connection Reinforcement Plate	809000315	1	1
008	Rubber Bushing	CF79-41020-A	5	5
010	Residential Screw and Washer	106000645	1	1
011	Ground Screw	109000076	1	1
012	Combustion Chamber Support Plate (L)	809000316	1	1
013	Combustion Chamber Support Plate (R)	809000317	2	2
015	Igniter bracket	809000318	1	1
016	Igniter Assembly	805000172	1	1
017	Screw	CP-80452	1	1
019	Latch	109001393	2	2
045	Front Cover Panel Gasket Top	809000319	1	1
046	Front Cover Panel Gasket Side	809000320	2	2
047	Front Cover Panel Gasket Bottom	809000321	1	1
100	Burner Door Assembly	806000086	1	1
101	Burner Door Gasket	806000087	1	1
102	Burner Insulation	806000088	1	1
103	Combustion Check Valve Assembly	808000060	1	1
110	Combustion Fan Assembly	808000061	1	1
111	Fan Mounting Packing	109001396	1	1
112	O-ring	109000612	2	2
113	Hexagon Head Screw	809000322	3	3
114	Gas Valve Assembly	806000089	1	1
115	O-ring	109000252	2	2
116	Gas Connection Pipe	806000090	1	1
117	Gas Tube Bracket	109000635	1	1
118	Inlet Gas Supply Connection	106000119	1	1
119	Inlet Gas Test Port Screw	106000138	2	2
120	O-ring	M10B-13-4	2	2
121	Noise Filter Assembly	806000091	1	1
130	Heat Exchanger Assembly	807000245	1	1
131	Heat Exchanger Insulation	806000092	1	1
133	PCB Bracket	809000323	1	1
134	Heat Exchanger Bracket	809000324	1	1
135	Adapter Gasket	809000325	1	1
136	Heat Exchanger Adapter	808000062	1	1
137	Fan Adapter	808000063	1	1
138	Gas Control Adapter	806000093	1	1
139	Hex Nut	809000326	5	5
145	Condensate Trap	807000236	1	1
146	Clip	109000137	2	2
148	Clip	807000246	1	1
149	Drain Tube at Air Intake	809000327	1	1
151	Flame Rod	807000328	1	1
152	Electrode	805000173	1	1
153	Electrode Gasket	805000175	2	2
200	Exhaust Adapter Assembly	808000064	1	1
202	O-ring	108000018	2	2



ITEM	DESCRIPTION	PART NUMBER	IP199S	IP175S
203	Exhaust Adapter Gasket	808000065	1	1
204	Thermistor	105002024	1	1
205	O-ring	107000323	1	1
206	Exhaust Gasket	808000066	1	1
207	Thermistor Screw	109000622	1	1
210	Fuel Connection Assembly	108000083	1	1
211	Cap	109001407	1	1
212	Exhaust pipe connection port - 2 inch	108000084	1	1
213	Exhaust Gasket - 2 inch	109000623	1	1
215	Air Supply Pipe Seal Ring	108000017	1	1
220	Air Supply Box Assembly	808000067	1	1
221	Air Supply Filter (set)	108000086	1	1
222	Air Supply Assembly	108000087	1	1
223	Air Supply Gasket - 2 inch	109000624	1	1
410	CH Outlet Connection	807000182	1	1
413	Water Pressure Sensor Assembly	807000185	1	1
416	Plate HEX-CH Heating Connection (for solo)	807000329	1	1
422	CH Heating Return Pipe Assembly	807000340	1	1
423	CH return Connection (for solo)	807000341	1	1
431	Heat Exchanger Pipe Connection Assembly	807000333	1	1
433	Trap Drain Plug Assembly	807000195	1	1
440	HEX-CH Heating Connection Pipe	807000334	1	1
442	Air Vent	808000052	1	1
443	Heat Exchanger Return Connection	807000335	1	1
453	Pipe Bracket	809000328	4	4
460	Thermistor Sensor	805000154	1	1
461	Thermistor Sensor	805000155	1	1
470	O-ring	807000215	2	2
472	O-ring	807000204	1	1
473	O-ring	807000205	2	2
474	O-ring	807000336	4	4
480	O-ring	807000207	1	1
481	O-ring	807000337	1	1
482	O-ring	807000338	2	2
502	Clip	809000173	2	2
503	Clip	809000329	2	2
702	Integrated Control Assembly	805000177	1	1
705	Transformer	805000158	1	1
706	PC Board Assembly-Solo	805000180	1	1
707	PCB Cover	809000334	1	1
708	Controller Unit Harness	105002042	1	1
710	Power Cord Assembly FF	805000160	1	1
713	Sensor Harness	805000181	1	1
714	Heater Ground Harness	805000162	1	1
716	Over Heat Switch	805000164	1	1
717	Water Pressure Connection Harness	805000090	1	1
718	Thermistor Sensor	805000165	1	1
720	Guide Seal	809000176	1	1
801	Screw	CP-30583	4	4



ITEM	DESCRIPTION	PART NUMBER	IP199S	IP175S
802	Screw	ZBA0408UK	2	2
803	Hexagon Head Screw	ZQA0514UK	6	6
807	Screw	U217-449	4	4
810	Screw	109000179	10	10
814	Screw	109000651	2	2
820	Screw	809000177	51	51
821	Truss Screw	109000598	24	24
822	Screw	809000178	2	2
823	Screw	CP-20883-408UK	6	6
824	Screw	809000179	2	2
825	Ground Screw	109000793	2	2
826	Screw	109000649	8	8
827	Screw	809000331	4	4
828	Screw	809000332	2	2
829	Torx screw	809000333	4	4
860	Wall Bracket	809000314	1	1
861	Vent Screen Set	108000104	1	1
862	LP Conversion Orifice-Included	806000095	1	1
863	Pressure Relief Valve	807000211	1	1
864	Outdoor Temperature Sensor	803000081	1	1
865	System Thermistor	805000179	1	1
888	User Manual - EN	800000218	1	1
889	Installation Manual - EN	N/A	1	1
890	Test sheet	N/A	1	1
891	User Manual - FR	800000219	1	1
892	Installation Manual - FR	N/A	1	1