








# ASSEMBLY INSTRUCTION

## STAINLESS TOP DINING TABLE

---


<b>A</b> Table Top	<b>B</b> Leg	<b>C</b> Allen Wrench 4mm	<b>D</b> Bolt 5/16"x1-3/4"
			
1pc	4pcs	1pc	8pcs
<b>E</b> Lock Washer 5/16"	<b>F</b> Flat Washer 5/16"x19mm		
			
8pcs	8pcs		

---




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 
- 1** Upside down the table top(A), remove the blocks as shown.(The phillips screwdriver is necessary and it's provided by yourself.)



- 
- 2** Upside down the table top(A), attach 4 pcs legs(B) and install use bolt(D), lock washer(E) and flat washer(F), tight by allen wrench(C).













---


## Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

# ASSEMBLY INSTRUCTION


## ROLLED TOP TUFTED CHAIR

<b>A</b> Chair Back  1pc	<b>B</b> Seat  1pc	<b>C</b> Front Leg  2pcs	<b>D</b> Lock Washer M8x13mm  9pcs
<b>E</b> Flat Washer M8x19mm  9pcs	<b>F</b> Bolt M8x80mm  4pcs	<b>G</b> Bolt M8x60mm  4pcs	<b>H</b> Bolt M8x45mm  1pc
<b>I</b> Allen Key M5  1pc	<b>J</b> Wood Dowel Ø10x30mm  2pcs		



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- Put the Seat (B) on a smooth flat surface, attach Front Leg (C) to the Seat (B) using Bolt (G), Lock Washer (D) and Flat Washer (E) on both holes of Seat (B) by Allen Key (I). Turn the Allen Key (I) in Bolt (G). But not too tight. Attach Wood Dowel (J) to Seat (B) back.



Take the Allen Key, and turn the bolts until the legs are secure. **DO NOT TIGHTEN COMPLETELY.** Stop when you feel you are adding force to tighten the bolt.

- Put Chair Back (A) on a smooth flat surface, attach the Seat (B) to the Chair Back (A) using Bolt (F) & Bolt (H), Lock Washer (D), Flat Washer (E) in both holes of Seat (B) and Chair Back (A). Turn the Allen Key (I) in Bolt (F) & Bolt (H).

Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.



Helpful Tip:  
-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

Turn left or turn right to adjust the leveler until the chair is stabilized.

## Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.