

Installation Instructions

Body Side Kit For End of the Counter Installation

Tools Required:

#2 Phillips screw driver
1/4" Nut Driver
Pliers

Parts Supplied:

3 Panel Supports	1-1/4" Spacer	Washer	#8-1" Long Screw
1 Body Side	Clip	#8-3/8" Long	#8-1-1/2" Long Screw
1/2" Spacer	Shoulder Rivet	Hex Screw	

Use these instructions to mount the Body Side Kit on either side of the Slide-In Range.

A Installing the Kit

This Body Side Kit must be installed prior to installing the Range in position.

- A1** Place the three panel supports in the 3 square holes of the vertical side trim and rotate 45° as shown below. (May require Pliers) See illustration on back page.
- A2** Remove the hex head screw at the top end of the vertical side trim as shown in the illustration on back page.
- A3** Insert 1" screw through shoulder rivet. Place the 1/2" spacer over the end of the 1" screw. Place the spacer-shoulder rivet-screw assembly through washer. Install assembly in place of the screw removed in A2. (See illustration on back page.)
- A4** Locate the body side keyway holes over the heads of the panel supports.
- A5** Push the body side forward locking the slots of the keyway holes on the side panel supports.
- A6** Place the short (3/8" long) hex head screw through the bottom hole in the rear of the body side and attach to the lower section of the range. See illustration on back page, **Do Not Tighten**.
- A7** Place the longest screw (1-1/2") through the top hole of the body side at the rear of the range. Slide the spacer (1-1/4") over the screw and attach the screw to the hole in the rear of the range above the louvers. Do not tighten. (If a backsplash kit is used in conjunction with this kit, use the shorter spacer found in the backsplash kit.) See illustration on back page.
- A8** Lift the rear of the body side to close the gap between the cooktop glass and the body side. Tighten the screws from steps A6 and A7.
- A9** To stabilize the bottom front corner of the body side-range assembly, place the clip over the inside flange of the body side and the outside flange of the vertical side trim, as shown in illustration. Start by raising the front corner of the range by turning the leveling leg downward, to provide more clearance for attaching clip. See illustration on back page for details of attaching clip. (Hold the body side and the vertical side trim close for easier assembly of the clip.) See Illustration on back page.
- A10** Refer to the Installation Instructions included with the range to place the range into kitchen location.

