

# REPLACEMENT OF LIGHT BULB

If the light bulb needs to be replaced, follow these instructions to ensure safety from personal harm as well as damage to the clock movement.

- a. Allow the clock to operate until the weights drop to their lowest point and the clock stops.
- b. Unplug the electrical cord from the wall outlet.
- c. Ensure that the clock is positioned square and firm on the floor so that it will not tip over. Open the clock door.
- d. Refer to STEP 3 of the Instruction Manual. Remove the three weights from the clock and place them on the floor on a scratch resistant surface.
- e. Refer to STEP 2 of the Instruction Manual. Hold the pendulum guide firm while removing the pendulum. Place the pendulum in a location where it will not get damaged.
- f. Reach through the front door and locate the light bulb. Replace the light bulb with the same watt bulb as supplied originally.
- g. Plug the electrical cord into the wall outlet. Ensure that the light bulb operates properly.
- h. Refer to STEP 2 of the Instruction Manual to hang the pendulum.
- i. Refer to STEP 3 of the Instruction Manual to hang the weights. Check to make sure that the cable is in the cable pulley. The bottom of each weight is labeled to show its proper hanging position as you view your clock from the front – LEFT – CENTER – RIGHT. Hang the weights on the pulley.
- j. Wind your clock. NEVER wind the clock without weights attached.
- k. Refer to STEP 5 of the Instruction Manual to set the time.
- l. Refer to STEP 6 of the Instruction Manual to start the clock.

