

ASSEMBLY INSTRUCTION

42" ROUND BLACK DINING TABLE

A TABLE TOP




1 pc

B PEDESTAL



1 pc

C MOUNTING PLATE




1 pc

D LEGS



4 pcs

E BOLT
φ1/4"x38mm



6 pcs

F BOLT
φ5/16"x38mm



4 pcs

G HEX NUT
φ5/16"x12mm



8 pcs

H LOCK WASHER
φ5/16"x13mm




18 pcs

I FLAT WASHER
φ 5/16" X 19mm




18 pcs

J ALLEN KEY




1 pc

K WRENCH



1 pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product.


As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1

Attach the Mounting Plate (C) to pedestal (B) with Flat Washer (I), Lock Washer (H), Bolt (F) by Allen Key (J).


**2**

Attach the Mounting Plate (C) to Table Top (A) with Flat Washer (I), Lock Washer (H), Bolt (E) by Allen Key (J).




3

Attach the Legs (D) to Pedestal (B) with Flat Washer (I), Lock Washer (H), Hex Nut (G) by Wrench (K).



4

Assembly product is now completed.













Cleaning & Care :


Treat surface with care. Surface is resistant to scratches but is not scratch resistant.

Clean surface with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION


PARSON CHAIR

A Chair Back	B Seat	C Front Leg	D Lock Washer M8x13mm
			
1pc	1pc	2pcs	9pcs
E Flat Washer M8x19mm	F Bolt M8x80mm	G Bolt M8x60mm	H Bolt M8x45mm
			
9pcs	4pcs	4pcs	1pc
I Allen Key M5	J Wood Dowel Ø10x30mm		
			
1pc	2pcs		



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1 Put the Seat (B) on a smooth flat surface, attach Front Leg (C) to the Seat (B) using Bolt (G), Lock Washer (D) and Flat Washer (E) on both holes of Seat (B) by Allen Key (I). Turn the Allen Key (I) in Bolt (G). But not too tight. Attach Wood Dowel (J) to Seat (B) back.



Take the Allen Key, and turn the bolts until the legs are secure. **DO NOT TIGHTEN COMPLETELY.** Stop when you feel you are adding force to tighten the bolt.

- 2 Put Chair Back (A) on a smooth flat surface, attach the Seat (B) to the Chair Back (A) using Bolt (F) & Bolt (H), Lock Washer (D), Flat Washer (E) in both holes of Seat (B) and Chair Back (A). Turn the Allen Key (I) in Bolt (F) & Bolt (G).

Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.



Helpful Tip:
-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

Turn left or turn right to adjust the leveler until the chair is stabilized.

Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.