

Product Contents

- 1 x AMV-340
- 2 x Mounting Ears
- 4 x Mounting Screws
- 1 x Pluggable Terminal Block
- 1 x RS232 Cable
- 1 x Power Adapter (DC 24V)
- 1 x Power Cord
- 4 x Plastic Cushions
- 1 x Reference Guide

Safety Suggestions

Read and Follow Instructions. Read all safety and operating instructions before operating the unit.

Retain Instructions. Keep the safety and operating instructions for future reference.

Heed Warnings. Adhere to all warnings on the unit and in the operating instructions.

Heat. Keep the unit away from heat sources such as radiators, heat registers, stoves, etc., including amplifiers that produce heat.

Power Sources. Connect the unit only to a power supply of the type described in the operating instructions, or as marked on the unit.

Power Cord Protection. Route power supply cords so that they are not likely to be walked on or pinched by items placed on or against them, paying particular attention to the cord plugs at power receptacles and at the point at which they exit from the unit.

Water and Moisture. Do not use the unit near water—for example, near a sink, in a wet basement, near a swimming pool, near an open window, etc.

Object and Liquid Entry. Do not allow objects to fall or liquids to be spilled into the enclosure through openings.

Servicing. Do not attempt any service beyond that described in the operating instructions. Refer all other service needs to qualified service personnel.

Damage Requiring Service. The unit should be serviced by qualified service personnel when:

- The power supply cord or the plug has been damaged.
- Objects have fallen or liquid has been spilled into the unit.
- The unit has been exposed to rain.
- The unit does not appear to operate normally or exhibits a marked change in performance.
- The unit has been dropped or the enclosure has been damaged.

Cleaning

To clean this product, lightly dampen a lint-free cloth with plain water or a mild detergent and wipe the outer surfaces.

NOTE: Do not use harsh chemicals as damage to the unit may occur.

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.

Industry Canada Compliance Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received including interference that may cause undesired operation.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes:

1. Ce dispositif ne peut causer des interférences nuisibles.
2. Cet appareil doit accepter toute interférence reçue y compris des interférences qui peuvent provoquer un fonctionnement indésirable.



DECLARATION OF CONFORMITY (DOC)

The Declaration of Conformity for this product can be found on the RTI website at: www.rticorp.com/declaration

Contacting RTI

For news about the latest updates, new product information, and new accessories, please visit our web site at: www.rticorp.com

For general information, you can contact RTI at:

Remote Technologies Incorporated
5775 12th Ave. E Suite 180
Shakopee, MN 55379
Tel. (952) 253-3100
Fax (952) 253-3131
info@rticorp.com

Service & Support

If you are encountering any problems or have a question about your RTI product, please contact RTI Technical Support for assistance (see the Contacting RTI section of this guide for contact details).

RTI provides technical support by telephone or e-mail. For the highest quality service, please have the following information ready:

- Your Name
- Company Name
- Telephone Number
- E-mail Address
- Product model and serial number (if applicable)

If you are having a problem with hardware, please note the equipment in your system, a description of the problem, and any troubleshooting you have already tried.

Please do not return products to RTI without return authorization.

Limited Warranty

RTI warrants new products for a period of three (3) years (excluding consumables such as rechargeable batteries which are warranted for one (1) year) from the date of purchase by the original purchaser (end user) directly from RTI / Pro Control (herein referred to as "RTI"), or an authorized RTI dealer.

Warranty claims may be initiated by an authorized RTI dealer using the original dated sales receipt or other proof of warranty coverage. In the absence of the receipt of purchase from the original dealer, RTI will provide warranty coverage extension of six (6) months from the date code of the product. Note: RTI warranty is limited to the provisions set forth in this policy and does not preclude any other warranties offered by third parties who are solely responsible for those other warranties.

Except as specified below, this warranty covers defects in product material and workmanship. The following are not covered by the warranty:

- Product purchased via unauthorized sellers or internet sites will not be serviced—regardless of purchase date.
- Damages caused by accident, misuse, abuse, neglect or acts of God.
- Cosmetic damage, including, but not limited to, scratches, dents and normal wear and tear.
- Failure to follow instructions contained in the Product Installation Guide.
- Damages due to products used in an application or environment other than that for which it was intended, improper installation procedures or adverse environmental factors such as incorrect line voltages, improper wiring, or insufficient ventilation.
- Repair or attempted repair by anyone other than RTI and Pro Control or authorized service partners.
- Failure to perform recommended periodic maintenance.
- Causes other than product defects, including lack of skill, competence or experience of user.
- Damage due to shipment of this product (claims must be made to the carrier).
- Altered unit or altered serial number: defaced, modified or removed.

RTI is also not liable for:

- Damages caused by its products or for failure of its products to perform, including any labor costs, lost profits, lost savings, incidental damages, or consequential damages.
- Damages based upon inconvenience, loss of use of the product, loss of time, interrupted operation, commercial loss, any claim made by a third party or made on behalf of a third party.
- Loss of, or damage to, data, computer systems or computer programs.

RTI's liability for any defective product is limited to repair or replacement of the product, at the sole discretion of RTI.

In cases where the warranty policy conflicts with local laws, the local laws will be adopted.

RTI AMV-340

3x1 Audio Mixer Amplifier

Reference Guide



AMV-340 3x1 Audio Mixer Amplifier


The AMV-340 is a 40 Watt Power Amplifier (Class-D) with output alternatively at 70V or 100V. It has two stereo inputs (1x3.5mm jack for line in, 2xRCA for L&R), one digital input & one balanced MIC. Powerful features include ducking function, EQ control, MIC mixer etc, and the MIC input supports 3 levels with condenser MIC, dynamic MIC & line audio input. The AMV-340 power amplifier is designed to integrate with both 70V and 100V to meet different voltages requirements.

The AMV-340 provides superior quality and reliability as well as these features:

- Mono audio output at 40 Watts.
- Switchable between 70V and 100V.
- Ducking function.
- Sixteen ID codes for discrete control of different AMV-340 amplifiers.
- Three-level MIC input, supports condenser microphone, dynamic microphone and wireless microphone.
- MIC port can support balance/unbalance signal, suppress the external noise effectively.
- Two stereo audio inputs and one digital audio input, switchable by button and RS232.
- Volume/Bass/Treble controllable by buttons and RS232.
- Fast switching speed for good performance.
- Compact form factor with noiseless convection cooler.
- LED indicator, for power and working status.
- Antistatic case design provides protection for long-term, stable performance.


Installation & Operation

FRONT PANEL DESCRIPTION




No.	Name	Function
1	Audio Input Selection	Press button to select the input audio source. Once selected, the corresponding LED will be lit. <ul style="list-style-type: none"> 1 is for dual mono audio input (2 RCA connectors for L&R) 2 is for stereo audio input (3.5mm mini jack) 3 is for digital fiber audio input (optical)
2	Audio Control	Press this button to select the MIC or Line volume level or the Bass and Treble level. Once selected, use the Up/Down arrow buttons to adjust level.
3	Audio Adjustment	To adjust levels up/down or mute the corresponding audio. <ul style="list-style-type: none"> ▼ : Adjust level down (Ex. Turn down the volume) ▲ : Adjust level up (Ex. Turn up the volume) MUTE: Mute the output

REAR PANEL DESCRIPTION




No.	Name	Function
1	Power Indicator	Turns red when power on.
2	Microphone Input	3-pole captive screw connector for microphone input, the dial switch in right side is to select the micro input kind, including 48V (for condenser microphone), MIC (for dynamic microphone) and LINE (for line audio).
3	Audio Input	3.5mm mini jack for stereo audio input, it can be connected with audio source device such as DVD player.
4	ID Code	16 codes range from 0 to F (hexadecimal), works together with the PC control software.
5	Power Port	To connect with the power adapter (DC24V).
6	2 x RCA	Dual-mono audio input, which can be connected with audio source device such as a PC.
7	Digital Audio Input	Fiber connector for digital audio input (PCM format only), it can be connected with a device with fiber port, such as blue-ray player.
8	RS-232	3-pole captive screw connector for serial control, it can be connected with control system (Use a 3-pole captive to 9 pin female D connector) to control AMV-340.
9	Audio Output	To connect with audio output devices, such as speakers (To select 70V or 100V depends on the input voltage of the speakers). COM is for grounding (GND).

CONNECTION DIAGRAM



BUTTON CONTROL



Audio Switching

The INPUT SELECT button will switch between:

- Input 1: RCA analog audio input
- Input 2: 3.5 mm TRS input
- Input 3: Optical digital audio input

Volume and EQ Control

- The LEVEL SELECT button will switch between MIC, LINE, BASS, and TREBLE levels
- When MIC or LINE are selected, the Down, Up, and Mute buttons will adjust the volume or mute the selected input
- When BASS or TREBLE are selected, the Down and Up buttons re or treble levels of the analog audio input signal.

RS-232 Control

To control the AMV-340 using serial communication from a control system, wire the RS-232 output of the control system to the AMV-340 RS-232 3-pole screw connector (pinout: Tx-Gnd-Rx).

- Baud rate: 9600
- Data bit: 8
- Stop bit: 1
- Parity bit: none

INSTALLATION

Visit the RTI dealer portal (www.rticorp.com/dealer) for additional instructions and specifications.

NOTE: Features and specifications subject to change without notice.