



## Bamboo Torch Warnings & Instructions

**⚠️ DANGER: TORCH FUEL IS HARMFUL OR FATAL IF SWALLOWED. CONTAINS PETROLEUM HYDROCARBONS. READ WARNINGS ON TORCH FUEL CONTAINER CAREFULLY.**

**FOR OUTDOOR USE ONLY! KEEP OUT OF REACH OF CHILDREN AND PETS. NEVER LEAVE A BURNING TORCH UNATTENDED. FAILURE TO FOLLOW WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE.**

**USE ONLY TIKI® BRAND TORCH FUELS – DO NOT USE GASOLINE OR OTHER FLAMMABLE FUELS.**

Keep clothing, hair and face away from flame when lighting. Use only in well-ventilated area. Do not use in windy conditions. Do not use fuel canister outside of torch. Use only TIKI® Brand Wicks. Do not tip torch as fuel can spill and cause fire or serious injury. Store fuel in original fuel bottle with cap secured, and dispose of any unwanted fuel in accordance to local laws and regulations.

**⚠️ WARNING:** This product and combustion products emitted when this product is burning can expose you to chemicals including soot, which is known to the State of California to cause cancer and lead which is known to the State of California to cause Cancer and birth defects or other reproductive harm. For more information go to [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov).

### INSTRUCTIONS FOR USE:

- 1. INSTALLING:** Insert torch pole into ground minimum of 6" until secured. Do not place torch under covered shelter or umbrellas, near pedestrian traffic or combustibles such as wood structures, fuel, clothing or dry vegetation. Retain these instructions for reference.
- 2. FILLING:** Unscrew metal flame guard from fuel canister and fill with TIKI® Brand Torch Fuel. Fill to ½" from top seam. DO NOT OVERFILL. Reattach metal flame guard to fuel canister. DO NOT OVERTIGHTEN. Wipe away any spilled fuel before lighting. Place canister in torch.
- 3. LIGHTING:** Allow wick to become saturated with fuel. Exposed wick should be no higher than ¾".
- 4. EXTINGUISHING:** Using the snuffer cap that is attached to the torch, carefully place completely over wick until flame is extinguished. To prevent snuffer cap from igniting, remove after flame is extinguished and allow the wick to cool. Place snuffer cap over wick to protect from elements. Allow to cool for 30 minutes before handling and refilling.

©2020 Lamplight Farms Incorporated • W140 N4900 Lilly Rd., Menomonee Falls, WI 53051

TIKI® is a trademark of Lamplight Farms Incorporated TIKI® es marcas de Lamplight Farms Incorporated

Customer Service/Servicio al cliente: 1-888-473-1088

Made in China/Hecho en China

**⚠️ PELIGRO: EL COMBUSTIBLE DE LA ANTORCHA ES DAÑO O MORTAL SI SE INGIERE. CONTIENE HIDROCARBUROS DE PETRÓLEO. LEA CUIDADOSAMENTE LAS ADVERTENCIAS EN EL ENVASE DEL COMBUSTIBLE DE LA ANTORCHA.**

**PARA USO EN EXTERIORES SOLAMENTE. MANTENGA ALEJADO DEL ALCANCE DE LOS NIÑOS Y LAS MASCOTAS. NUNCA DEJE UNA ANTORCHA ENCENDIDA SIN SUPERVISIÓN. SI NO RESPETA LAS ADVERTENCIAS E INSTRUCCIONES PUEDE PRODUCIR LESIONES PERSONALES O DAÑOS MATERIALES GRAVES.**

**USE ÚNICAMENTE COMBUSTIBLE PARA ANTORCHAS DE MARCA TIKI®, NO UTILICE GASOLINA NI NINGÚN OTRO COMBUSTIBLE INFLAMABLE.**

Mantenga la ropa, cabello y cara lejos de la flama cuando encienda la antorcha.

Utilice sólo en áreas bien ventiladas. No lo utilice cuando haya mucho viento. No utilice un recipiente fuera de la antorcha. Use sólo con mechas de marca TIKI®. Guarde el combustible en el recipiente de combustible original y la tapa bien puesta; deseche el combustible que no necesite según las leyes y normas locales.

**⚠️ AVISO:** Este producto y los productos emanados como resultado de la combustión de este producto pueden exponerlo a sustancias químicas incluido el hollín, que es conocido para el estado de California que causa cáncer. Para obtener más información, visite [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov)

### INSTRUCCIONES DE USO:

- 1. INSTALACIÓN:** Introduzca la varilla de la antorcha en el suelo al menos 15,24 cm, hasta que esté firme. No coloque la antorcha debajo de un refugio cubierto ni de sombrillas, ni tampoco cerca de la circulación peatonal ni de elementos combustibles tales como estructuras de madera, combustible, ropa o vegetación seca. Antes de encender la antorcha retire la etiqueta colgante y guárdela como referencia.
- 2. LLENADO:** Desenrosque el protector metálico de llama del envase de combustible y llénelo con el combustible para antorcha marca TIKI®. Llène a ½" (1.3 cm) de la parte superior costura. NO LLENE EXCESIVAMENTE. Vuelva a colocar el protector metálico de llama en el envase de combustible. NO APRIETE EXCESIVAMENTE. Limpie el combustible derramado antes de encender. Coloque el recipiente en la antorcha.
- 3. ENCENDIDO:** Deje que la mecha se moje completamente con combustible. La mecha expuesta no debe superar los 1,9 cm.
- 4. APAGADO:** Coloque la tapa apagavelas unida a la antorcha completamente sobre la mecha hasta que se apague la flama. Para evitar que la tapa apagavelas se encienda, retírela cuando la mecha esté apagada y deje que la mecha enfríe. Coloque la tapa apagavelas sobre la mecha para proteger esta última de los elementos climáticos. Deje enfriar durante 30 minutos antes de manipular y rellenar.