

INSTRUCTIONS FOR 28° TANK TRIP LEVER

1. Unbend upper lift wire or unclip chain from lever.
2. Hold lever and loosen locknut by turning clockwise with wrench. Remove locknut and withdraw old lever.
3. Insert flush lever through hole in tank.
4. Tighten locknut with wrench by turning counter-clockwise.
5. Insert chain or strap into lever.

INSTRUCCIONES PARA PALANCA DE ACTIVACIÓN DEL TANQUE 28°

1. Desenrolle el alambre de elevación superior o desenganche la cadena de la palanca.
2. Sujete la palanca y afloje la contratuerca girándola hacia la derecha con la llave inglesa. Retire la contratuerca y retire la palanca vieja.
3. Inserte la palanca de descarga a través del agujero en el tanque.
4. Apriete la contratuerca con la llave inglesa girándola hacia la izquierda.
5. Inserte la cadena o la correa en la palanca.

