

Deluxe Press-Fit Plug Protectors

48307 User Guide

ADULT INSTALLATION REQUIRED.

WARNING:

RISK OF FIRE OR ELECTRIC SHOCK. If the closure falls out of or fits loosely in the receptacle, the receptacle contacts may be worn or broken. To reduce the risk of fire or injury caused by overheating, arcing or exposure of live plug blades, do not use the receptacle further until it has been examined by a licensed electrician to determine whether the outlet needs to be replaced.

WARNING:

RISK OF ELECTRIC SHOCK. This device is intended to make it more difficult for children to gain access to energized outlets. Like any other child-deterrent product, this device is not a substitute for adult supervision. An unsupervised child may be able to defeat this product. As with all electrical products, precautions should be observed during handling and use to prevent electric shock.

Discourage children from playing with electrical equipment.

FOR INDOOR HOME USE ONLY.

Important Safety Information

Read all instructions before installing. Keep these instructions for future use.

Your child will eventually be able to defeat this product. To keep this product effective for as long as possible, avoid letting children see how you operate child safety devices. Watching you disengage a lock, latch or cover could enable them to learn sooner how to defeat it.

For best performance, ensure that your wall outlet and face plate are installed correctly and are flush with each other. If the wall outlet and faceplate are not flush, gaps may form between the face plate and the plug protector, potentially making it easier for a child to defeat the device.

CAUTION: This product is only a deterrent.

To Use

- 1 Squeeze left side tab on plug and insert firmly into outlet.
- 2 To remove, squeeze left side tab and press top tab to release lock. While squeezing and pressing tabs, gently pull plug from outlet.

Protectores de toma de corriente a presión de lujo

48307 Guía del Usuario

REQUIERE INSTALACIÓN POR PARTE DE UN ADULTO.

AVISO:

RISK OF FIRE OR ELECTRIC SHOCK. If the closure falls out of or fits loosely in the receptacle, the receptacle contacts may be worn or broken. To reduce the risk of fire or injury caused by overheating, arcing or exposure of live plug blades, do not use the receptacle further until it has been examined by a licensed electrician to determine whether the outlet needs to be replaced.

WARNING:

RIESGO DE DESCARGA ELÉCTRICA. Este dispositivo tiene el fin de dificultar que los niños entren en contacto con las tomas de corriente. Como cualquier otro producto para la seguridad de los niños, este dispositivo no sustituye la supervisión por parte de un adulto. Un niño sin supervisión puede ser capaz de inutilizar la protección que ofrece este producto. Al igual que con cualquier otro artefacto eléctrico, se deben tomar las precauciones necesarias durante su manipulación para evitar descargas eléctricas. Evite que los niños jueguen con dispositivos eléctricos.

PARA USO DOMÉSTICO ÚNICAMENTE EN INTERIORES.

Información de seguridad importante

Lea todas las instrucciones antes de instalar. Guarde estas instrucciones para su uso futuro.

Un niño sin supervisión puede ser capaz de inutilizar la protección que ofrece este producto. Para que este producto funcione efectivamente durante más tiempo, evite que los niños vean como se opera. Si los niños ven cómo usted libera una traba, un pestillo o una cubierta, podrían aprender más rápido la manera de inutilizar cualquier tipo de dispositivo de seguridad.

Para un mejor funcionamiento, asegúrese de que la toma de corriente y la placa frontal estén correctamente instaladas y niveladas una con la otra. Si la toma de corriente y la placa frontal no están niveladas, puede quedar una separación entre la placa frontal y el protector de la toma de corriente, lo que les facilitaría a los niños la manera de inutilizar el dispositivo.

PRECAUCIÓN: Este producto es sólo un elemento disuasivo.

Para Uso

- 1 Presione la lengüeta ubicada al costado izquierdo del enchufe y encaje con firmeza en la toma de corriente.
- 2 Para quitarlo, presione la lengüeta ubicada al costado izquierdo junto con la lengüeta ubicada en la parte superior para liberar la traba y tire hacia afuera.