

Cuisinart® 7-Cup Food Processor

QUICK REFERENCE OPERATION GUIDE

- 1.** With the bowl on the base, use the handle to turn the work bowl clockwise to lock it onto the housing base.



- 2.** Carefully lift and remove the storage hub from the work bowl.



- 3.** **Using the universal chopping/mixing/dough blade:** Carefully place the blade onto the stem adapter. Holding top of stem adapter, lift and place over the work bowl accessory adapter. Blade should rest on the bottom of the work bowl.



- 4.** **Using the reversible slicing and shredding discs:** Insert the stem adapter without the universal blade. Choose the desired disc and carefully place disc over stem adapter, with the side being used facing up.



- 5.** Place the work bowl cover, with feed tube at the back of the work bowl, on the work bowl by latching the back on first and then pushing down on the front to lock into place. Align pusher with the feed tube opening on the work bowl cover and slide down to the bottom. Plug in the housing base. The machine is now ready for use.



- 6.** Add ingredients to the work bowl, either through the feed tube or directly into the bowl. Press the On button and the motor will start. Press the Pulse/Off button when finished.



Cuisinart® Procesadora de alimentos de 7 tazas (1.65 L)

GUÍA DE REFERENCIA RÁPIDA

- 1.** Coloque el bol sobre la base y, agarrándolo del as, gírelo en sentido horario para sujetarlo.



- 2.** Levante con cuidado y retire el eje de almacenamiento del bol.



- 3.** Para usar la cuchilla picadora/mezcladora/amasadora universal: Con cuidado, deslice la cuchilla por encima del adaptador. Sosteniendo el adaptador por la parte superior, colóquelo en el eje del bol. La cuchilla debe quedar en el fondo del bol.



- 4.** Para usar los discos rebanadores/trituradores reversibles: Instale el adaptador removible (sin la cuchilla) en el bol. Con cuidado, coloque el disco deseado sobre el adaptador, con el lado que desea usar apuntado hacia arriba.



- 5.** Coloque la tapa en el bol, el tubo de alimentación en la parte posterior del mismo. Inserte la parte trasera de la tapa primero, y luego presione la parte delantera hasta que quede segura. Inserte el empujador en el tubo de alimentación. Enchufe el cable en una toma de corriente. El aparato está listo para su uso.



- 6.** Coloque los ingredientes en el bol o introdúzcalos en el tubo de alimentación. Presione el botón ON; el aparato se pondrá en marcha. Para apagar el aparato, presione el botón PULSE/OFF.

