Cuisinart®

EasyPop® Popcorn Maker

Remove all packaging materials and any promotional labels or stickers from your popcorn maker. Be sure all parts of your new appliance have been included.

Included Parts

Measuring Cup

Bowl Cap

Popping/Serving Bowl

Removable Popping Plate Assembly

Base

Operating Instructions

1. Place motor base and all removable parts on a clean, flat surface. Make sure the motor base is unplugged from the power outlet and that all parts have been cleaned and dried thoroughly before assembling.

2. Grasp popping plate by the handles and place on top of motor base.

3. Gently press down on the handles until each side of the popping plate rests firmly in place.

4. Grasp the popping bowl by the handles and place it on the popping plate. Be sure that the handles on the popping bowl rest comfortably in the grooves on the popping plate.

5. Plug the popcorn maker into a 120V outlet; your popcorn maker is now assembled for use.

Using the Serving Bowl

1. Place bowl cap on the top of the serving bowl before adding any seasonings.

2. Grasp the locking levers on each side of the popping plate, as well as the handles of the serving bowl, and pinch together. Gently squeeze the locking levers by pulling up and the popping plate and serving bowl will lift from the motor base (2a).

3. Turn over and place the bottom of the serving bowl on a flat service.

4. Once serving bowl is properly positioned, lift the popping plate away from the serving bowl and return to motor base.

Popcorn Amounts

Kernels	Vegetable Oil	Popped Popcorn
¼ cup	1½ teaspoons	Approx. 8 cups
⅓ cup	2 teaspoons	Approx. 1-12 cups
½ cup	1 tablespoon	Approx. 12-14 cups

IMPORTANT!

Do not discard. Read before operating your new Popcorn Maker. Keep for further reference.

These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure proper operation and optimum performance, please read the entire Instruction Booklet.

PG-29975