
BEST CHOICE PRODUCTS



INSTRUCTION MANUAL

24in Handheld Snow Pusher

SKY12138

Ver. 1

NOTICE

Please retain these instructions for future reference.

- Please do not exceed the weight/load limitations of this item.
- Do not allow children to use this item unsupervised. This item is not a toy.
- Always distribute the load evenly over the surface of the pusher tray.
- Do not operate in the vicinity of sharp or dangerous objects that could damage the tires.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Fasten hardware loosely during initial assembly. Do not firmly tighten the hardware until the item is completely assembled.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

TOOLS REQUIRED



WRENCH (PROVIDED, 2)



PHILLIPS SCREWDRIVER (NOT PROVIDED)



1 PERSON ASSEMBLY



UP TO 15 MIN. ASSEMBLY

HARDWARE

1 M6 x 15mm BOLT



4 PCS

2 M6 NUT



4 PCS

3 M8 x 40mm BOLT



2 PCS


4 M8 NUT



2 PCS

PARTS

A BLADE



1 PC

B UPPER POLE



1 PC

C LOWER POLE



1 PC


D BRACKET



1 PC

PRODUCT ASSEMBLY

1. Attach the **part D bracket** to the **part A blade** with four **part 2 nut** and four **part 1 bolts.**
2. Attach the **part C lower pole** to the **part D bracket** with one **part 4 nut** and one **part 3 bolt.**
3. Attach **part B upper pole** to the **part C lower pole** with one **part 4 nut** and one **part 3 bolt.**



HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support


Product Inquiry


Orders FAQ


Product Assembly


Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.