BEST CHOICE
PRODUCTS



INSTRUCTION MANUAL

2D Galloping Lighted 3pc Deer Set

Ver. 1

SKY11402 + SKY11403 + SKY11404

NOTICE | *Please retain these instructions for future reference.*

- This product is intended for outdoor use and should be assembled outdoors only.
- Parts are loosely attached to one another with string lights. Be careful when handling parts as they are joined together with electric wires.
- This item is not intended for permanent installation or use.
- Unplug item when not in use or if left unattended.
- Ensure that your voltage is consistent with specifications.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

WARNING


- Do not plug into a wall outlet until item is fully assembled and lights are properly connected.
- Do not use in extreme weather conditions.
- This product contains glitter, do not assemble indoors to avoid unintended property damage and cleanup.
- Do not allow glitter to contact your eyes or face as this may result in skin irritation or injury.
- Keep item away from all heat sources (fireplace, stove, heater, etc.).
- Please use the provided stakes to properly secure the reindeer.
- Do not secure wiring with staples, nails, or sharp hooks.
- Do not hang ornaments or other objects from the cord.
- Unplug item before removing or changing bulbs.
- Replace burned-out bulbs immediately. Make sure to purchase bulbs of the same rated voltage and wattage.

3PC DEER SET


This set includes three figures: One buck, one doe, and one fawn. Construct the **DEER 1** using the **larger parts** provided, the **DEER 2** with the **medium parts,** and the **DEER 3** with the **smallest parts**. Do not attempt to mix the three figure assemblies.



DEER 1





DEER 2



DEER 3


HARDWARE






PARTS

A BASE



3 PCS

B SUPPORT POLE




3 PCS

C SMALL DECORATIVE PANEL



2 PCS

D LARGE DECORATIVE PANEL




3 PCS

E LEGS




3 SETS

F BODY



3 PCS

G HEAD




3 PCS

H TAIL




3 PCS

I ANTLER/EAR




3 PCS

J BOW



3 PCS


K POWER ADAPTER




3 PCS

PRODUCT ASSEMBLY - DEER 3


1 Insert the **part B support pole** into the **part A base.**



2 Attach the **part C & D decorative panels** to the **part A base.** Secure the connections using four **part 1 cotter pins.**




3 Insert **part E legs** into the designated holes on the **part F body.** Insert the rod on the front left leg into the designated hole on the front right leg. Repeat to secure the back legs.




4 Attach the assembled deer body to the **part B support pole.**

Secure the connections using one **part 1 cotter pin.**




5 Attach the **part H tail** and **part G head** to the **part A body.**

Secure the back of the neck by inserting the neck's pins into the receiver on the body, then use one **part 1 cotter pin** to secure the bottom of the neck.




6 Attach the **part I antlers/ears** and **part J bow** to the deer. Ensure all components are securely attached.




PRODUCT ASSEMBLY - DEER 1 & 2


7 Repeat steps to build the **DEER 2.**




8 Repeat steps to build the **DEER 1.**



9 Locate the plugs on each deer body and connect them to the plugs on the **part J bows** and **part K power adapter.**



10 Secure the assembled figures to the ground with twelve **part 2 U-stakes**, four stakes per base. Plug into a wall outlet to turn on lights.



HELP CENTER

Question about your product? We're here to help. Visit us at:

bestchoiceproducts.com/pages/help



Chat Support


Product Inquiry


Orders FAQ


Product Assembly


Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.