Bent Trimmers

- Nickel-chrome plating resists corrosion and rusting



23008



23010



23011



23015

Cat. No.	Description	Special Features	Application	Material	Cutting Length	Overall Length
23008	Bent Trimmer, 8"	Extended Handle	Cuts Plastic, Rubber, Tar Paper, Cording, Vinyl, Fiberglass Insulation and Cloth Materials	Metal	3.5" (88.9 mm)	9" (228.6 mm)
23010	Bent Trimmer, 10"	Extended Handle	Cuts Plastic, Rubber, Tar Paper, Cording, Vinyl, Fiberglass Insulation and Cloth Materials	Metal	4.5" (114.3 mm)	10.5" (266.7 mm)
23011	Bent Trimmer, 11-1/4"	Extended Handle	Cuts Felt Lining, Muslin, Cord, Rubber, Abrasive Materials and Multiple Layers of Fabric	Metal	4.75" (120.7 mm)	11.25" (285.8 mm)
23015	Single Serrated Blunt Blade Shear	Extended Handle, Serrated Blade	Cuts Belting, Heavy Fabric or Carpet, Leather, Upholstery	Metal	3.188" (81 mm)	9.75" (247.7 mm)

Sharpening Tools

Pocket-Sized Knife Sharpener

- Versatile sharpener featuring fine craftsmanship and unique design
- Sharpening rod unscrews and stores in handle for convenient carrying in tool box, pouch, or pocket
- Sharpening rod is precision-cut, hard-chromed steel for accurate, consistent sharpening and long life
- Magnetized to trap metal particles when sharpening
- Handle is a high-visibility orange color with handy pocket clip

PRODUCT SHOWN CLOSED





PRODUCT SHOWN OPEN

44151

Cat. No.	Blade Length	Overall Length	Overall Width	Blade Material	Handle Length
44151	3.75" (95.3 mm)	9.5" (241.3 mm)	0.5" (12.7 mm)	Steel	5.5" (139.7 mm)

Combination Knife and Scissors Sharpener

- High-grade, tungsten-carbide inserts sharpen both sides of the blade at the same time
- Restores knife edge in three or four strokes
- Built-in finger guard helps to protect your hand
- Lightweight, compact size for easy carrying and storage
- Sharpens electrician's scissors, pocket knives, retractable-blade utility knives, razor blade knives and serrated knives



48036

Cat. No.	Overall Length	Overall Width
48036	4" (101.6 mm)	2.25" (57.2 mm)

⚠WARNING: Improper use of knife and scissors sharpener and/or failure to follow instructions can result in injuries. Keep your fingers behind the curved guard and your thumb securely on the multi-grooved thumb-rest indentation, never in front of it.