97982-INS - DIGITAL TIRE PRESSURE GAUGE (GENERIC)

SPECIFICATIONS

2.250"

4.000"

Hang Hole

INSTRUCTIONS

Turn On/Off with [ON/MODE].

To zero the gauge: Press and hold [ZERO/SET] 3 seconds.

While gauge is on, turn the backlight on with [ZERO/SET].

To change the Unit Display:

1. Press and hold [ON/MODE] 3 seconds.
2. Press [ZERO/SET] to select "Unit" mode.
3. Press [ON/MODE] to cycle through PSI, Bar, kg_f/cm^2, kPa, Temp (ºC).
4. Press [ZERO/SET] to select the desired unit.

To change the Pressure Hold Mode:

1. Press and hold [ON/MODE] 3 seconds.
2. Press [ON/MODE] 1 time. "Hold" will be flashing.
3. Press [ZERO/SET] to select "Hold" mode.
4. Press [ON/MODE] to cycle through continuous, peak, and valley display modes.
5. Press [ZERO/SET] to select the desired mode.

To change the Auto-off Timer:

1. Press and hold [ON/MODE] 3 seconds.
2. Press [ON/MODE] 2 times. "Auto" will be flashing.
3. Press [ZERO/SET] to select "Auto-off Timer" mode.
4. Press [ON/MODE] to cycle through time (in minutes) before the gauge automatically turns off. Select "Off" to disable the "Auto-off" feature. The LCD will display "Sleep" to let you know the "Auto-off" is disabled.
5. Press [ZERO/SET] to select the desired time.

To change the Backlight Timer:

1. Press and hold [ON/MODE] 3 seconds.
2. Press [ON/MODE] 3 times. "bLEd" will be flashing.
3. Press [ZERO/SET] to select "Backlit LED Timer" mode.
4. Press [ON/MODE] to cycle through time (in seconds). for the backlit LED. Select "On" or "Off" to keep the backlight always on or always off.
5. Press [ZERO/SET] to select the desired time.

To reset Temperature Compensation

1. Press and hold [ON/MODE] 3 seconds
2. Press [ON/MODE] 4 times. "CoFF" will be flashing.
3. Press [ZERO/SET] to reset the gauge to default (atmoshperic pressure at sea level).

MATERIAL SPECIFICATION: Plastic Card Stock
COLOR SPECIFICATION: Black
SIZE: As referenced above