Salter Megastone 28cm Wok - Silver

BW05753S2EU7

Please retain instructions for future reference.

Care and use

Before using the cookware for the first time, it is essential to hand-wash it thoroughly. To precondition the non-stick surface, wipe the inside of the cookware with vegetable oil, gently heat it, allow it to cool completely, and then wipe it clean with a soft cloth. This cookware is suitable for use on gas, electric solid hot plates, halogen, radiant ring, and induction hobs; however, it must not be used in a domestic or microwave oven, for deep fat frying, under a grill, on an open flame, or a barbecue. To prevent scorching the soft-touch coating on the handles, avoid placing the cookware on hob rings larger than its base size or allowing flames to overlap the sides. It is appropriate to use heat-resistant plastic, silicone, wooden, or metal utensils under normal cooking conditions, but please refrain from cutting food directly in the cookware, as this can damage the surface. Do not overheat empty cookware or use it at high heat, as the non-stick coating is designed for medium heat settings. Always supervise cookware while in use and ensure proper ventilation in your kitchen. Exercise care when moving cookware on ceramic hobs, as they can be scratched; it is advisable to lift rather than drag the cookware across the surface. Any screws on the cookware may become loose over time, and should be retightened with a screwdriver as necessary; however, take care not to overtighten screws on glass lids to avoid damaging them. After use, allow the cookware to cool completely before moving or cleaning. While it is dishwasher safe, hand-washing is recommended to maintain its finish. Clean the cookware with warm, soapy water and a mild detergent using a soft cloth; abrasive cleaners or scourers should be avoided. If using a dishwasher, remove the cookware promptly after the cycle ends and dry it thoroughly. For stubborn stains, use a non-abrasive plastic mesh or pad with warm, soapy water. Store the cookware in a dry, clean place and refrain from storing it while wet; when stacking, place a piece of paper between items to prevent scratching. Take caution that handles do not overlap adjacent hob rings or extend over the edge of the hob, as they may become hot during use; always use heat-resistant gloves when moving the cookware. Ensure that the cookware does not boil dry to prevent warping, and never expose hot cookware to cold water or liquids. If overheating occurs, allow the cookware to cool to room temperature before removal from the hob, and inspect its condition for safety before subsequent uses. If there is any sign of damage, dispose of it responsibly. Provided the care and usage instructions are adhered to, Salter offers a ten-year guarantee, which promises to replace, substitute, or refund any product that fails due to faulty workmanship or materials, but this does not cover damage caused by accidents or misuse and is in addition to your statutory rights. This cookware is guaranteed against peeling and blistering of the non-stick coating for the life of the pan, as long as it is used according to the care and use guidelines; this guarantee does not cover any damage resulting from incorrect use and is valid for the UK and ROI only.

Made in **China**.

Manufactured by: UP Global Sourcing UK Ltd, Address: Victoria Street, Oldham, Manchester OL9 0DD. **UK**.

Ultimate Products Europe Ltd, Address: 19 Baggot Street Lower, Dublin, D02 X658. **ROI**.