

glass warehouse


LAN-HH180

Lani Glass to glass for 10mm (3/8”)- 15mm (19/32”) glass





BACK- inside




FRONT- outside


Installation

1. Check that the alignment of the glass hinge panel is plumb.


Watch the install video




2. Undo the cover plate screws completely, then screw them back in 2 to 3 turns. For 12mm (1/2“) and above panel thickness, remove the rear spacer from the corresponding side. For 10mm (3/8“) panel leave the rear spacer in.




3. Take one hinge and slide the D plate side into the top cut out of the hinge panel. Lightly tighten the cover plate screws. The hinge should still be movable in the cut out. Repeat these steps for the other hinge in the bottom cut out.




4. Open the top hinge and place packers below the hinge. Push them in level with the glass then rest the hinge on the packer. Repeat for the bottom hinge. Make sure the hinges are plumb. Then tighten the cover plate screws on the hinge panel side.



5. Place the gate panel on timber blocks to bring it close to level with the other panels. Then slide the gate panel into the hinges. Position the gate panel with the latch side 1mm higher. Then tighten the cover plate screws.



6. Open the gate and on the gate panel side, insert the packers above the hinge for both top and bottom hinges. Push packers in level with the glass, then carefully test the gate and make sure it opens freely.



glass warehouse

LAN-HH180

Watch the install video


Lani Glass to glass for 10mm (3/8”) - 15mm(19/32") glass

NOTE: Speed or damper adjustments should only be done a ter the hinges are installed.
In most cases, the hinges will not need any adjustment.


WATCH VIDEO atlantichinge.com/install

Increasing speed


1. Insert the speed tool all the way into the speed adjuster at the base of the arrow.



2. Apply pressure on the speed tool in the + symble direction until you can remove the speed pin. Then push the tool to the + symble to increase speed.




3. Insert the speed pin all the way back in,release the pressure of the speed tool and remove it.




Reducing speed


1. Insert the speed tool all the way into the speed adjuster at the + symbol.



2. Apply pressure in the + direction on the speed tool until you can remove the speed pin. Then allow the tool to rotate to the base of the arrow to reduce speed.




3. Insert the speed pin all the way back in, release the pressure of the speed tool and remove it.




Damper adjustment

Damper adjusters are numbered. The larger the number, the more damping. 15 is the highest and 12 is the lowest.



1. Open the gate and slide out the damper adjuster.



2. Insert the damper adjuster. Push in all the way.

TROUBLESHOOTING CHECKLIST

Squeak Noise - Check the spigots as they can cause this noise in some circumstances.


Door closing slowly - Check hinge panel alignment and speed adjustment and damper adjustment. if the problem persists, please contact Atlantic Hinge.


Door slamming - Check damper adjustment and reduce closing speed. If the problem persists, please contact Atlantic Hinge.

glass warehouse


LAN-HH0B90

Lani Glass to wall for 10mm (3/8”)- 15mm (19/32”) glass





BACK- inside



FRONT- outside


Installation

1. Check the wall or post alignment, making sure it is plumb and level. Also make sure the glass latch panel or post is plumb and in alignment.


Watch the install video




2. Undo the cover plate screws completely, then screw them back in 2 to 3 turns. For 12mm (1/2“) and above panel thickness, remove the rear spacer. For 10mm (3/8“) panel leave the rear spacer in.




3. Take one hinge and slide it into the gate panel. With the hinge in the center of the cutout push all the way to the back of the cutout tighten the cover plate screws. Repeat these steps for the lower hinge.




4. Place the gate panel with the fixed hinges into position on some timber blocks at the desired level and make sure it is plumb.



5. Pre drilling the holes for harder timbers or masonry. Then secure the first 2 wall screws on the top hinge into the timber. Repeat for the lower hinge. Carefully open the gate and secure the other 2 screws on each hinge.



6. Push packers in above the hinge for the glass to rest on. They should be pushed in past the level of the glass (see diagram). Repeat step 6 for bottom hinge.




glass warehouse

LAN-HH0B90

MASONRY WALL INSTALLATION

Lani Glass to wall for 10mm (3/8”)- 15mm (19/32”) glass

Extra Accessories



Template


These instructions must be followed or the warranty will be voided.

Installation


1 to 4. Follow steps 1 to 4 from the standard installation instructions, then follow on from here.

Watch the install video

4a. With the gate and hinges in position, mark the 2 visible holes on both hinge. (Warranty will be voided if masonry walls are drilled with hinges in place.)




4b. Move the gate with hinges out of the doorway. Then use the included template to mark the other 2 holes for both hinges.




4c. With the gate still moved out of the doorway, drill all four holes and repeat for the second hinge. Then install your wall plugs.



5. Move the gate with hinges back into position. Then secure the first two wall screws on the top hinge. Repeat for the lower hinge. Carefully open the gate and secure the other two screws on each hinge.



6. Push packers in above the hinge for the glass to rest on. They should be pushed in past the level of the glass (see diagram). Repeat step 6 for bottom hinge.



glass warehouse

LAN-HH0B90

Watch the install video

Lani Glass to wall for 10mm (3/8”) - 15mm(19/32) glass

NOTE: Speed or damper adjustments should only be done a ter the hinges are installed.
In most cases, the hinges will not need any adjustment.


WATCH VIDEO atlantichinge.com/install

Increasing speed

1. Insert the speed tool all the way into the speed adjuster at the base of the arrow.




2. Apply pressure on the speed tool in the + symble direction until you can remove the speed pin. Then push the tool to the + symble to increase speed.



3. Insert the speed pin all the way back in, release the pressure of the speed tool and remove it.




Reducing speed


1. Insert the speed tool all the way into the speed adjuster at the + symbol.



2. Apply pressure in the + direction on the speed tool until you can remove the speed pin. Then allow the tool to rotate to the base of the arrow to reduce speed.



3. Insert the speed pin all the way back in, release the pressure of the speed tool and remove it.




Damper adjustment

Damper adjusters are numbered. The larger the number, the more damping. 15 is the highest and 12 is the lowest.



1. Open the gate and slide out the damper adjuster.



2. Insert the damper adjuster. Push in all the way.

TROUBLESHOOTING CHECKLIST

Squeak Noise - Check the spigots as they can cause this noise in some circumstances.

Door closing slowly - Check hinge panel alignment and speed adjustment and damper adjustment. If the problem persists, please contact Atlantic Hinge.

Door slamming - Check damper adjustment and reduce closing speed. If the problem persists, please contact Atlantic Hinge.


glass warehouse

LOK-PL180


LOKI PRO-LATCH 180

8-12mm gate & 12mm catch panel


Accessories



1mm plastic 4pc`s




FRONT - Outside pool area




BACK - Inside pool area

Installation


1. Loosen the M5 x 16 screws enough so the front plate and back plate are detached. For a 10mm gate add 2 pc`s of 1mm plastic on the back plate. 8mm gate add 4 pc`s



2. Place the front plate and back plate over the gate panel. Align the side edge with the gate then tighten the M5 x 16 screws.



3. Put the 180 catch fully over the catch panel and align it with the front plate then tighten the M6 screws. Check the glass panel gap is 8-10mm.




glass warehouse

LOK-PLWG

LOKI PRO-LATCH Wall

8-12mm gate panel


Accessories




1mm plastic 4pc`s



Screw 3pc




FRONT - Outside pool area




BACK - Inside pool area

Installation


1. Loosen the M5 x 16 screws enough so the front plate and back plate are detached. For a 10mm gate add 2 pc`s of 1mm plastic on the back plate. 8mm gate add 4 pc`s



2. Place the front plate and back plate over the gate panel. Align the side edge with the gate then tighten the M5 x 16 screws.



3. Hold the wall catch aligned with the front plate and mark position. Open gate and screw the wall catch to the wall. Check the glass panel gap is 6-8mm.




glass warehouse

LOK-PL90EXT


LOKI PRO-LATCH 90 External

8-12mm gate & 12mm catch panel


Accessories



1mm plastic 4pc`s




FRONT - Outside pool area




BACK - Inside pool area

Installation


1. Loosen the M5 x 16 screws enough so the front plate and back plate are detached. For a 10mm gate add 2 pc`s of 1mm plastic on the back plate. 8mm gate add 4 pc`s



2. Place the front plate and back plate over the gate panel. Align the side edge with the gate then tighten the M5 x 16 screws.



3. Put the 90 catch over the catch panel and align it with the front plate. Then tighten the M6 screws, they must not protrude. Make sure the glass panel gap is 8-10mm.




glass warehouse

LOK-PL90INT


LOKI PRO-LATCH 90 Internal

8-12mm gate & 12mm catch panel


Accessories



1mm plastic 4pc`s




FRONT - Outside pool area




BACK - Inside pool area

Installation

1. Loosen the M5 x 16 screws enough so the front plate and back plate are detached. For a 10mm gate add 2 pc`s of 1mm plastic on the back plate. 8mm gate add 4 pc`s



2. Place the front plate and back plate over the gate panel. Align the side edge with the gate then tighten the M5 x 16 screws.



3. Put the 90 catch over the catch panel and align it with the front plate. Then tighten the M6 screws, they must not protrude. Make sure the glass panel gap is 8-10mm.

