BEST CHOICE
PRODUCTS

INSTRUCTION MANUAL

24in Christmas Wreath with Bow

Ver. 1

THIS PRODUCT MAY CONTAIN FLOCKING POWDER

For flocked wreaths, assemble this product outside or on a disposable surface for easy cleanup. Keep out of reach of children and pets if possible. Avoid contact with the face, eyes, and mouth. Wash affected areas thoroughly in case of accidental exposure.

APPLICABLE TO WREATHS WITH REMOTE CONTROL

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

⚠ WARNING

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

b) Even used batteries may cause severe injury or death.

c) Call a local poison control center for treatment information.

d) Non-rechargeable batteries are not to be recharged.

e) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

f) Ensure the batteries are installed correctly according to polarity (+ and -).

g) Do not mix old and new batteries. different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

h) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

i) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

NOTICE

Please retain these instructions for future reference.

- Product is intended for indoor or outdoor use.
- Do not place this item in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of an open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

CLEANING & STORAGE

- Store in a cool and dry place away from heat and moisture.
- Before putting in storage, please complete the following:
  - Completely remove all decorations.
  - Clean with a slight damp cloth and let it dry naturally.

1 PERSON ASSEMBLY

APPROXIMATELY 15-30 MIN. ASSEMBLY

PARTS

A WREATH



1 PC

B BOW



1 PC

C PVC TIE



1 PC

PRODUCT ASSEMBLY

1 Locate the battery box behind the wreath and install **3 D batteries. (not provided)**



2 Fluff the wreath and arrange tips according to your preference.



PRODUCT ASSEMBLY

3

Locate the steel ring on the back of the **part B bow,** then loop the **part C PVC strip** through the steel ring and secure by tying a knot.



4

Place the **part B bow** on the front of the **part A wreath,** then part the branches and tie the **part C PVC strip** to the wreath's frame. Tie tightly to secure.

Plug the bow into the wreath's power cord.



Fluff the wreath and arrange tips according to your preference.

FLUFFING TIPS

1. Lay the wreath on a flat, level surface, then hold it down with one hand.
2. Use your free hand to shape the tips, starting at the base and working your way upward/inward.
3. Lift each branch tip to create a full, layered appearance.
4. Gently curve the tips to fill any bare spots.
5. Check your work twice.
6. For pre-lit wreathes, plug in the lights to make sure they are visible through the foliage.
7. Adjust the bow until it sits as desired.

HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com

CHAT US!
Chat Support

Product Inquiry

Orders FAQ

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

BEST CHOICE
PRODUCTS

INSTRUCTION MANUAL

30in Christmas Wreath with Bow

Ver. 2

THIS PRODUCT MAY CONTAIN FLOCKING POWDER

For flocked wreaths, assemble this product outside or on a disposable surface for easy cleanup. Keep out of reach of children and pets if possible. Avoid contact with the face, eyes, and mouth. Wash affected areas thoroughly in case of accidental exposure.

APPLICABLE TO WREATHS WITH REMOTE CONTROL

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

⚠ WARNING

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

b) Even used batteries may cause severe injury or death.

c) Call a local poison control center for treatment information.

d) Non-rechargeable batteries are not to be recharged.

e) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

f) Ensure the batteries are installed correctly according to polarity (+ and -).

g) Do not mix old and new batteries. different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

h) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

i) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

NOTICE

Please retain these instructions for future reference.

- Product is intended for indoor or outdoor use.
- Do not place this item in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of an open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

CLEANING & STORAGE

- Store in a cool and dry place away from heat and moisture.
- Before putting in storage, please complete the following:
  - Completely remove all decorations.
  - Clean with a slight damp cloth and let it dry naturally.

1 PERSON ASSEMBLY

APPROXIMATELY 15-30 MIN. ASSEMBLY

PARTS

A WREATH



1 PC

B ADAPTER

1 PC

C BOW



1 PC

D PVC TIE



1 PC

PRODUCT ASSEMBLY

1 Connect the **part B adapter** to the power cord. Set aside the wreath.



2 Fluff the wreath and arrange tips according to your preference.



PRODUCT ASSEMBLY

3

Locate the steel ring on the back of the **part C bow,** then loop the **part D PVC strip** through the steel ring and secure by tying a knot.



4

Place the **part C bow** on the front of the **part A wreath,** then part the branches and tie the **part D PVC strip** to the wreath's frame. Tie tightly to secure.

Plug the bow into the wreath's power cord.



Do not plug this item into an outlet until it is fully assembled and fluffed.

Fluff the wreath and arrange tips according to your preference.

FLUFFING TIPS

1. Lay the wreath on a flat, level surface, then hold it down with one hand.
2. Use your free hand to shape the tips, starting at the base and working your way upward/inward.
3. Lift each branch tip to create a full, layered appearance.
4. Gently curve the tips to fill any bare spots.
5. Check your work twice.
6. For pre-lit wreathes, plug in the lights to make sure they are visible through the foliage.
7. Adjust the bow until it sits as desired.

HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com

CHAT US!
Chat Support

Product Inquiry

Orders FAQ

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

BEST CHOICE PRODUCTS

INSTRUCTION MANUAL

36in Christmas Wreath with Bow

Ver. 2

THIS PRODUCT MAY CONTAIN FLOCKING POWDER

For flocked wreaths, assemble this product outside or on a disposable surface for easy cleanup. Keep out of reach of children and pets if possible. Avoid contact with the face, eyes, and mouth. Wash affected areas thoroughly in case of accidental exposure.

APPLICABLE TO WREATHS WITH REMOTE CONTROL

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

⚠ WARNING

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

b) Even used batteries may cause severe injury or death.

c) Call a local poison control center for treatment information.

d) Non-rechargeable batteries are not to be recharged.

e) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

f) Ensure the batteries are installed correctly according to polarity (+ and -).

g) Do not mix old and new batteries. different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

h) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

i) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

NOTICE

Please retain these instructions for future reference.

- Product is intended for indoor or outdoor use.
- Do not place this item in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of an open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

CLEANING & STORAGE

- Store in a cool and dry place away from heat and moisture.
- Before putting in storage, please complete the following:
  - Completely remove all decorations.
  - Clean with a slight damp cloth and let it dry naturally.

1 PERSON ASSEMBLY

APPROXIMATELY 15-30 MIN. ASSEMBLY

PARTS

A WREATH



1 PC

B ADAPTER

1 PC

C BOW



1 PC

D PVC TIE



1 PC

PRODUCT ASSEMBLY

1 Connect the **part B adapter** to the power cord. Set aside the wreath.



2 Fluff the wreath and arrange tips according to your preference.



PRODUCT ASSEMBLY

3

Locate the steel ring on the back of the **part C bow,** then loop the **part D PVC strip** through the steel ring and secure by tying a knot.



4

Place the **part C bow** on the front of the **part A wreath,** then part the branches and tie the **part D PVC strip** to the wreath's frame. Tie tightly to secure.

Plug the bow into the wreath's power cord.



Do not plug this item into an outlet until it is fully assembled and fluffed.

Fluff the wreath and arrange tips according to your preference.

FLUFFING TIPS

1. Lay the wreath on a flat, level surface, then hold it down with one hand.
2. Use your free hand to shape the tips, starting at the base and working your way upward/inward.
3. Lift each branch tip to create a full, layered appearance.
4. Gently curve the tips to fill any bare spots.
5. Check your work twice.
6. For pre-lit wreathes, plug in the lights to make sure they are visible through the foliage.
7. Adjust the bow until it sits as desired.

HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com

CHAT US!
Chat Support

Product Inquiry

Orders FAQ

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

BEST CHOICE
PRODUCTS

INSTRUCTION MANUAL

48in Christmas Wreath with Pre-Lit Bow

Ver. 2

THIS PRODUCT MAY CONTAIN FLOCKING POWDER

For flocked wreaths, assemble this product outside or on a disposable surface for easy cleanup. Keep out of reach of children and pets if possible. Avoid contact with the face, eyes, and mouth. Wash affected areas thoroughly in case of accidental exposure.

APPLICABLE TO WREATHS WITH REMOTE CONTROL

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

⚠ WARNING

a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.

b) Even used batteries may cause severe injury or death.

c) Call a local poison control center for treatment information.

d) Non-rechargeable batteries are not to be recharged.

e) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

f) Ensure the batteries are installed correctly according to polarity (+ and -).

g) Do not mix old and new batteries. different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

h) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

i) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

NOTICE

Please retain these instructions for future reference.

- Product is intended for indoor or outdoor use.
- Do not place this item in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of an open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

CLEANING & STORAGE

- Store in a cool and dry place away from heat and moisture.
- Before putting in storage, please complete the following:
  - Completely remove all decorations.
  - Clean with a slight damp cloth and let it dry naturally.

TOOLS REQUIRED

SMALL WRENCH

1 PERSON ASSEMBLY

APPROXIMATELY 30-45 MIN. ASSEMBLY

PARTS

A BOLT SET

4 SETS

B WREATH



1 SET

C ADAPTER

1 PC

D BOW



1 PC

E PVC TIE



1 PC

PRODUCT ASSEMBLY

1 Assemble **part B wreath** with four **part A bolt sets.**



2 Connect the **part C adapter** to the power cord. Set aside the wreath.



PRODUCT ASSEMBLY

3 Fluff the wreath and arrange tips according to your preference.



4 Locate the steel ring on the back of the **part D bow,** then loop the **part E PVC strip** through the steel ring and secure by tying a knot.



PRODUCT ASSEMBLY

5

Place the **part D bow** on the front of the **part B wreath,** then part the branches and tie the **part E PVC strip** to the wreath's frame. Tie tightly to secure.

Plug the bow into the wreath's power cord.



Do not plug this item into an outlet until it is fully assembled and fluffed.

Fluff the wreath and arrange tips according to your preference.

FLUFFING TIPS

1. Lay the wreath on a flat, level surface, then hold it down with one hand.
2. Use your free hand to shape the tips, starting at the base and working your way upward/inward.
3. Lift each branch tip to create a full, layered appearance.
4. Gently curve the tips to fill any bare spots.
5. Check your work twice.
6. For pre-lit wreathes, plug in the lights to make sure they are visible through the foliage.
7. Adjust the bow until it sits as desired.

HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com

CHAT US!
Chat Support

Product Inquiry

Orders FAQ

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.

BEST CHOICE
PRODUCTS

INSTRUCTION MANUAL

60in Christmas Wreath with Pre-Lit Bow

Ver. 1

THIS PRODUCT MAY CONTAIN FLOCKING POWDER

For flocked wreaths, assemble this product outside or on a disposable surface for easy cleanup. Keep out of reach of children and pets if possible. Avoid contact with the face, eyes, and mouth. Wash affected areas thoroughly in case of accidental exposure.

BEST CHOICE
PRODUCTS

As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

Always.

NOTICE

Please retain these instructions for future reference.

- Product is intended for indoor or outdoor use.
- Do not place this item in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of an open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.
- This product is intended for residential use only.

CLEANING & STORAGE

- Store in a cool and dry place away from heat and moisture.
- Before putting in storage, please complete the following:
  - Completely remove all decorations.
  - Clean with a slight damp cloth and let it dry naturally.

TOOLS REQUIRED

SMALL WRENCH

1 PERSON ASSEMBLY

APPROXIMATELY 30-45 MIN. ASSEMBLY

PARTS

A M4 x 30mm BOLT SET

6 SETS

B WREATH



1 SET

C ADAPTER

1 PC

D BOW



1 PC

E PVC TIE



1 PC

PRODUCT ASSEMBLY

1 Assemble **part B wreath** with six **part A bolt sets.**



2 Connect the **part C adapter** to the power cord. Set aside the wreath.



PRODUCT ASSEMBLY

3 Fluff the wreath and arrange tips according to your preference.



4 Locate the steel ring on the back of the **part D bow,** then loop the **part E PVC strip** through the steel ring and secure by tying a knot.



PRODUCT ASSEMBLY

5

Place the **part D bow** on the front of the **part B wreath,** then part the branches and tie the **part E PVC strip** to the wreath's frame. Tie tightly to secure.

Plug the bow into the wreath's power cord.



Do not plug this item into an outlet until it is fully assembled and fluffed.

Fluff the wreath and arrange tips according to your preference.

FLUFFING TIPS

1. Lay the wreath on a flat, level surface, then hold it down with one hand.
2. Use your free hand to shape the tips, starting at the base and working your way upward/inward.
3. Lift each branch tip to create a full, layered appearance.
4. Gently curve the tips to fill any bare spots.
5. Check your work twice.
6. For pre-lit wreathes, plug in the lights to make sure they are visible through the foliage.
7. Adjust the bow until it sits as desired.

HELP CENTER

Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com

CHAT US!
Chat Support

Product Inquiry

Orders FAQ

Product Assembly

Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

© Best Choice Products, Inc. All rights reserved. Distributed by Best Choice Products, Inc. Newport Beach, CA 92660

⚠ WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.