

Step 10

Attach the front panel to the cabinet.

