

23303

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Unscrew the canopy screws (5) using a screwdriver (not included) from the canopy (4) to detach the mounting plate (1).
2. Attach the mounting plate (1) with box screws (2) to the outlet box.
3. Pull out the outlet wire and ground wire from the outlet box.
4. Make wire connections with wire nut (3).
 - Connect the white wire (Neutral wire) from the light to the white wire from power source.
 - Connect the black wire (Live wire) from the light to the black wire from power source.
 - Wrap the grounding wire (green wire or bare copper wire) from the light around the green screw on the mounting plate (1), then connect it to the grounding conductor from power source.
5. Carefully tuck all wires back into the outlet box. Attach the canopy (4) to the mounting plate (1) and secure it with the canopy screws (5) using a screwdriver (not included).
6. Place the center tube (7) and center plate (10) onto the threaded pipe of the canopy (4). Then, thread the socket assembly (11) onto the canopy (4).
7. Unscrew the fixture screws (9) from the metal frame (13) using a screwdriver (not included).
8. Place the glass shade (12) into the metal frame (13), press down the metal clips to secure the glass shade (12) in place. Align the holes of the metal frame (13) with the holes on the canopy (4), and then secure with the previously removed fixture screws (9) using a screwdriver (not included).
9. Install 60W Max A19 bulbs (bulbs not included).
(Don't exceed the maximum capacity recommended on the sockets).
10. Place the metal washer (15), 1pc rubber washer (16) and diffuser (17) onto the socket assembly (11), and then secure with another rubber washer (16) and finial (18).

