

Prior to pole installation.

check with local authorities for location of utility lines (gas, elec., water) in area where hole is to be dug. Make sure all under ground-wiring has been installed according to local building codes.

Post installation

- A) Dig a hole 16" in diameter and check local building codes for hole depth.
- B) Layer bottom of hole with 4" of gravel or crushed stone. Paint the lower section of pole that will be buried, with an asphalt sealer. This will prevent corrosion between the aluminum pole and the concrete.
- C) Place pole in center of hole and feed wire through wireway hole (X). With stakes and twine support the pole in plum position
- D) Mix and pour concrete per manufacturers instructions, and let dry completely.

