

5' Steam Dryer Installation Kit with 3/4" Elbow

Parts List

- A. Wye adapter
- B. 60" hose with 3/4" elbow fitting
- C. 12" hose

Tools

- Pliers

Installation Instructions

Confirm that all parts are present. Connect to cold water valve only.

1. Turn off the cold water supply at the shutoff valve.
2. Unscrew and remove the washer cold inlet hose from the cold water supply valve.
3. Attach one female end of the 12" hose to the cold water valve. Hand-tighten, then tighten an additional 1/4 turn with pliers. Do not overtighten.
4. Attach the other female end of the 12" hose to the wye adapter.
5. Attach the straight end of the 60" hose to the wye adapter. Hand-tighten, then tighten an additional 1/4 turn with pliers. Do not overtighten.
6. Attach the washer inlet hose to the other side of the wye adapter. Hand-tighten, then tighten an additional 1/4 turn with pliers. Do not overtighten.
7. Connect the opposite end of the 60" hose to the fill valve located on the back of the dryer. Hand-tighten, then tighten an additional 1/4 turn with pliers. Do not overtighten.
8. Slowly turn on the cold water supply valve to its full open position, then check the wye adapter and hoses for leaks.
9. Make sure that there are no kinks and that the hoses and wye adapter are not stretched. Components should not be exposed to heat, open flame, or corrosive materials.

