

zedliner[®]
FLEXSTEEL

 **bedgear**[®]

HOW TO ATTACH THE DRI-TEC[®] SLEEP KIT



INCLUDES:

- (1) Pillow Cover
- (1) Top Backrest Cover
- (1) Bottom Footrest Cover

GETTING STARTED

Remove the fitted sheets and pillowcase from the bag. Each fitted sheet is labeled to indicate its placement.

Recline the chair fully so the leg rest extends, exposing the zipper between the seat and backrest.



Step 2: Secure the Sheets

Unzip the zipper connecting the seat and backrest.

Tuck the **BEDGEAR** Powerband® Strap underneath to hold the sheets in place.

Zip back up once tucked.



Step 1: Install the Sheets

Top Backrest Cover: Slip the backrest sheet over the cushion, starting at the top and working your way down towards the seat.

Bottom Footrest Cover: Locate the bottom of the fitted sheet, where tag indicator is. Slip this sheet over the leg rest, working up towards the backrest, then place over the **BEDGEAR** Powerband® Strap.



Step 3: Add the Pillowcase

Slip the pillowcase over the head pillow.

Note: You do not need to remove the pillow to apply the pillowcase.

Your Zecliner® is now ready for sleeping!