


NOTES:

- The included Glass Shade is designed for this fixture only. Do not install any other shade.
- Instructions are applicable to sconce and surface mount versions.

REQUIRED TOOLS:

- Phillips Head Screwdriver

INCLUDED HARDWARE + TOOLS:



Wiring Kit (x1)



8-32 x 1" Screws (x2)

INSTALLATION INSTRUCTIONS

1. Wire the Wood Fixture to junction box using provided Wiring Kit and Optional Circle Bracket. Consult electrician if necessary.
2. Mount the Wood Fixture to junction box using the 8-32 Screws (x2).
3. Place the Brass Spacer and Glass Shade on the Threaded Socket.
4. Screw the Threaded Washer onto Threaded Socket to secure parts.

