

90203

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock. Use min 90°C supply conductors.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Thread two mounting screws (6) through the mounting plate (7) and secure with the hex nut (9).
2. Secure the mounting plate(7) to the outlet box(1) with box screws(10).
3. Pull out the wires and ground wire from the Outlet Box(1).
Make wire connections with wire nut(5)
---White wire from light to White Wire(3) from power source.
---Black wire from light to Black Wire(2) from power source.
---Tie the ground wire(4) from fixture and from outlet box(1) to the ground screw(8) on the mounting plate(7).
4. Attach the fixture canopy(11) to the outlet box (1), secure it with the knobs (12).
5. Install 9W LED A19 bulbs:(bulbs(14) not included)
(Don't exceed the maximum wattage recommended on the Socket (13).
6. Raise up the shade(16) to the canopy(11) and secure with decorative screws(15).

MIN 90°C SUPPLY CONDUCTORS
INSTALLATION IS NOW COMPLETED

