

208104
INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.
Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Unscrew the canopy nuts (10) from the canopy (4) to detach the mounting plate (7).
2. **Attach the mounting plate (7) with box screws (8) to the outlet box.**
3. Thread the central stem (16) onto the fixture assembly (11).
4. Place 1pc metal washer (15), rubber washer (14) and diffuser (13) onto the central stem (16), then secure it with another rubber washer (14), metal washer (15) and the finial (12).
5. Align the holes of bracket (1) with the holes on shade (2) and (3), secure it with the nuts (10).
6. Align the holes of bracket (1) with the holes of canopy (4), and then secure it with canopy screw (6) using a screwdriver (not included).
7. Unscrew the fixture screws (9) from the metal frame (13) using a screwdriver (not included).
8. **Attach the mounting plate (7) with box screws (8) to the outlet box.**
9. Pull out the outlet wire and ground wire from the outlet box.
Make wire connections with wire nut (9).
--Connect the white wire (Neutral wire) from the light to the white wire from power source.
--Connect the black wire (Live wire) from the light to the black wire from power source.
--Wrap the grounding wire (green wire or bare copper wire) from the light around the green screw on the mounting plate (7), then connect it to the grounding conductor from power source.
10. Attach the fixture to the outlet box, secure it with the canopy nuts (10).
11. Install 60W Max B10 bulbs (bulbs not included).
(Don't exceed the maximum capacity recommended on the sockets).

