

ASSEMBLY INSTRUCTION

ITEM: 6081-90867-82-6/0-6/6 Upholstered Headboard 6081-90868-82-6/0-6/6 Upholstered Footboard 6081-90863-82-6/0 Upholstered Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE LIST

PART LIST

No.	Drawing	Description	Size	Q'ty
Α		All thread bolt	Ø5/16x4"	8
В	(Half Round Washer	Ø5/16"	8
С	0	Lock Washer	Ø5/16"	8
D		Hexagon Nut Ø5/16"		8
Е	()000000>	Wood Screw	Ø8x25mm	10
F		Wrench	D12mm	1

No.	Drawing	Description	Q'ty
1		Headboard	1
2		Footboard	1
3		Side Rail	2
4		Slats	5
5	Ů	Slats Support	5

