


SCHOOLHOUSE

ELECTRIC & SUPPLY CO.

Backed Utility Stool

Assembly Instructions

INCLUDED HARDWARE:



1/4-20
Carriage Bolt (x6)



1/4 Lock
Washer (x6)



1/4-20
Hex Nut (x6)

REQUIRED TOOL(S):

7/16" Wrench

INSTRUCTIONS:

1. Using (2) Carriage Bolts, (2) Lock Washers and (2) Hex Nuts, attach Brace to Seat through the recessed holes in the top of Seat, as shown in STEP 1 on diagram. Tighten hardware.
2. Using (2) Carriage Bolts, (2) Lock Washers and (2) Hex Nuts, attach Brace to Seat through the holes in the back flange of Seat, as shown in STEP 2 on diagram. Tighten hardware.
3. Using the remaining (2) Carriage Bolts, (2) Lock Washers and (2) Hex Nuts, select the desired height for your Backrest and Attach Backrest to Brace as shown in STEP 3 on diagram. Tighten hardware.

