


SI[®] ZERO EDGE PRO



Owner's Manual



INSTALLERS: PLEASE BE SURE TO LEAVE THIS
MANUAL WITH THE OWNER. THANK YOU!



APPLY S/N
STICKER HERE

Limited 1 year warranty on Screen Innovations products

Screen Innovations warrants its products, to the original purchaser only, to be free from defects in materials and workmanship for a period of one (1) year from the date of purchase by the original purchaser provided they are properly operated according to Screen Innovations' instructions and are not damaged due to improper handling or treatment after shipment from the factory.

This warranty does not apply to equipment showing evidence of misuse, abuse, or accidental damage, or which has been tampered with or repaired by a person other than authorized Screen Innovations personnel.

Screen Innovations' sole obligation under this warranty shall be to repair or to replace (at Screen Innovations' option) the defective part of the merchandise. Returns for service should be made to your Screen Innovations' dealer. If it is necessary for the dealer to return the screen or part to Screen Innovations, transportation expenses to and from Screen Innovations are payable by the purchaser and Screen Innovations is not responsible for damage in shipment. To protect yourself against damage or loss in transit, insure the product and prepay all transportation expenses.

This warranty is in lieu of all other warranties, express or implied, including warranties as to fitness for use and merchant ability. Any implied warranties of fitness for use, or merchantability, that may be mandated by statute or rule of law are limited to the one (1) year warranty period. This warranty gives you specific legal rights, and you may also have other rights, which vary from state-to-state. No liability is assumed for expenses or damages resulting from interruption in operation of equipment, or for incidental, direct, or consequential damages of any nature.

In the event that there is a defect in materials or workmanship of a Screen Innovations product, you may contact our Sales Partners at 9715-B Burnet Road Suite 400, Austin, TX 78758, (512) 832-6939.

Important: this warranty shall not be valid and screen innovations shall not be bound by this warranty if the product is not operated in accordance with screen innovations' written instructions.

Keep your sales receipt to prove the date of purchase and your original ownership.

Table of Contents

SUGGESTED PROJECTOR PLACEMENT 5

STANDARD FRAME PARTS LIST 7

STANDARD FRAME ASSEMBLY 9

SPLIT FRAME PARTS LIST 12

SPLIT FRAME ASSEMBLY 14

LED LIGHTS ATTACHMENT 18

BLACK DIAMOND OR SHORT THROW ATTACHMENT 21

SLATE OR PURE ATTACHMENT 25

 BLACK BACKER ATTACHMENT 28

MAESTRO ATTACHMENT 29

 BLACK BACKER ATTACHMENT 32

SMALL TRIM ATTACHMENT 34

MEDIUM OR LARGE TRIM ATTACHMENT 36

LOGO ATTACHMENT 38

TRIM REMOVAL 39

WALL INSTALLATION 41

FLOWN INSTALLATION 43

IR LIGHTING HEX CODES 45

IP CONTROLLED LIGHTING SETUP 46






Please visit support.screeninnovations.com where you can find cut sheets, Installation instructions, spec sheets, tech notes, guides, drivers and tutorial videos.

For more technical support questions - Call: 512.832.6939 or email: support@screeninnovations.com
 Hours of Support: 7:30am - 5pm CST
screeninnovations.com









Please visit our Screen Material Wizard (screeninnovations.com/tools/screen-material-wizard/) for minimum throw distance requirements based on screen material.





STANDARD FRAME PARTS LIST


(LED Lights Only)




3/4" Small trim option

1 1/2" trim option


Hardware Kit




Wall Brackets




Mounting Screws




4X
1/4-20 x 1/4" Screws
(Small trim only)




Thumb Screws




4X Thick Corner Brackets




4X Thin Corner Brackets




1/8" & 5/32" Hex Keys




4X Gloves




Bungees
(Maestro only)




Acrylic Logo



Channel Nut
(AT only)



Corner Alignment part
(Black Diamond and Short Throw)



If IP controlled LED lights are ordered, Phillips Hue hub must be purchased and set up separately. See page 41 for IP lighting Instructions.

LED IR Controlled Only




LED Remote




LED Foam


Flying Mount Only




2X Flown Screen Mount




2X Flown Ceiling Mount



2X Flown Cable




STANDARD FRAME ASSEMBLY




NOTE: If using AT or Maestro material then check to make sure the channel nuts are installed in the inner channel before proceeding.


1




2




Insert the thin corner brackets into the outside channels and the thick corner brackets into the inside channels of the vertical frames. Then slide into the channels in the horizontal frames.



3








4




Make sure the points on the frame pieces line up. Then finger tighten 2 of the set screws to lock in the corners.

5




$A = B$

6








Measure the diagonals to check if frame is square. If one diagonal is longer then push on the corners at that diagonal. Tighten all set screws once the diagonals are equal to within 1/8".



SPLIT FRAME PARTS LIST


(LED Lights Only)




3/4" Small trim option

1 3/4" Trim option

Hardware Kit




Wall Brackets




Mounting Screws




4X
1/4-20 x 1/4"
Screws
(Small trim only)




Thumb Screws




4X Thick Corner Brackets




4X Thin Corner Brackets




1/8" & 5/32"
Hex Keys




4X Gloves




Bungees
(Maestro only)




Acrylic Logo



Channel Nut




Corner Alignment part



If IP controlled LED lights are ordered, Phillips Hue hub must be purchased and set up separately, see page 46 for IP lighting Instructions.

LED IR Controlled Only




LED Remote




LED Foam


Flying Mount Only




2X Flown Screen Mount




2X Flown Ceiling Mount



2X Flown Cable




SPLIT FRAME ASSEMBLY




NOTE: If using AT or Maestro material then check to make sure the channel nuts are installed in the inner channel before proceeding.

1





2




Insert the thin corner brackets into the outside channels and the thick corner brackets into the inside channels of the vertical frames. Then slide into the channels in the horizontal frames.

3




4




Slide the horizontal frame pieces together and secure with the splice bars. Then attach the vertical support to the frame as shown.

5








6




Make sure the points on the frame pieces line up. Then finger tighten 2 of the set screws to lock in the corners.

7




A = B

8



Measure the diagonals to check if frame is square. If one diagonal is longer then push on the corners at that diagonal. Tighten all set screws once the diagonals are equal to within 1/8".






If IP controlled LED lights are ordered, Phillips Hue hub must be purchased and set up separately, see page 50 for IP lighting Instructions.


NOTE: Steps 1 and 2 will have already been completed if possible to be shipped that way. If so skip to step 3.

1





Connect the lighting harness with the included screws to the nuts in the frame piece with the lights attached to it.

2




Plug in the lights to the controller plugs.

3




Press in the lights to the channel on the frame. LED foam must be used when rounding the corners. Failure to do so will damage the LED strips




Cut the light strips at the copper pad as indicated to the correct length such that they just overlap at the middle of the top frame piece. DO NOT cut the light strips at any other location.

**BLACK DIAMOND or
SHORT THROW**






SLATE or PURE



MAESTRO




1




Wear gloves when handling material. Carefully unroll the screen material out onto a clean floor. Take care to not bend or crease the screen material.

2




Carefully lie the frame onto the screen material. Center the frame about the screen material.

3




Remove and discard the black retaining bumpers then spread out the posts so that they align with the snaps on the screen material.

4



Attach the snap attachments at the middle and then work your way towards the ends on all 4 sides of the screen material. Check to make sure the screen material is flat and adjust the snaps positions if necessary to flatten the screen material.

5





SLATE OR PURE



Then check to make sure the screen material is flat and adjust the snap positions if necessary to flatten the screen material. Once all snaps are attached **flip screen over and make sure that the screen material is flat and tight everywhere.**



Black diamond and short throw material are highly sensitive. Take care to not bend or crease the material as you unroll it.




BLACK DIAMOND OR SHORT THROW

Then check to make sure the screen material is flat and adjust the snap positions if necessary to flatten the screen material. Once all snaps are attached **flip screen over and make sure that the screen material is flat and tight everywhere.**

For AT Material Only


6

Acoustically Transparent (AT) materials come with a black backer that must be installed to eliminate shine through.





Spread out the nuts in the top frame piece and attach the black backer to the nuts with the thumb screws. **Flip screen over and make sure that the screen material is flat and tight everywhere.**

Note: If the notch in the black backer is not aligned with the vertical support then flip it over.





1




Wear gloves when handling material. Carefully unroll the screen material and black backer out onto a clean floor. Take care to not bend or crease the screen material.

2




Insert the rods into the pocket in the screen material. Make sure the screen material is lying flat. If the screen material is bunched up at the rods then work from the middle out spreading out the screen material until it is flat.

3




Carefully lay the frame onto the screen material and black backer. Center the frame about the screen material.

4




Remove and discard the black retaining bumpers then spread out the posts so that they aligning with the holes in the screen material and black backer.

5





Put one end of the bungee through the hole in the material and black backer and place over the post while holding the other end. Then pull the other end of the over the post. Do this at all 4 corners first. **Make sure the screen material is centered about the frame before proceeding.**

6




Attach the bungees at the middle and then work your way towards the ends on all 4 sides of the screen material. Check to make sure the screen material is flat and adjust the bungee positions if necessary to flatten the screen material.






Velvet on trim is delicate, handle with care. Install trim with screen flat on floor, viewing side up, NOT when screen is vertical.

1




Attach the **vertical trim first** onto the screen as shown above.

2



Attach the horizontal trim pieces. Align and secure the corners with the 1/4-20 x 1/4" screws as shown. Hold the trim corners together while tightening the screw to ensure a well aligned corner.




Split Frame Only: Connect the horizontals at the middle by installing quantity 4 1/4-20 x 1/4" screws trough the trim into the splice bar.






Velvet on trim is delicate, handle with care. Install trim with screen flat on the floor with the viewing side up, not when screen is vertical.

1



Attach the trim onto the screen as seen above.


2



Loosen the screw on the corner plate, slide over to the corner, and hold the corners together while tightening the screw to secure the well aligned corners.


Split Frame Only: Loosen the screw on the center cover plate, slide over to the middle, and hold together trim pieces while tightening the screw to secure the well aligned center trim seam.



1



Attach the logo to the trim by holding it at the middle of the horizontal trim and letting the magnet pull it to and attach to the back of the trim.




NOTE: You can also attach the logo to the screen after it is installed on the wall or floor. The trim can attach to either horizontal trim piece. However if your screen has lights make sure the trim is attached to the side of the screen with the lighting harness.







WALL INSTALLATION



1




2




3




FLOWN INSTALLATION





1




2



3



4



NOTE: If you pull too far the screen can be lowered by pushing down the button on the top of the flying mount.

 We recommend you don't cut the extra cables for future adjustability. Simply tape the extra cable to the back of the screen frame.

IR Controlled Option Only

2013 5CA3	2013 5DA2	2013 41BE	2013 40BF
2013 58A7	2013 59A6	2013 45BA	2013 44BB
2013 54AB	2013 55AA	2013 49B6	2013 48B7
2013 50AF	2013 51AE	2013 4DB2	2013 4CB3
2013 1CE3	2013 1DE2	2013 1EE1	2013 1FE0
2013 18E7	2013 19E6	2013 1AE5	2013 1BE4
2013 14EB	2013 15EA	2013 16E9	2013 17E8
2013 10EF	2013 11EE	2013 12ED	2013 13EC
2013 0CF3	2013 0DF2	2013 0EF1	2013 0FF0
2013 08F7	2013 09F6	2013 0AF5	2013 0BF4
2013 04FB	2013 05FA	2013 06F9	2013 07F8


Backlight IP Option Only

Before attempting to connect your LED IP to Phillips Hue, ensure that the Hue Bridge is powered on and connected to the local WIFI network.

1. Begin by connecting the power supply to an electrical outlet. After a few seconds, the LEDs should power on to a white color.
2. Open the Phillips Hue app on your smart device, and navigate to **Light Setup** in the **settings tab**.
3. Press the **Plus** button in the lower right-hand corner, then press **Search**.
4. It can take several seconds to connect. Once connected, the LEDs will light green.
5. The LED IP will appear in the Phillips Hue app as **Extended Color light 1** and **Dimmable light 1**. Only use **Extended Color Light 1** to control the LED's. **Dimmable Light 1** should be deleted.
6. After the LED IP is connected, it can be renamed and used like any Hue lamp.



Reset Instructions (Required to connect to a different Phillips Hue)

1. Begin with the LED IP powered on
2. Turn off for a minimum of 2 seconds
3. Turn on and wait for LEDs to light
4. Repeat the off/on procedure a total of four times
5. At this point the LEDs will begin blinking for 10 seconds.
6. Once the LEDs stop blinking, repeat the off/on procedure two more times
7. At this point the LED IP will reset. Once complete, the LEDs will light a white color



Note: The LED IP can be connected and controlled by only one Phillips Hue Bridge at a time

1



Disconnect the trim at the corners by either removing the screw or loosening the corner plate and sliding over.

Then push in on trim pieces while rotating trim off of frame. The magnet will hold the trim in place at first. Therefore you may need to shake the trim at first to get it to rotate away from the frame.

NOTES

1. _____

2. _____

3. _____

4. _____

5. _____

6. _____

7. _____

8. _____

9. _____

10. _____

11. _____

12. _____

13. _____

14. _____

15. _____

16. _____

17. _____

18. _____



Screen Innovations

9715-B Burnet Rd, Suite 400 Austin, TX 78758

512.832.6939

www.screeninnovations.com