

Two-Hole Tubular Full Bath Waste Kit

Parts List

- | | |
|----------------------|-----------------------------|
| A. Stopper Assembly | G. Gasket (Qty. 2) |
| B. Spud | H. Overflow Elbow |
| C. Drain Gasket | I. Overflow Gasket |
| D. Drain Elbow | J. Overflow Faceplate |
| E. 1.5" Tee | K. Faceplate Screw (Qty. 2) |
| F. Slip Nut (Qty. 2) | |

Additional Parts Needed

- Pliers
- Screwdriver

Installation Instructions

1. Place the overflow gasket (I) onto the overflow elbow (H) and insert into the tub overflow hole from the back of the tub.
2. Set the drain elbow (D) under the tub with the drain gasket (C) between the drain elbow (D) and the tub.
3. Screw in the spud (B) through the tub into the drain gasket (C) and drain elbow (D). Use a pliers to secure the spud (B).
4. Place a slip nut (F) (threads facing outward) and a gasket (G) on the drain elbow (D) and on the overflow elbow (H).
5. Set the 1.5" tee (E) in place in the drain line and tighten both slip nuts (F).
6. Attach the overflow faceplate (J) to the overflow elbow (H) using the two faceplate screws (K).
7. Install the stopper assembly (A) into the spud (B).
8. Tighten all connection points.
9. Water test the installation by filling up a tub with water to the overflow opening and checking for leakage.

