


# KINGSTON

REPLACE YOUR EXISTING  
DRAIN FLOOR

## INSTALLATION

1. Remove floor covering and debris from the drain floor area.
2. To install the drain, apply adhesive to the drain.
3. Set drain in the spot.
4. Press down gently to set the drain into the adhesive. Do not move the drain.
5. Wipe off the excess adhesive.
6. Allow the adhesive to cure for 24 hours before using the drain.



**WARNING:**  
DO NOT USE THIS PRODUCT IN CONTACT WITH  
FLAMMABLE LIQUIDS OR GASES. ALWAYS  
USE PROPER VENTILATION.