



A special water-based formulation designed for tacking between coats of wood seals and finishes. Tack-It[®] removes dust and dirt that may have settled on the floor and ensures a clean surface for coating to bond with. It leaves no greasy or oily residue to destroy gloss and promotes proper adhesion between coats.

Features & Benefits

Leaves no greasy, oily residue and leaves the floor ready to go

Removes dust and dirt without irritating fumes to not bother building occupants

Dries in 30 minutes under normal drying conditions

Item Number & Unit of Measure

Item Number	HIL0045807
Unit of Measure	5 gal BIB

Specifications

Color	Colorless
Appearance	Clear
Fragrance	Mild IPA
Formula Type	Liquid
Dilution Ratio	RTU - 1:32
PH	6.00 - 8.00

Safety

See safety datasheet (if applicable) and product label for safety information, handling and proper use.

Directions for Use

Tacking: Soak terry cloth towel in Tack-It. Wring out toweling so that it is saturated but not dripping. Place towel under broom or dust mop and begin tacking. After each pass, adjust towel in order to maintain a clean edge. Re-soak toweling when it begins to dry out. Tack-It can also be used with the Court Clean [®] systems (TKH100 and TKH101). Allow floor to dry at least 30 minutes before applying seal or finish. For best results, use non-linting towels and tack the floor a final time with a cleaning cloth similar to Hillyard Item No. CHI415. Cleaning: Tack-It can also be used for light cleaning of wood floors. Dilute Tack-It at 4-6 ounces per gallon. NOTICE: DO NOT use on raw wood. DO NOT use Tack-It to tack membrane curing compounds. DO NOT SPRAY ON HOT SURFACES. NOTICE: Saw dust from freshly sanded floors or dust from wood floors that have been abraded between coats will spontaneously catch fire if improperly discarded. Immediately after abrading or sanding wood floors, place dust waste in a sealed, water-filled metal container and immediately remove from building. NOTICE: Rags or applicators soaked in a combustible liquid will spontaneously catch fire if improperly discarded. Immediately after using rags or applicators soaked in a combustible liquid, place waste in a sealed, water-filled metal container and immediately remove from building