

JSG381 1/8" Mini Patch / Plug Combo Instructions

Directions

1. Remove tire from wheel. If injury is repairable, mark injury and remove puncturing object and other debris.
2. If injury does not exceed 25° and no larger than 1/8", the Mini Patch / Plug Combo may be used.
3. Center patch-head over the injury and outline an area slightly larger than the path to define the repair area.
4. Clean repair area with STEELMAN Liquid Buffer and an inner liner scraper. Once dry, mechanically buff to a velvet texture.
5. Using a burr, clear injury channel of all debris. DO NOT ENLARGE INJURY. Vacuum debris from repair area.
6. Using cement probe, apply vulcanizing cement to injury channel. Also apply a thin coat to the repair area.
7. Once cement is completely dry, remove protective covering from the patch. DO NOT touch the gum surface.
8. Pass the wire through the channel and pull the wire from the outside using a pair of pliers. Pull into seated position.
9. Stitch patch down firmly and remove clear film. Cut off stem 1/8" above thread surface. Repair is complete.