

## Bathtub Trim Kit with Snap-On Faceplate

**Note:** Compatible with Jones Stephens' quick test style bath waste kits.

## Parts List

B. Spud

- A. Stopper Assembly
- C. Drain Gasket D. Faceplate

**Note:** Depending on the model, the package includes a faceplate and a drain or a faceplate and a stopper.

## **Additional Parts Needed**

• Pliers

## **Installation Instructions**

- 1. To install the faceplate (D), snap it onto the existing retainer nut, making sure that the slot is facing downward.
- 2. To install the stopper assembly (A), insert it into the existing drain.
- 3. To install the drain (B-C), place the drain gasket (C) underneath the tub and screw the drain spud (B) into the existing drain elbow, through the drain gasket (C). You can use a pliers to help install the spud.

