



A technologically advanced, optimum-solids polish perfected for high speed and ultra-high speed floor care. It is based on high-tech polymers that will deliver durable, deep gloss protection for your floors. Endeavour was designed to be the polish of choice for areas where heavy traffic, grit, dirt, scuffs, and black heel marks torture an ordinary polish to a dull death. It stands up to repeated cleaning with detergents and keeps shining.

**Features & Benefits**

Stands up to repeat cleaning with detergents and keeps shining

Repeated burnishing just makes it better

Levels beautifully and dries fast for building a durable base

**Item Number & Unit of Measure**

|                 |              |
|-----------------|--------------|
| Item Number     | HIL0052506   |
| Unit of Measure | 1 gal Bottle |

**Specifications**

|                     |                   |
|---------------------|-------------------|
| Color               | White             |
| Appearance          | Milky Emulsion    |
| Fragrance           | Non-Objectionable |
| Formula Type        | Liquid            |
| Dilution Ratio      | RTU               |
| PH                  | 8.00 - 9.00       |
| Non-Volatile Matter | 18.0%             |

|                      |           |
|----------------------|-----------|
| Solids Content       | 18.0%     |
| Coverage SqFt/Gallon | 1500-2000 |
| Burnishable          | Yes       |
| Dry Time (hrs.)      | 1         |
| Sheen                | Gloss     |
| UL Certified         | Yes       |

**Safety**

See safety datasheet (if applicable) and product label for safety information, handling and proper use.

**Directions for Use**

**Preparation: New floors:** After resilient flooring has been installed and the adhesive has cured for at least 2 weeks, scrub with a solution of Hillyard Recoat Prep or Assurance, following label directions, and a blue pad to remove factory finish. Pick up scrubbing solution with an automatic scrubber or wet vacuum. Flood rinse with a solution of Hillyard Nutra-Rinse and pick up solution with an automatic scrubber or wet vacuum. Damp mop rinse twice with water and allow to dry for at least 1 hour. **Scrub and recoat:** Scrub the existing floor polish with a solution of Hillyard Recoat Prep or Assurance, following label directions, and a blue pad. Pick up scrubbing solution with an automatic scrubber or wet vacuum. Flood rinse with a solution of Hillyard Nutra-Rinse and pick up solution with an automatic scrubber or wet vacuum. Damp mop rinse twice with water and allow to dry for at least 1 hour. **Stripping:** Strip Endeavour or other polishes from the floor with a solution of Hillyard Arsenal Stripper, Devastator, or Power-Strip, following label directions. Pick up scrubbing solution with an automatic scrubber or wet vacuum. Flood rinse with a solution of Hillyard Nutra-Rinse and pick up solution with an automatic scrubber or wet vacuum. Damp mop rinse twice with water and allow to dry for at least 1 hour. **Application:** When using a sealer, apply a minimum of 5 coats of Endeavour at a rate of 1500-2000 ft<sup>2</sup>/gallon with a microfiber flat finish mop or Multi-Flo XP. Allow

each coat to dry a minimum of 30 minutes before applying the next. When a sealer is not used, apply a minimum of 7 coats of Endeavour. **NOTE:** Allow for longer dry time between coats of finish if the humidity is above 80% or the floor temperature is below 60°F (16 °C). For best results, do not apply more than 3-4 coats per day. **Maintenance:** Use a cotton dust mop, treated with Hillyard Super Hil-Tone, daily to remove loose dirt and grit. Damp mop or autoscrub, as scheduled, with Hillyard Super Shine-All®, Top Clean®, or Arsenal® Heavy Duty Floor Cleaner. After the floor has been cleaned, gloss may be restored by dry burnishing. Use Hillyard Restorer, as scheduled, to repair and increase the gloss of the finish. Scrub and recoat, as scheduled, with a minimum of 2 coats of Endeavour. **FLOOR PAD RECOMMENDATIONS:** **Stripping:** black; **Scrub and Recoat:** blue; **Autoscrubbing:** red. **NOTICE:** Do not use an ammoniated cleaner for daily care. If the floor is very porous, seal with Hillyard Hil-Tex+®, Seal 341® or Seal 340® before applying Endeavour. If stains are a problem, seal with Strong Guard®. Do not pour unused finish or seal back into the original container.