

## IO PC. 3/8 IN. DR. FLARE NUT SOCKET SET



and bolts and is suitable for limited • Includes: 10 mm, 11 mm, 12 mm, 13 mm. 14 mm. 15 mm. 16 mm. 17 mm. • Use on sensors, ABS pipe, master 18 mm and 19 mm



## performancetool.com

cylinders, coolant, fuel injectors, and diesel inject sensors and lines

access spaces

P.O. Box 88259 Tukwila, WA. 98138 1-800-426-1262 (USA & Canada) 1-800-352-9185 (Fax)