
## The Georgian Bathroom Collection Installation & User Guide



Congratulations on the purchase of your Perrin & Rowe Bathroom Product. Correctly installed and with sensible care, this product will give you many years of trouble free service.

#### **IMPORTANT INFORMATION**

Before you proceed... We recommend you engage the services of a registered plumber to install this product.


For ease of possible future servicing, we also recommend the fitting of conveniently placed isolating valves.

In addition to the guide below it is essential that the written information overleaf is carefully read and understood.

#### **Preparation Check Box for Installer**

Flush the plumbing system before installing the bathroom product.


Once unpacked remove large & small base seals, rosette, hood & lever, securing nut, clamp plate, pop-up and top waste ready for installation.



### Fit two 3/4" NPT female fittings into the wall at 7 7/8" Centers. Fit a 3/4" NPT male shank (not


supplied) into the fitting so that no more then 5/8" of thread is protruding from the wall. Apply thread sealing material to shank and screw union onto shank. Turn union to required postion and slide rosette up to wall surface. A silicone seal can be applied between the wall rosette if required.

#### **Hand Shower and Cradle**



#### **Extended Pillar Unions**

Remove backnut and fiber washer from union. From top pass shank through hole in surface ensuring that the base seal remains position. Replace backnut and fibre washer onto shank and tighten by hand only so that unions can still rotate.



#### **BEFORE USE**

- Carefully check the installation for leaks.
- If further building work is to be carried out in the vicinity, cover the product with a plastic bag to avoid damaging the finish.
- $\bullet$  Please ensure that the installation complies with local plumbing codes.

#### **CARE & MAINTENANCE**


Wipe down after use to avoid water spotting and mineral build up.

Occasional cleaning with warm soapy water, followed by a polish with a soft cloth is all that is required to keep the plated finish in good condition.

Do not use proprietary abrasive liquids, powders, or pads to clean the shower. Do not use any products with ammonia bleach or limescale remover. You will damage the plated finish and void your guarantee.



# Floor Legs For Tub/Shower Mixer



Congratulations on the purchase of your Perrin & Rowe Product. Correctly installed and with sensible care, this product will give you many years of trouble free service.


#### IMPORTANT INFORMATION


Before you proceed... We recommend you engage the services of a registered plumber to install this product.

For ease of possible future servicing, we also recommend the fitting of conveniently placed isolating valves.

In addition to the guide below it is essential that the written information overleaf is carefully read and understood.

#### **Preparation Check Box for Installer**





#### **BEFORE USE**

- Carefully check the installation for leaks, internal leaks will be noticable through the Access Slot.
- If further building work is to be carried out in the vicinity, cover the tap to avoid damaging the finish.
- Please ensure that the installation complies with local plumbing codes.

#### **CARE & MAINTENANCE**

Wipe down after use to avoid water spotting and mineral build up.

Occasional cleaning with warm soapy water, followed by a polish with a soft cloth is all that is required to keep the plated finish in good condition.

Do not use proprietary abrasive liquids, powders, or pads to clean the shower. Do not use any products with ammonia bleach or limescale remover. You will damage the plated finish and void your guarantee.