

ITEM# 81560

Bella Maison 60" TV console

**Leick**  
Home  
SINCE 1910

2219 S. 19th St.


Sheboygan, WI 53081

Ph: 920-451-4060









Fax: 920-451-4063

info@leickhome.com








www.leickhome.com



Hardware List






Item	Description	Qty
a	 Bolt 1/4" X 1-1/8"	6PCS
b	 Allen wrench	1PC
c	 Washer 1/4" X 12mm	6PCS
d	 Flat Shelf Supports	12PCS
e	 Left Door Pull	2PCS
f	 Right Door Pull	2PCS
g	 Machine screw for door pull 5/32" X 3/4"	4PCS
h	 Rounded Shelf Supports	8PCS

# Parts List

Item	Description	Qty
	Cabinet	1PC
	Top Panel	1PC
	Side Panel	2PCS
	Middle Bottom Panel	1PC
	Side Bottom Panel	2PCS
	Middle Adjustable Shelf	1PC
	Side Adjustable Shelf	2PCS

# Assembly Instructions

Two person assembly recommended.

<p><b>Step: 1</b> Unfold Cabinet.</p> 	<p><b>Step: 2</b> 2.1 Open four doors. 2.2 Screw-in 8 round shelf supports (h) onto vertical panels. 2.3 Insert middle bottom panel (D) and side bottom panels (E).</p> 
<p><b>Step: 3</b> Insert side panels (C).</p> 	<p><b>Step: 4</b> 4.1 Place the top panel (B) above the case, make sure all wooden dowels are fully inserted into the holes on top panel's bottom surface. 4.2 Fasten the top panel (B) with 6 bolts. Slightly push the upper frame of back panel inward to keep it aligned with top panel's back edge if needed while inserting the allen bolt.</p> 
<p><b>Step: 5</b> Install flat shelf supports (d) and insert shelves (F and G).</p> 	<p><b>Step: 6</b> Install door pulls (e and f).</p> 