



SNAVELY VINYL DOOR SWEEP INSTALLATION

FOR WOOD & VINYL DOORS

- 1) If your current door has one, unscrew the existing door sweep.*
- 2) Place the new door sweep on the bottom edge of your door ensuring the edge with the holes (the longer of the two sides) is on the inside of your door.*
- 3) Adjust the height so that the sweep butts up against the edge of the door sill.*
- 4) Using the provided screws and a #1 Robertson screw driver (square head), screw the sweep to your door.*

