

ASSEMBLY INSTRUCTIONS

1. Line up Notches in Acrylic Diffuser with Sockets.
2. Lower Acrylic Diffuser at an angle toward one Socket. When one Notch in the Acrylic Diffuser clears one Socket, lower the diffuser further.
3. Continue to line up remaining two Notches with the remaining two Sockets and lower completely until the diffuser rests flat on Base Plate.
4. Install light bulbs.
5. Lower Linen Shade onto Threaded Post.
6. Place Perforated Diffuser onto Threaded Post and secure by screwing on Finial.

