

25501

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Install the bulb (1) to the socket (2) (60W Max. type A bulb, not included), (Don't exceed the maximum capacity recommended on the sockets).
2. Attach the shiny opal glass (7) to the bracket (3) and secure in place using the cap (4) and the connect part (5). Do not secure too tightly.
3. Screw the center tube (6) to the top of the connect part (5).
4. Insert the mounting screws (14) through the mounting bar (12) and secure in place using nuts.
5. Attach the mounting bar (12) to the outlet box with the outlet box screws (11). Moderately adjust the cable clip (14), and unfasten the hex nut inside the canopy (10) by wrench (8) to adjust the wire to the appropriate length, and then use a wrench (8) to lock the hex nut.
6. Pull out the outlet wire and ground wire from the outlet box.
Make wire connections with wire nut (12).
--Connect the ribbed wire w/o marking (Neutral wire) or white wire from the light to the white wire from power source.
--Connect the wire with the markings and smooth surface (Live wire) or black wire from the light to the black wire from power source.
--Wrap the grounding wire (green wire or bare copper wire) from the light around the green screw on the mounting bar (12), then connect it to the grounding conductor from power source.
7. Raise the canopy (10) up to the ceiling until the screws protrude through. Then secure the canopy (10) in place with the finials (9).

